FOREWORD

This manual is an essential part of your vehicle and should remain with the vehicle when resold or otherwise transferred to a new owner or operator. Please read this manual carefully before operating your new MARUTI SUZUKI and review the manual from time to time. It contains important information on safety, operation and maintenance. You are invited to avail the three Free Inspection Services as described in the manual. Three free inspection coupons are attached to this manual. Please show this manual to your dealer workshop while you take your MARUTI SUZUKI for any Service.

To prolong the life of your vehicle and reduce maintenance cost, the periodic maintenance must be carried out according to "PERIODIC MAINTENANCE SCHEDULE" described in "INSPECTION AND MAINTENANCE" section of this manual. It is essential for preventing trouble and accidents to ensure your satisfaction and safety.

Daily inspection and care as per "DAILY INSPECTION CHECKLIST" described in the "OPERATING YOUR VEHICLE" section of this manual is essential for prolonging the life of the vehicle and for safe driving. Vehicle and the available features/accessories therein should be used and plied by the owner/user in accordance with the applicable legal requirements.

MARUTI SUZUKI INDIA LIMITED believes in conservation and protection of Earth's natural resources.

To that end, we encourage every vehicle owner to recycle, trade-in or properly dispose of, as appropriate, used Engine Oil, coolant and other fluids, batteries and tyres etc.

MARUTI SUZUKI INDIA LIMITED

All information in this manual is based on the latest product information available at the time of publication. Due to improvements or other changes, there may be discrepancies between information in this manual and your vehicle. MARUTI SUZUKI INDIA LIMITED reserves the right to make production changes at any time, without notice and without incurring any obligation to make the same or similar changes to vehicles previously built or sold.

This vehicle may not comply with standards or regulations of other countries. Before attempting to register this vehicle in any other country, check all applicable regulations and make any necessary modifications.

IMPORTANT

WARNING CAUTION/NOTICE/ NOTE

Please read this manual and follow its instructions carefully. To emphasize special information, the symbol and the words **WARNING, CAUTION, NOTICE** and NOTE have special meanings. Pay particular attention to messages highlighted by these signal words:

A WARNING

Indicates a potential hazard that could result in death or serious injury.

A CAUTION


Indicates a potential hazard that could result in minor or moderate injury.

NOTICE

Indicates a potential hazard that could result in vehicle damage.

NOTE:

Indicates special information to make maintenance easier or instructions clearer.



The circle with a slash in this manual means "Don't do this" or "Don't let this happen".

NOTE:

- Words like car, model/variant are invariably used in this manual to denote the "Vehicle".
- Pictorial representations used in this manual are for reference purposes only.

MODIFICATION WARNING

Do not modify your vehicle. Modification could adversely affect safety, handling, performance, or durability and may violate governmental regulations. In addition, damage or performance problems resulting from modification shall not be covered under warranty.

NOTICE

Improper installation of mobile communication equipment such as cellular telephones, CB (Citizen's Band) radios may cause electronic interference with your vehicle's ignition system, resulting in vehicle performance problems. Consult your Maruti Suzuki authorised workshop or qualified service technician for advice on installing such mobile communication equipment.

NOTICE

The diagnostic connector of your vehicle is prepared only for the specific diagnostic tool for inspection and service purpose. Connecting any other tool or device may interfere with electronic parts operations and cause running out of batteries.

"WARNING"



Vehicle may break-down, meet with an accident or catch fire due to

- 1. Installation of
 - High wattage bulbs
 - Non genuine lamps / horns
 - Modified suspension / wheels
 - Non genuine parts / accessories etc.
- 2. Retrofitment of LPG / CNG fuel systems/kits.
- 3. Usage of domestic LPG.
- 4. Short circuiting due to tampering of wiring harness.

CAUTION: DO NOT STORE OR CARRY INFLAMMABLE MATERIALS IN THE VEHICLE.



Avoid driving into or starting the vehicle in a heavily water logged area. Vehicle may breakdown or engine may fail due to

1. Water entry into the engine (which may lead to hydrostatic lock).

2. Short circuiting of the electrical systems.

If the vehicle is stuck in deep water, do not start / crank the vehicle until the level of water drops below the level of exhaust pipe.

NOTE:

IF THE VEHICLE IS SUBMERGED IN WATER, REPORT TO THE NEAREST AUTHORIZED WORKSHOP.

"CAUTION"

- 1. Retro-fitment of LPG / CNG kit may deteriorate vehicle performance, reduce engine & engine related component's life and also warranty will be null and void for such vehicles.
- 2. Do not use domestic LPG/LPG cylinder for your factory fitted LPG vehicles.
- 3. Usage of domestic LPG for running vehicles is prohibited as per law.
- 4. Do not remove company fitted LPG/CNG kit to install some other kit. It may affect vehicle performance and may cause fire.
- 5. Drive slowly on wet roads. Tires may slip while braking at higher speeds due to aquaplaning. (reduced contact area between tire and road due to presence of water)
- 6. Do not leave engine running in garages or confined areas, with passengers inside. This may result in accumulation of carbon-monoxide in cabin and may lead to suffocation or breathing problems.
- 7. Do not park vehicle on dry leaves or grass. This may lead to fire due to hot catalytic converter, igniting the dry leaves/grass.
- 8. If the vehicle is equipped with CNG/LPG, ensure availability of fire extinguisher in the vehicle all the time.
- 9. Always wear seat belt at all the times.
- 10. Do not use mobile phone while driving.
- 11. Avoid Smoking in the car, live bud thrown in car may cause fire.
- 12. Do not put any body part under the vehicle when it is supported on a Jack.
- 13. Do not use non-genuine accessories in your vehicle.
- 14. Do not fit accessories from unauthorized workshops/sources.
- 15. Usage of non-approved electrical accessories in your vehicle may result in spark, fire or personal injury.

VIN:														
MODEL:	•	·	•		· ·	ow		·			·	·		÷
VARIANT:							/IE & DRESS	5						
COLOUR:														
ENGINE NO.:						CON	ITACI	NO.						
KEY NO.:						E-m	ail ID:							
INVOICE DATE:						0.51			1					
ODOMETER READING					KM	DEA	LING	AME						
REGISTRATION NO.:						- & C	ODE							
BATTERY MAKE:														
BATTERY NO.:						SHC	WRO							
BATTERY BATCH						ADDRESS & CONTACT NO. (STAMP)								
TYRE	MAKE		BA	тсно	ODE	(0.1	,							
Front Right														
Front Left														
Rear Right						APF		MENT						
Rear Left							•	-						
Spare						1								

For any assistance with regard to our product, please contact General Manager/Works Manager at any of our Dealer or Authorised workshop. For additional enquiry, you may contact our Regional Office or Service Department. The addresses and phone numbers are given in Service Network section of this Manual.

INSPECTION SCHEDULE	DATE OF SERVICE	MILEAGE (KM)	NAME OF SERVICING WORKSHOP
1 st Free inspection service - 1000 KM / 1 Months			
2 nd Free inspection service - 5000 KM / 6 Months			
3 rd Free inspection service - 10000 KM / 12 Months			
1 st Paid inspection service - 20000 KM / 24 Months			
2 nd Paid inspection service - 30000 KM / 36 Months			
3 rd Paid inspection service - 40000 KM / 48 Months			
4 th Paid inspection service - 50000 KM / 60 Months			
5 th Paid inspection service - 60000 KM / 72 Months			
6 th Paid inspection service - 70000 KM / 84 Months			
7 th Paid inspection service - 80000 KM / 96 Months			
8 th Paid inspection service - 90000 KM / 108 Months			
9 th Paid inspection service - 100000 KM / 120 Months			
10 th Paid inspection service - 110000 KM / 132 Months			
11 th Paid inspection service - 120000 KM / 144 Months			
12 th Paid inspection service - 130000 KM / 156 Months			
Maruti Suzuki Network can be viewed <u>For Arena Models:</u> <u>For</u>	<u>r Nexa Models;</u>	w Mobile Apps:	GET IT ON Google Play Available on the App Store
Maruti care		Nexa	

						¦ N	Node	l Na	me										1	Model	Name									
Model Code*							Mode	el Co	de*										I I	Model	Code'	•								
VIN				+			/IN													VIN		μ								
Engine No.		┢╌┦		_	+	 E	Engin	ne No).				+							Engine	e No.					-				
Mileage						l n	Vilea	ge												Mileag	е									
Invoice Date	D	D	M	ΜY	ΥY		nvoic	ce Da	ate			[)	D	/		Y	Y	ļ	Invoice	e Date				D	D	M	\mathbb{N}	Y	Y
Date of Inspection	D	D	\mathbb{N}	MY	ΥY		Date	of In	spect	tion		[)	D	/		Y	Y		Date o	f Inspe	ection			D	D	\mathbb{M}	\mathbb{N}	Y	Y
Registration No.		\square		$\overline{}$	\square	 F	Regis	stratio	on No)									 	Regist	ration	No.								
Customer Name							Custo	omer	Nam	ie									Ì	Custor	ner Na	ame								
Ph. No.						Р	Ph. No	b .												Ph. No.										
Service worksho	p/MAS	3 Cor	de (fil	l belo	w)		Se	rvic	e wo	orks	shop	MA	ss	Code	(fill	belo	ow)		ļ	Ser	vice	works	hop) / M	ASS	Co	de (f	ill be	elow)
			-								-			-	-				ļ				—				—			
OST OF MATERIAL DRNE BY CUSTOM		ONS	UMA	3LES	то ве	во Г\	Work	E B	In ch	ISTO	ALS / OMEF		со	NSU	MAE	BLES	т) ВЕ		COST C BORNE	BY C		OME		D C(ONS	UMA	ABLI	ES T	O BE
Signature						6	Signa	ature		Ĩ										Signa	ure									

amp of Selling dealer ode & Full Address)	Stamp of Selling dealer (Code & Full Address)	Stamp of Selling dealer (Code & Full Address)
Servicing Workshop	For Servicing Workshop	For Servicing Workshop
Please Fill up Model codes correctly. Please Fill up Complete VIN. Please fill up customer name and Phone No. letails legibly and correctly for the latest owner. ree service coupon of selling dealer not perational at present, should be sent to MSIL on nonthly basis.	1. Please Fill up Model codes correctly. 2. Please Fill up Complete VIN. 3. Please fill up customer name and Phone No. details legibly and correctly for the latest owner. 4. Free service coupon of selling dealer not operational at present, should be sent to MSIL on monthly basis.	 Please Fill up Model codes correctly. Please Fill up Complete VIN. Please fill up customer name and Phone No. details legibly and correctly for the latest owner. Free service coupon of selling dealer not operational at present, should be sent to MSIL on monthly basis.
FOR BAR CODE	FOR BAR CODE	FOR BAR CODE
 Service Division Maruti Suzuki India Limited	Service Division Maruti Suzuki India Limited	Service Division Maruti Suzuki India Limited

				м	lodel	Name									Mod	el Na	me								
Model Code*				М	lodel	Code*									Mod	el Co	de*								
VIN		++			IN									 	VIN										
Engine No.				E	ngine	No.								٦ï	Engi	ne No	D.								
Mileage				м	lileag	e		-	_					Ī	Milea	age			4	-					
Invoice Date	DD	D M N	ЛΥΥ	In	voice	Date			D	D	\mathbb{N}	\mathbb{N}	Y	Y	Invo	ce D	ate			D	D	\mathbb{N}	\mathbb{N}	Y	Y
Date of Inspection	DD	D M N	ΛΥΥ	D	ate o	f Inspe	ction		D	D	\mathbb{N}	\mathbb{N}	Y	Y	Date	of In	spect	on		D	D	\mathbb{N}	\mathbb{N}	Y	Y
Registration No.					egisti	ation N	No. –								Regi	strati	on No	. –							
Customer Name					uston	ner Na	me							-	Cust	omer	Nam	e							
				iΓ										٦ ¦											
Ph. No.				P	h. No.									- i	Ph. N	0.									
Service workshop	MASS C	ode (fill l	below)		Ser	vice v	vorks	hop /	MAS	S Co	ode (f	ill be	ow)		S	ervio	e wo	orksh	op / N	IASS	Co	de (f	ill be	low)
		_						-			-							-				-			
DEST OF MATERIALS A DRNE BY CUSTOMER Workshop In charge Signature	AND CON	SUMABI	LES TO BE		RNE	BY C	CTERIA CUSTO charge	MER	AND C	ONS	SUMA	ABLE	S TO	BE 	COST BORN Wor Sigr	ΕB	r CU				ONS	UMA	BLE	S T	O BE

mp of Selling dealer	Stamp of Selling dealer	Stamp of Selling dealer
de & Full Address)	(Code & Full Address)	(Code & Full Address)
Servicing Workshop lease Fill up Model codes correctly. lease fill up Complete VIN. lease fill up customer name and Phone No. etails legibly and correctly for the latest owner. ree service coupon of selling dealer not berational at present, should be sent to MSIL on onthly basis.	 For Servicing Workshop 1. Please Fill up Model codes correctly. 2. Please fill up Complete VIN. 3. Please fill up customer name and Phone No. details legibly and correctly for the latest owner. 4. Free service coupon of selling dealer not operational at present, should be sent to MSIL on monthly basis. 	 For Servicing Workshop 1. Please Fill up Model codes correctly. 2. Please fill up Complete VIN. 3. Please fill up customer name and Phone No. details legibly and correctly for the latest owner. 4. Free service coupon of selling dealer not operational at present, should be sent to MSIL on monthly basis.
FOR BAR CODE	FOR BAR CODE	FOR BAR CODE
Service Division	Service Division	Service Division
Maruti Suzuki India Limited	Maruti Suzuki India Limited	Maruti Suzuki India Limited

Model Name						м	odel N	ame									 	Moc	el Name	9								
Model Code*						M	odel C	ode*										Mod	el Code	*								
VIN			\square				IN											VIN										
Engine No.					+	 Ei	ngine I	No.									' 	Eng	ine No.	l								
Mileage	-					м	ileage			<u> </u>							İ	Mile	age									
Invoice Date	D	D	M	M	ΥY	IIn	voice l	Date			D	D	M	\mathbb{N}	Y	Y		Invo	ice Date	•			D	D	M	\mathbb{N}	Y	Y
Date of Inspection	D	D	M	M	ΥY	D	ate of	nspectior	ı		D	D	M	\mathbb{M}	Y	Y	!	Date	e of Insp	ection			D	D	M	M	Y	Y
Registration No.						i 🗕	-	tion No. er Name									 		istration									
						iΓ											i											
Ph. No.		1				Pr	n. No.											Ph. I	lo.									
Service worksh	op / MAS	S Co	de (fil	l belo	ow)		Serv	ice worl	ksho	p / M	IASS	Co	de (f	ill be	low)	Ι	S	ervice	work	shop	o / M	ASS	6 Co	de (f	ill be	elow)
	-		—						Ι				-								Ι				-			
OST OF MATERIA ORNE BY CUSTO		ONS	UMA	BLES	TO BE			MATER BY CUS			ID C	ONS	UM/	BLE	sт	O BE			OF MA				D C	ONS	UMA	ABLI	ES T	ΟВ
Workshop In charge Signature						W N	/orksh ignatu	op In chai re	rge									Wo Sia	kshop Ir ature	n charg	je							

Imp of Selling dealer ode & Full Address)	Stamp of Selling dealer (Code & Full Address)	Stamp of Selling dealer (Code & Full Address)
Servicing Workshop ease Fill up Model codes correctly.	For Servicing Workshop 1. Please Fill up Model codes correctly.	For Servicing Workshop 1. Please Fill up Model codes correctly.
ease fill up Complete VIN. pase fill up customer name and Phone No. tails legibly and correctly for the latest owner. se service coupon of selling dealer not erational at present, should be sent to MSIL on onthly basis.	 Please fill up Complete VIN. Please fill up customer name and Phone No. details legibly and correctly for the latest owner. Free service coupon of selling dealer not operational at present, should be sent to MSIL on monthly basis. 	 Please fill up Complete VIN. Please fill up customer name and Phone No. details legibly and correctly for the latest owner. Free service coupon of selling dealer not operational at present, should be sent to MSIL on monthly basis.
FOR BAR CODE	FOR BAR CODE	FOR BAR CODE
Service Division Maruti Suzuki India Limited	Service Division Maruti Suzuki India Limited	Service Division Maruti Suzuki India Limited

WARRANTY POLICY

Maruti Suzuki India Limited (hereinafter called "Maruti Suzuki"), warrants that each new Maruti Suzuki vehicle distributed in India by Maruti Suzuki and sold by a Maruti Suzuki authorised dealer will be free, under normal use and service, from any defects in material and workmanship at the time of manufacture SUBJECT TO THE FOLLOWING TERMS AND CONDITIONS:

(1) Qualification:

To qualify for this warranty the vehicle must be delivered by a Maruti Suzuki authorised dealer and set-up, and serviced by a Maruti Suzuki authorised workshop.

(2) Term:

The term of the warranty shall be twenty-four (24) months or 40,000 kilometers (whichever occurs first) from the date of invoice to the first owner.

NOTICE

Maruti Suzuki offers warranty of sixty (60) months or 1,00,000 kilometers (whichever occurs first) for Lithiumion battery & Integrated Starter Generator (ISG) in petrol model from the date of invoice to the first owner.

(3) Maruti Suzuki Warranty Obligation:

If any defect(s) should be found in a Maruti Suzuki vehicle within the term stipulated above, Maruti Suzuki's only obligation is to repair or replace at its sole discretion any part shown to be defective, with a new part or the equivalent at no cost to the owner for parts or labour, when Maruti Suzuki acknowledges that such a defect is attributable to faulty material or workmanship at the time of manufacture. Such defective parts, which have been replaced, will become the property of Maruti Suzuki. The owner is responsible for any repair or replacements which are not covered by this warranty. The decision of Maruti Suzuki shall be final & binding.

(4) Limitation:

This warranty shall not apply to:

- (a) Normal maintenance service required other than the three free services, including without limitation, oil and fluid changes, Consumables, headlight aiming, fastener retightening, wheel balancing, wheel alignment and tyre rotation, cleaning of injectors, adjustments of clutch and valve clearance.
- (b) The normal wear of parts including without limitation, bulbs, tyres* and tubes, spark plugs, belts, hoses, filters, wiper blades, brushes, contact points, fuses, clutch disc, brake shoes, brake pads, cable and all rubber parts (except oil seal and glass run).
- (c) Any vehicle which has been used for competition, rallies or racing.
- (d) Any repairs or replacement arising from accidents or collision.
- (e) Any defect/ damage caused by misuse, negligence, abnormal use, insufficient care, vandalism, theft, riot, fire, flooding not limited to entry of water in the components resulting in engine seizure, hydrostatic lock, etc. or external damages to the body/ components.
- (f) Any damage resulting due to usage of adulterated fuel/ lubricants/ oil/ coolant/ fluids/ polishing products and fuel/ lubricants/ oil/ coolant/ fluids used other than those specified in the Owner's Manual.
- (g) Any vehicle which has been modified or altered, including without limitation, the installation of performance accessories, enlargements of lights, other changes and external/ consequential reasons.
- (h) Any vehicle on which parts or accessories not approved by Maruti Suzuki (Non-MSGA, Non-MSGP) have been used.

(* - If there is a complaint related to tyre, the customer may contact respective tyre manufacturer.)

- Any vehicle which has not been operated in accordance with the operating instructions in this Owner's Manual and Service Booklet.
- (j) Any vehicle which has not received the service inspections prescribed in this Owner's Manual and Service Booklet.
- (k) Any vehicle which has been assembled, disassembled, adjusted or repaired by other than a Maruti Suzuki authorised workshop.
- (I) Any vehicle which has been used for purposes other than what it was designed for.
- (m) Any damage or deterioration caused by airborne fallout, industrial fallout, acid rain, hail or hail storm, wind storm, lightning, bird droppings, rodents bite / rat bite and such other thing that result in damage to the vehicle.
- (n) Insignificant defects / noise which do not affect the function of the vehicle including without limitation, sound, vibration and fluid seep.
- (o) Any natural wear and tear including without limitation, ageing, wear & tear or deterioration such as discoloration, fading, deformation or blurring and fabric discoloration.
- (p) Installation and usage of domestic LPG gas/LPG Cylinder.
- (q) V-belts, hoses and gas leaks.
- (r) Any vehicle retrofitted with LPG/CNG kits.
- (s) Repainting including patchwork, bodywork and mouldings and interior trims.
- (t) Corrosion, rusting of body parts and/ or components.
- (u) Any vehicle on which odometer has been changed unauthorisedly or odometer reading has been modified/ tampered with/ or not matching the service records.
- (v) The damage(s) caused to the vehicle being unattended despite knowledge that the defect exists and ignorance by the owner/ user of the vehicle.
- (w) Any damage(s) caused to vehicle including battery/ tyre due to parking of the vehicle in idle condition for long duration of time periods.

- (x) Any vehicle on which the retro-fitment is not authorized and/ or type approved as per the standards prescribed by the relevant authority including but not limited to Automotive Standards of India.
- (y) Any vehicle on which the retro-fitment is such which directly or indirectly causes any damage to the vehicle or affects the functions of the vehicle in any manner whatsoever.

(5) Extent of Warranty:

This warranty is the entire written warranty given by Maruti Suzuki for Maruti Suzuki vehicles and no dealer or its or his agent or employee is authorised to extend or enlarge this warranty and no dealer or its or his agent or employee is authorised to make any oral warranty or representation or assurance on behalf of Maruti Suzuki.

Maruti Suzuki reserves the right to add any improvements or change the design of any model at any time with no obligation to make the same changes on units previously sold.

(6) Warranty Service:

To obtain warranty service, the complete vehicle must be presented at the owner's expenses to Maruti Suzuki authorised workshop.

The customer shall be responsible for his belongings or accessories fitted in the vehicle at the time of presenting the vehicle for service and no claim shall be entertained in any manner under any circumstances.

(7) Owner's Warranty Obligations:

NOTICE

The owner shall not use the vehicle in a damaged condition and report the same immediately to the nearest Maruti Suzuki authorized workshop. This would result in early inspection and repair of the vehicle and any possible harm to the person or aggravation of damage to the vehicle can be prevented.

It is responsibility of each owner to:

- Have performed, at his own expenses, by a Maruti Suzuki authorised workshop all the service inspections specified in the Maruti Suzuki "Owner's Manual and Service Booklet" and maintain adequate proof that such service inspections have been performed.
- Update and maintain the 'Customer service maintenance records' page in the "Owner's Manual and Service Booklet", whenever service inspection or warranty service is carried out on the vehicle in a Maruti Suzuki authorised workshop.
- Present the Maruti Suzuki "Owner's Manual and Service Booklet" to the Maruti Suzuki authorised workshop whenever requesting service inspections or warranty service.

If the "Owner's Manual and Service Booklet" should be lost or destroyed the owner should consult the Maruti Suzuki authorised dealer from whom the vehicle was purchased for instructions concerning replacement of the "Owner's Manual and Service Booklet".

(8) Disclaimer of Consequential Damage:

Maruti Suzuki assumes no responsibility for loss of vehicle, loss of time, inconvenience or any other indirect incidental or consequential damage resulting from the vehicle not being available to the owner because of any defect covered by this warranty.

(9) Change of Owner

Even if ownership of the vehicle changes, the remaining warranty period is effective for the new owner.

This warranty is applicable only in India and not transferable to any other country.

EMISSION WARRANTY POLICY

Maruti Suzuki offers the Emission Warranty on all Maruti Suzuki vehicles (apart from the Regular Warranty and will run parallel to the regular product warranty) only in four metropolitan cities (New Delhi, Kolkata, Mumbai and Chennai) with effect from July 1st, 2001.

Terms:

The Emission Warranty will be applicable for **80,000 kms or 3 years** (Whichever comes earlier) from the date of invoice to the first owner. The remaining warranty terms will be valid in case of any change in ownership provided the production of all valid documents.

Conditions:

- 1. Under Emission Warranty, Warranty claims will be admitted for a prima-facie examination, in case vehicle fails to meet the Emission Standard as specified in sub rule (2) of rule no. 115 of Central Motor Vehicles Rules (CMVR), 1989.
- The warranty claims will only be accepted after examination carried out by Maruti Suzuki or Maruti Suzuki authorised workshop which leads to firm conclusions that the
 - a) Original settings have not been tampered in any case.
 - b) Part (as given in Annexure A) has a manufacturing defect.
 - c) Vehicle is unable to meet the Emission Standards (as given in 1.), inspite of the vehicle having been maintained and used in accordance with the instructions as specified in Owner's Manual and Service Booklet and the used fuel and different oils (Engine oil, Transmission oil, Brake oil etc.) are also as per specification.

- 3. The method of examination for deciding the warranty of the parts will be at the sole discretion of Maruti Suzuki and Maruti Suzuki authorised workshop and results of the examination will be final and binding. If after examination, the warrantable condition is not established, Maruti Suzuki and Maruti Suzuki authorised workshop has the right to charge all, or part of the cost of such examination.
- 4. Under Emission Warranty, the parts (as given in Annexure A) will be changed free of cost, but the consumables will be charged as per actual.
- 5. If the part covered under Emission Warranty or the associated parts, are not independently replaceable, on account of these being integral parts of a complete assembly, Maruti Suzuki and Maruti Suzuki authorised workshop will have the sole discretion to replace either the entire assembly or by using some of the parts of the system through suitable repairs or modifications.
- 6. Any consequential repairs or replacement of parts which may be found necessary to establish compliance of Emission Warranty, will not be considered under warranty, unless the same is under product warranty. The consumable will be charged as per actual under such repair or replacement.
- 7. Maruti Suzuki will not be responsible for the cost of transportation of the vehicle to the nearest Maruti Suzuki authorised workshop or any loss due to non-availability of the vehicle during the period of lodging of a warranty claim and examination and/or repair by Maruti Suzuki authorised workshop.
- 8. Maruti Suzuki will not be responsible for any penalty that may be charged by statutory authorities on account of failure to comply with the EMISSION STANDARDS.
- 9. Emission Warranty will not be affected by the change of owner, provided all the documents are available.

- 10. All maintenance actions (as specified in the Owner's Manual and Service Booklet) need to be followed and recorded in the manual for emission warranty.
- 11. The customer needs to produce the PUC (Pollution Under Control) certificate valid for the period preceding the test during which the failure is discovered. The receipts (for the maintenance of the vehicle as per specification in Owner's Manual and Service Booklet from the date of original purchase of the vehicle) will also be required.

Conditions under which the Emission Warranty is not APPLICABLE

- 1. In the absence of valid PUC certificate.
- 2. Vehicle not serviced from Maruti Suzuki authorised workshop as per the schedule specified in the Owner's Manual.
- 3. Vehicle subjected to abnormal use (accident, motor race, rallies or for the purpose of establishing the records etc).
- 4. Use of non MSGP (Maruti Suzuki Genuine Part).
- 5. Vehicle that has been tampered with.
- 6. Tampering with odometer so that the actual kilometer reading cannot be determined.
- 7. Use of adulterated fuel and/or unspecified oils (Engine oil, Transmission oil and Brake oil etc).

Annexure - A

- List of parts (if applicable) covered under Emission Warranty
- 1. Fuel Injection Assembly, Pressure Regulator, Throttle Body Assembly.
- 2. Electronic Control Module (ECM).
- 3. Intake Manifold.
- 4. EGR valve.
- 5. Ignition Coil.
- 6. Canister Assembly.
- 7. Vapour Liquid Seperator.
- 8. Fuel Tank and Filler Cap.
- 9. PCV (Positive Crankcase Ventilation) Valve.
- 10. Oil Filler Cap.
- 11. Catalytic Convertor.
- 12. Exhaust Manifold.
- 13. All Fuel Injection System related Sensors.
- 14. High Pressure Fuel Pump.
- 15. Glow Plug.
- 16. Glow Plug Controller.

TABLE OF CONTENTS

FOR SAFE DRIVING	1
BEFORE DRIVING	2
OPERATING YOUR VEHICLE	3
DRIVING TIPS	4
OTHER CONTROLS AND EQUIPMENT	5
INSPECTION AND MAINTENANCE	6
EMERGENCY SERVICE	7
APPEARANCE CARE	8
SPECIFICATIONS	9
SERVICE NETWORK	10


1

FOR SAFE DRIVING

Floor Mats	. 1-1
Front Seats	. 1-1
Rear Seats	1-3
Seat Belts and Child Restraint Systems	. 1-9
Child Restraint System for India	1-19
Supplemental Restraint System (airbags)	1-25
Exhaust Gas Warning	1-32

65D231S

Floor Mats



To prevent the driver's side floor mat from sliding forward and possibly interfering with the operation of the pedals, MARUTI SUZUKI genuine floor mats are recommended.

Whenever you put the driver's side floor mat back in the vehicle after it has been removed, be sure to hook the floor mat grommets to the fasteners and position the floor mat properly in the footwell.

When you replace the floor mats in your vehicle with a different type such as allweather floor mats, we highly recommend using MARUTI SUZUKI genuine floor mats for proper fitting.

A WARNING

Failure to take the following precautions may result in the driver's side floor mat interfering with the pedals and causing a loss of vehicle control or an accident.

- Make sure that the floor mat grommets are hooked to the fasteners.
- Never stack additional floor mats on top of the existing floor mat.
- Never use a floor mat which does not fit the floor as the same may cause hindrance/damage in vehicle and its functioning
- Never use damaged floor mats.

Front Seats

Seat Adjustment

A WARNING

Never attempt to adjust the driver's seat or seatback while driving. The seat or seatback could move unexpectedly, causing loss of control. Make sure that the driver's seat and seatback are properly adjusted before you start driving.

WARNING

To avoid excessive seat belt slack, which reduces the effectiveness of the seat belts as a safety device, make sure that the seats are adjusted before the seat belts are fastened.

A WARNING


Do not place any object under the front seat. If an object gets stuck under the front seat, the following may occur.

The seat shall not be latched.

 Also, the lithium-ion battery, located under the front left side seat, in a model equipped with ENG A-STOP system, will be damaged.


Do not leave cigarette lighters or spray cans on the floor. If a cigarette lighter or spray can is on the floor, it may light accidentally when luggage is loaded or the seat is adjusted, causing a fire.

Adjusting Seat Position



The adjustment lever for each front seat is located under the front of the seat. To adjust the seat position, pull up on the adjustment lever and slide the seat forward or rearward.

After adjustment, try to move the seat forward and rearward to ensure that it is securely latched. Adjusting Seat height (if equipped)




If the driver's seat is equipped with a seat height adjuster lever on the outboard side of the seat, raise or lower the seat by pulling up or down the adjuster lever.

Adjusting Seatbacks

All seatbacks should always be in an upright position when driving, or seat belt effectiveness may be reduced. Seat belts are designed to offer maximum protection when seatbacks are in the upright position.

NOTE:


To operate the seat back smoothly, pull the seat back adjustment lever in upward direction. Ensure to move seat back only after lever is moved to fully up position. After adjustment of seat back, release the lever gently. Check that seat back is locked by moving it forward and backward.



72R0133

To adjust the seatback angle of front seats, pull up the lever on the outboard side of the seat, move the seatback to the desired position, and release the lever to lock the seatback in place.

Head Restraints



Head restraints are designed to help reduce the risk of neck injuries in the case of an accident. Adjust the head restraint to the position which places the center of the head restraint closest to the top of your ears. If this is not possible for very tall passengers, adjust the head restraint as high as possible.


WARNING

· Never drive the vehicle with the head restraints removed.

Do not attempt to adjust the head restraint while driving.

NOTE:

It may be necessary to recline the seatback to provide enough overhead clearance to remove the head restraint.



To raise the front head restraint, pull upward on the restraint until it clicks. To lower the restraint, push down on the restraint while holding in the lock lever. If a head restraint must be removed (for cleaning, replacement, etc.), push in the lock lever and pull the head restraint all the way out.

Rear Seats


Seat Adjustment

To avoid excessive seat belt slack, which reduces the effectiveness of the seat belts as a safety device, make sure that the seats are adjusted before the seat belts are fastened.

Do not place any object under the seat. If an object gets stuck under the front seat, the following may occur. The seat shall not be latched.

Adjusting Seat Position

For 2nd row seats



72R0024

1-3

The adjustment levers for 2nd row seats are located under the front of the seats. To adjust the seat position, pull up on the adjustment lever and slide the seat forward or rearward.

After adjustment, try to move the seat forward and rearward to ensure that it is securely latched.

NOTICE

When the 3rd row seat is folded forward, adjust the 2nd row seat not to reach the 3rd row seat.

Adjusting Seatbacks

All seatbacks should always be in an upright position when driving, or seat belt effectiveness may be reduced. Seat belts are designed to offer maximum protection when seatbacks are in the upright position.

NOTE:

To operate the seat back smoothly, pull the seat back adjustment lever in upward direction. Ensure to move seat back only after lever is moved to fully up position. After adjustment of seat back, release the lever gently. Check that seat back is locked by moving it forward and backward.

For 2nd row seats






To adjust the seatback angle of 2nd row seats, pull up the lever on the outboard side of the seat, move the seatback to the desired position, and release the lever to lock the seatback in place.

For 3rd row seats

EXAMPLE



To adjust the seatback angle of 3rd row seats, put one hand on the backrest and fully lift up the release lever in the upper side of the backrest.

With the release lever in raised condition, pull down the backrest till the position little bit more than desired angle.

Then, remove hand from release lever and push the backrest towards back to fix it in position.

Do not pull down the backrest more than required, the seat belt cannot show full effect.

NOTICE


Adjust the 3rd row seat after getting down from the seat. If the release lever is pulled while being seated, the backrest will suddenly collapse to max angle.

Pull the release lever fully. If the seat is made to collapse without the lock being released, movement of lock will become heavy.

1-4


Walk-in Type Seats

For 2nd row seats



NOTE:

To enter to or exit from the 3rd row seat, insert the tongue plate of the buckle into the part (1) before moving the 2nd row seat.



The walk-in type seat can be moved to provide easy entry to and exit from the 3rd row seats. You can move a walk-in seat by lifting up the release lever and pushing the seatback forward.

WARNING

- After using the walk-in function, be sure to return the folded seat back to an upright position.
- Before returning a walk-in seat to its normal seating position, make sure that the feet of the passenger in the 3rd row seat are out of the way.
- After returning the seat to its normal seating position, make sure it is securely latched.

NOTICE

Release lever is meant for easy entry purpose only. Not to be used for adjusting seatback.

Head Restraints

Head restraints are designed to help reduce the risk of neck injuries in the case of an accident.

A WARNING

- Never drive the vehicle with the head restraints removed.
- Do not attempt to adjust the head restraint while driving.

NOTE:


It may be necessary to fold forward the seatback to provide enough overhead clearance to remove the head restraint.

Adjust the head restraint to the position which places the center of the head restraint closest to the top of your ears. If this is not possible for very tall passengers, adjust the head restraint as high as possible.

1-5

2nd row seats

3rd row seats



To raise the rear head restraint, pull upward on the restraint until it clicks. To lower the restraint, push down on the restraint while holding in the lock lever. If a head restraint must be removed (for cleaning, replacement, etc.), push in the lock lever and pull the head restraint all the way out.


When installing a child restraint system, raise the head restraint to the most upper position.

Folding Rear Seats

The rear seat of your vehicle can be folded forward to provide additional cargo space.

2nd row seats


To fold the 2nd row seat forward:



1) Insert the tongue plate of the buckle into the part (1).

NOTICE

- When you move a seatback, make sure the tongue plate of the buckle is inserted in the seat belt catch hole so the seat belts are not caught by the seatback, seat hinge, or seat latch. This helps prevent damage to the belt system.
- Make sure the belt webbing is not twisted.
- 2) Lower the head restraint fully.
- 3) Store the seat belt buckles in the seat cushion slit.



4) Pull up the lever on the outboard side of the seat, and fold the seatback forward.

1-6

72RH0-74E

EXAMPLE Image: Second
NOTICE

When the 2nd row seat head restraint reaches the front seatback, slide the front seat forward.


WARNING

If you need to carry cargo in the passenger compartment with the 2nd row seatback folded forward, be sure to secure the cargo or it may be thrown about, causing injury. Never pile cargo higher than the seatback.

To return the seat to the normal position, follow the procedure below.

NOTICE

When you move a seatback, make sure the tongue plate of the buckle is inserted in the seat belt catch hole so the seat belts are not caught by the seatback, seat hinge, or seat latch. This helps prevent damage to the belt system.




Raise the seatback until it locks into place. NOTE:

When the seatback is locked in the folded position, pull up the lever on the outboard side of the seat to unlatch the seatback.

After returning the seat, try moving the seatback to make sure they are securely latched.


3rd row seats To fold the 3rd row seat forward:

1) Lower the head restraint fully.



2) Stow the seat belt buckles of the right and left seating position into the pocket of the seat cushion as shown in the illustration.

1-7



73R0007

3) Lift up the release lever on the top of seat, and fold the seatback forward.

NOTICE

When the 3rd row seat head restraint reaches the 2nd row seatback, slide the 2nd row seat forward.


NOTICE

When you are not using a seat belt, stow the seat belt buckles of the right and left seating position into the pocket first. This helps prevent being caught by the seat and being damaged.

A WARNING

If you need to carry cargo in the passenger compartment with the 3rd row seatback folded forward, be sure to secure the cargo or it may be thrown about, causing injury. Never pile cargo higher than the seatback.

To return the seat to the normal position, follow the procedure below.



Raise the seatback until it locks into place.


When you raise the seat from back of it, pull the strap (1).

NOTICE

Do not allow items in the luggage box to extend above the top of the luggage box. Otherwise, the luggage box or cover may be damaged.

After returning the seat, try moving the seatback to make sure they are securely latched.

Seat Belts and Child Restraint Systems



A WARNING

 Wear Your Seat Belts at All Times.
 An airbag supplements, or adds to, the frontal collision protection offered by seat belts. The driver and all passengers must be properly restrained by wearing seat belts at all times, even if driving for a very short distance, whether or not an airbag is mounted at their seating position, to minimize the risk of severe injury or death in the event of a collision. (Continued) • Do not modify, remove, disassemble seat belts. Doing so may prevent them from functioning properly and cause the risk of severe injury or death in the event of a collision. (Continued)


EXAMPLE Above the pelvis (Continued)

- Never allow persons to ride in the cargo area of a vehicle. In the event of an accident, there is a much greater risk of injury for persons who are not riding in a seat with their seat belt securely fastened.
- Ensure that all seat belts are worn correctly. An improperly worn seat belt increases the risk of injury or death if a collision occurs.

WARNING

- Seat belts should always be adjusted as follows:
- the lap portion of the belt should be worn low across the pelvis, not across the waist.
- the shoulder straps should be worn on the outside shoulder only, and never under the arm.
- the shoulder straps should be away from your face and neck, but not falling off your shoulder. (Continued)

1-9



(Continued)

- Never use the same seat belt on more than one occupant and never attach a seat belt over an infant or child being held on an occupant's lap. Such seat belt use could cause serious injury in the event of an accident.
- Periodically inspect seat belt assemblies for excessive wear and damage. Seat belts should be replaced if webbing becomes fraved, contaminated, or damaged in any way. It is essential to replace the entire seat belt assembly after it has been worn in a severe impact, even if damage to the assembly is not obvious.
- Children age 12 and under should ride properly restrained in the rear seat.
- Infants and small children should never be transported unless they are properly restrained. Restraint systems for infants and small children can be purchased locally and should be used. Make sure that the system you purchase meets applicable safety standards. Read and follow all the directions provided by the manufacturer.

(Continued)

1-10

(Continued)


- For children, if the shoulder belt irritates the neck or face, move the child closer to the center of the vehicle.
- Avoid contamination of seat belt webbing by polishes, oils, chemicals, and particularly battery acid.
 Cleaning may safely be carried out using mild soap and water.
- Do not insert any items such as coins, clips, etc. into the seat belt buckles, and be careful not to spill liquids into these parts. If foreign materials get into a seat belt buckle, the seat belt may not work properly.
- All seatbacks should always be in an upright position when driving, or seat belt effectiveness may be reduced. Seat belts are designed to offer maximum protection when seatbacks are in the upright position.


Lap-Shoulder Belt

Emergency Locking Retractor (ELR)

The seat belt has an emergency locking retractor (ELR), which is designed to lock the seat belt only during a sudden stop or impact. It also may lock if you pull the belt across your body very quickly. If this happens, let the belt go back to unlock it, and then pull the belt across your body more slowly.

Safety reminder







To reduce the risk of sliding under the belt during a collision, position the lap portion of the belt across your lap as low on your hips as possible and adjust it to a snug fit by pulling the shoulder portion of the belt upward through the latch plate. The length of the diagonal shoulder strap adjusts itself to allow freedom of movement.

1-11

All Seat Belts Except Center of 2nd Row Seat



To fasten the seat belt, sit up straight and well back in the seat, pull the latch plate attached to the seat belt across your body and press it straight into the buckle until you hear a "click".




To unfasten the seat belt, push the button on the buckle and retract the belt slowly while attaching a hand to the belt or/and the latch plate.

NOTE:


If the seat belt cannot be pulled from its fully retracted position, firmly pull the belt and release it. Then smoothly pull the belt out of the retractor

Center Seat Belt of 2nd Row Seat

Lap belt




Sit up straight and well back in the seat. To fasten the belt, pull the latch plate attached to the seat belt across your hips and press it straight into the buckle until you hear a "click". To reduce the risk of sliding under the belt during a collision, position the belt across your lap as low on your hips as possible and adjust it to a snug fit. To tighten the belt, pull the free end of the belt across alongside the lap strap.



To lengthen, release the latch plate from the buckle, pull the latch plate (adjuster) in the direction of the arrow. The latch plate should then be refitted into the buckle and the belt tightened as previously described. To unfasten the belt, press the release button and the buckle latch.


1-12



NOTE:

The word "CENTER" is marked on the buckle and tongue for the rear center belt. The buckles are designed so a latch plate cannot be inserted into the wrong buckle.

Driver's seat belt reminder light / Front passenger's seat belt reminder light



When the driver and/or front passenger do(does) not fasten their seat belts, the seat belt reminder lights will come on or blink and a buzzer will sound to remind the driver and/or passenger to fasten their seat belts. For more details, refer to the explanation below.

NOTE:

The driver's seat belt reminder light / front passenger's seat belt reminder light is for both the driver and front passenger.

Driver's seat belt reminder

If the driver's seat belt remains unbuckled when the ignition switch is in "ON" position or the ignition mode is "ON", the reminder works as follows:

- 1) The driver's seat belt reminder light will come on.
- After the vehicle's speed has reached about 15 km/h, the driver's seat belt reminder light will blink and a buzzer will sound for about 95 seconds.
- The reminder light will remain on until the driver's seat belt is buckled.


If the driver has buckled his or her seat belt and later unbuckles the seat belt, the reminder system will be activated from Step 1) or 2) according to the vehicle's speed. When the vehicle's speed is less than 15 km/h, the reminder will start from Step 1). When the vehicle's speed is more than 15 km/h, the reminder will start from Step 2).

The reminder will be automatically canceled when the driver's seat belt is buckled or the ignition switch is turned off.

1-13

Front passenger's seat belt reminder

If there is a person sitting in the front passenger seat and the front passenger seat belt is unbuckled when the ignition switch is in "ON" position or the ignition mode is "ON", the front passenger's seat belt reminder will activate.



69RH203

(2) The sensor of the front passenger's seat belt reminder

The seat belt reminder sensor (2) detects whether a person is sitting in the front seat. The sensor of the front passenger's seat belt reminder is located in the seat cushion. The front passenger's seat belt reminder works in the same manner as the driver's seat belt reminder.

WARNING

It is absolutely essential that the driver and passengers fasten their seat belts at all times. Persons who are not fastening seat belts have a much greater risk of injury if an accident occurs. Make a regular habit of buckling your seat belt before putting the key in the ignition or pressing the engine switch.

A CAUTION

- Do not spill liquid or semi-solid on the front passenger's seat. If you spill it on the front passenger's seat, immediately wipe it dry with a soft cloth. Contact of liquid with sensor may impact the function of seat belt reminder sensor.
- Do not place any sharp or heavy object on passenger seat which can penetrate through seat upholstery and can cause damage to sensor.

NOTICE


- The sensor of the front passenger's seat belt reminder is located in the seat cushion. If heavy or sharp objects are put on the seat cushion, or a removal, disassembly and modification of the passenger's seat are performed, the sensor may not work properly or can be damaged. Do not put heavy or sharp objects on the seat cushion. Do not remove, disassemble and modify the passenger's seat.
- Depending on the variety of seat cover, operation of the sensor may be adversely affected. MARUTI SUZUKI highly recommends that you use MARUTI SUZUKI genuine seat cover exclusively for this vehicle.
- If you spill liquid such as liquid aromatics, soft drinks or juice on the front passenger's seat cushion, the sensor of the front passenger's seat belt reminder located in the seat cushion can be damaged. Immediately wipe it dry with a soft cloth when spilled.

(Continued)


NOTICE

(Continued)

 When sitting on the front passenger's seat, it is very important that the passenger sits upright, leaning against the seat backrest and centered on the seat cushion in order for the seatbelt reminder system to function effectively. An occupant sitting improperly (slouches, turns sideways, sits forward or sideways) may hamper the functioning of this system as it may not detect the occupant. Shoulder anchor height adjuster (if equipped)



Seat Belt Catch Hole (for 2nd row seats)



NOTE:

- If you put an object on the passenger's seat, the weight of the object will be sensed by the sensor and the front passenger's seat belt reminder light will come on and then the interior buzzer may beep.
- If a child or a small sized person sits on the front passenger's seat or the cushion is put on the front passenger's seat, the weight may not be sensed by the sensor and the interior buzzer may not beep.
- Maruti Suzuki recommends use of Maruti Suzuki Genuine accessory of "Seat cover".

Adjust the shoulder anchor height so that the shoulder belt rides on the center of the outboard shoulder. To move upward, slide the anchor up. To move downward, slide the anchor down while pulling the lock knob out. After adjustment, check that the anchor is securely locked.

WARNING

Check that the shoulder belt is positioned on the center of the outside shoulder. The belt should be away from your face and neck, but not falling off your shoulder. Misadjustment of the belt could reduce the effectiveness of the seat belt in a collision.


NOTE:

To enter to or exit from the 3rd row seat, insert the tongue plate of the buckle into the part (1) before moving the 2nd row seat.

NOTICE


When you move a seatback, make sure the tongue plate of the buckle is inserted in the seat belt catch hole so the seat belts are not caught by the seatback, seat hinge, or seat latch. This helps prevent damage to the belt system.

1-15



1-16

Booster seat




79J223

MARUTI SUZUKI highly recommends that you use a child restraint system to restrain infants and small children. Many different types of child restraint systems are available; check that the restraint system you select meets applicable safety standards.

All child restraint systems are designed to be secured in vehicle seats either by seat belts (the lap portion of lap-shoulder belts) or by special rigid lower anchor bars built into the seat.


NOTE:

Observe any statutory regulation about child restraints.




Do not install a child restraint system on the front passenger's seat since a child restraint system cannot be installed appropriately.

If you install a child restraint system in the 2nd row seat, slide the seat installed the child restraint system as far back as possible. So that, the child's feet do not contact the front seatback. These will help avoid injury to the child in the event of an accident.



65D608D



A WARNING

Children could be endangered in a collision if their child restraint systems are not properly secured in the vehicle. When installing a child restraint system, follow the instructions below. secure the child in the restraint system according to the manufacturer's instructions.

Do not hold a child on a passenger's lap when the vehicle is in motion. Even if the passenger holds the child tightly, he/she would not be supported enough in the event of an accident and it could result in a serious injury of the child.

1-18

Child Restraint System for India Child Restraint

The suitability of each passenger's seat position for carriage of children and fitting of child restraint system is shown in the table below. Whenever you carry children up to 12 years of age, properly use the child restraints which conform to AIS 072, the standard for child restraints, referring to the table.

	Seating position (or other site)				
MASS GROUP	Front Passenger	Rear Outboard	Rear Centre	Intermediate Outboard	Intermediate Centre
Group 0 Up to 10 kg	х	х	N.A	U	Х
Group 0+ Up to 13 kg	х	х	N.A	U	Х
Group I 9 to 18 kg	х	х	N.A	U	Х
Group II 15 to 25 kg	х	х	N.A	U	Х
Group III 22 to 36 kg	х	х	N.A	U	Х


Key of letters to be inserted in the above table: U =Suitable for 'universal' category restraints approved for use in this mass group X =Seat position not suitable for children in this mass group N.A = Seat position not available for children in this mass group. NOTE: 'universal' is the category in the AIS 072. : 'Outboard' indicates window side seat.

Installation with lap-shoulder seat belts

If your vehicle is equipped with the rear head restraint, adjust the height of the head restraint or remove it for fitting the child restraint, as necessary. However, if a booster cushion not equipped with the seatback is fitted, the seat head restraint should not be removed. If the head restraint is removed for fitting the child restraint, you need to install it again after removing the child restraint. If the child restraint is fitted improperly, a child sitting in it could be injured in a collision.

NOTE:

Stow the removed head restraint in the luggage compartment so it will not cause inconvenience to the occupants.




ELR type belt

Install your child restraint system according to the instructions provided by the child restraint system manufacturer.

Check that the seat belt is securely latched.

Move the child restraint system in all directions to check that it is securely installed. When you put your child in the child restraint system, appropriately slide the front seat forward not to touch a part of your child's body. Installation with ISOFIX type anchorages



72R0029


Your vehicle is equipped with the lower anchorages in the 2nd row seat outboard seating positions for securing a ISOFIX type of child restraints with the connecting bars. The lower anchorages are located where the rear of the seat cushion meets the bottom of the seatback.

WARNING

Install the ISOFIX type of child restraint(s) in the only outboard seating positions, not in the central position for the 2nd row seat.

Install the ISOFIX type child restraint system according to the instructions provided by the child restraint system manufacturer. After installation, try moving the child

restraint system in all directions especially forward to check that connecting bars are securely latched to the anchorages.



Your vehicle is equipped with the top tether anchorages. Use the top tether strap of the child restraint according to the instructions provided by the child restraint system manufacturer.


Here is a general instruction:

If your vehicle is equipped with the rear head restraint, adjust the height of the rear head restraint or remove it for fitting the child restraint, as necessary. However, if a booster cushion not equipped with the seatback is fitted, the 2nd row seat head restraint should not be removed. If the rear head restraint is removed for fitting the child restraint, you need to install it again after removing the child restraint. If the child restraint is fitted improp-


If the child restraint is fitted improperly, a child sitting in it could be injured in a collision.

NOTE:

Stow the removed head restraint in the luggage compartment so it will not cause inconvenience to the occupants.




 Place the child restraint in the 2nd row seat, inserting the connecting bars to the anchorages between the seat cushion and the seatback.




1-21

 Use your hands to carefully align the connecting bar tips with the anchorages. Take care not to pinch your fingers.



 Push the child restraint toward the anchorages so that the connecting bar tips are partially hooked to the anchorages. Use your hands to confirm the position.



- 4) Grasp the front of the child restraint and push the child restraint forcefully to latch the connecting bars. Check that they are securely latched by trying to move the child restraint system in all directions, especially forward.
- Attach the top tether strap referring to "Installation of child restraint with top tether" section.

When you put your child in the child restraint system, appropriately slide the front seat forward not to touch a part of your child's body.

NOTICE

When installing a child restraint system to the 2nd row seat, slide the seat installed the child restraint system as far back as possible. Installation of child restraint with top tether


If your vehicle is equipped with the rear head restraint, adjust the height of the rear head restraint or remove it for fitting the child restraint, as necessary. However, if a booster cushion not equipped with the seatback is fitted, the 2nd row seat head restraint should not be removed. If the rear head restraint is removed for fitting the child restraint, you need to install it again after removing the child restraint.

If the child restraint is fitted improperly, a child sitting in it could be injured in a collision.

NOTE:

Stow the removed head restraint in the luggage compartment so it will not cause inconvenience to the occupants.


1-22



3R0175

Some child restraint systems require the use of a top tether strap. Top tether anchorage brackets are provided in your vehicle at the locations shown in the illustrations. The number of the top tether anchorage brackets provided in your vehicle depends on the vehicle specification. Install the child restraint system as follows:

- Secure the child restraint on the 2nd row seat using the procedure described above for securing a restraint system that does not require a top tether strap.
- 2) Hook the top tether strap to the top tether anchorage bracket and tighten the top tether strap according to the instructions provided by the child restraint system manufacturer. Attach the top tether strap to the corresponding top tether anchorage bracket located directly behind the child restraint.



- 3) When routing the top tether strap, pass the top tether strap as shown in the illustration. (Refer to "Head restraints" section for details on how to adjust the height of head restraint or remove it.)
- Check that cargo does not interfere with routing of the top tether strap.


NOTICE

When installing a child restraint system to the 2nd row seat, adjust the front seat position so that the front seat does not interfere with the child restraint system.

NOTE:

Maruti Suzuki recommends use of Maruti Suzuki Genuine accessory of "Child seat, ISOFIX".

Seat belt pretensioner system



63J269

A WARNING

This section describes your MARUTI SUZUKI vehicle's seat belt pretensioner system. Read and follow all these instructions carefully to minimize your risk of severe injury or death.

To determine if your vehicle is equipped with a seat belt pretensioner system at the front seating positions, check the label on the seat belt at the bottom part. If the letters "p" and/or "PRE" appear as illustrated,

your vehicle is equipped with the seat belt pretensioner system. You can use the pretensioner seat belts in the same manner as ordinary seat belts.

Read this section and "Supplemental restraint system (airbags)" section to learn more about the pretensioner system.

The seat belt pretensioner system works with the supplemental restraint system (air bags). The collision sensors and the electronic controller of the airbag system also control the seat belt pretensioners. The pretensioners are triggered only when there is a frontal collision severe enough to trigger the airbags and the seat belts are fastened. For precautions and general information including servicing the pretensioner system, refer to "Supplemental restraint system (airbags)" section in addition to this "Seat belt pretensioner system" section, and follow all those precautions.

The pretensioner is located in each front seat belt retractor. The pretensioner tightens the seat belt so the belt fits the occupant's body more snugly in the event of a frontal collision. The retractors will remain locked after the pretensioners are activated. Upon activation, some noise will occur and some smoke may be released.These conditions are not harmful and do not indicate a fire in the vehicle.

The driver and all passengers must be properly restrained by fastening seat belts at all times, whether or not a pretensioner is equipped at their seating position, to minimize the risk of severe injury or death in the event of a collision.

Sit fully back in the seat; sit up straight; do not lean forward or sideways. Adjust the belt so the lap portion of the belt is worn low across the pelvis, not across the waist. Please refer to "Seat adjustment" section and the instructions and precautions about the seat belts in this "Seat belts and child restraint systems" section for details on proper seat and seat belt adjustments.

Please note that the pretensioners along with the airbags will activate in severe frontal collisions. They are not designed to activate in rear impacts, roll-overs, or minor frontal collisions. The pretensioners can be activated only once. If the pretensioners are activated (that is, if the airbags are activated), have the pretensioner system serviced by a Maruti Suzuki authorised workshop as soon as possible.

The pretensioner system or the airbag system may not work properly if any of the following conditions occurs.

- If the air bag light on the instrument cluster does not come on briefly, when the ignition switch is turned to the "ON" position or the engine switch is pressed to change the ignition mode to "ON".
- If the air bag light comes on and stays on for more than 10 seconds, when the ignition switch is turned to the "ON" position

or the engine switch is pressed to change the ignition mode to "ON".

 If the air bag light comes on while driving.

Have both systems inspected by a Maruti Suzuki authorised workshop as soon as possible.

Service on or around the pretensioner system components or wiring must be performed only by a Maruti Suzuki authorised workshop who is specially trained. Improper service could result in unintended activation of pretensioners or could render the pretensioner inoperative. Either of these two conditions may result in personal injury.

To prevent damage or unintended activation of the pretensioners, check that the lead-acid battery is disconnected and the ignition switch has been in LOCK position or the ignition mode has been LOCK (OFF) for at least 90 seconds before performing any electrical service work on your MARUTI SUZUKI vehicle.

Do not touch pretensioner system components or wiring. The wires are wrapped with yellow tape or yellow tubing, and the couplers are yellow. When scrapping your MARUTI SUZUKI vehicle, ask a Maruti Suzuki authorised workshop, body repair shop, or scrap yard for assistance.


Supplemental Restraint System (airbags)

WARNING

This section of the owner's manual describes the protection provided by your Maruti Suzuki's supplemental restraint system (airbags). Please read and follow all these instructions carefully to minimize your risk of severe injury or death in the event of a collision.

Your vehicle is equipped with a Supplemental Restraint System consisting of the following components in addition to a lapshoulder belt at each front seating position.

- 1. Driver's front airbag module
- 2. Front passenger's front airbag module
- 3. Seat belt pretensioners
- 4. Airbag controller
- 5. Forward collision sensor



1-25

A WARNING


An airbag supplements or adds to the collision protection offered by seat belts. The driver and all passengers must be properly restrained by fastening seat belts at all times, whether or not an airbag is mounted at their seating position, to minimize the risk of severe injury or death in the event of a collision.

AIRBAG light



If the "AIRBAG" light on the instrument cluster does not blink or come on when the ignition switch is first turned to the ON position, or the ignition mode is first changed to "ON", or the "AIRBAG" light stays on, or comes on while driving, the airbag system (or the seat belt pretensioner system) may not work properly. Have the airbag system inspected by a Maruti Suzuki authorised workshop as soon as possible.


Front Airbags



Front airbag is designed to inflate in severe frontal collisions when the ignition switch is in "ON" position or the ignition mode is "ON".

Front airbag is not designed to inflate in rear impacts, side impacts, rollovers or minor frontal collisions, since they would offer no protection in those types of accidents.Remember, since an airbag deploys only one time during an accident, seat belts are needed to restrain occupants from further movements during the accident.

Therefore, an airbag is not a substitute for seat belts. To maximize your protection, always fasten your seat belts. Be aware that no system can prevent all possible injuries that may occur in an accident.




Front passenger's front airbag

EXAMPLE



1-26

The driver's front airbag is located behind the center pad of the steering wheel and the front passenger's front airbag is located behind the passenger's side of the dashboard. The words "SRS AIRBAG" are molded into the airbag covers to identify the location of the airbags.



A WARNING

Do not install a child restraint system on the front passenger's seat since a child restraint system cannot be installed appropriately.

A WARNING

If the airbag stored place is damaged or cracked, the airbag system may not work properly, which could result in serious injury in the event of a collision. Have your vehicle inspected by a Maruti Suzuki authorised workshop.


Refer to "Seat belts and child restraint systems" section for details on securing your child.

Conditions of front airbags deployment (inflation)





 Frontal collision with a fixed wall that does not move or deform at more than about 25 km/h




80J098E

 Strong impact equivalent to frontal collision such as above at left and right angles of about 30 degrees (1) or less from the front of your vehicle

Conditions of front airbags may inflate Receiving a strong impact to the lower body of your vehicle, the front airbags may inflate.




80J097




· Hitting a curb or medial strip

1-27




· Falling into a deep hole or ditch



Landing hard or falling


Front airbags may not inflate The front airbags may not inflate when a strong impact has not occurred since the collision object (including living being like animals) was easy to be deformed or moved, or the collided portion of your vehicle was easy to be deformed. Also, front airbags may not inflate in many cases when the collision angle is greater

than about 30 degrees at left and right angles from the front of your vehicle. Also, in certain collisions at low speed, the air bags may not inflate.




Frontal collision to a stopped vehicle at less than about 50 km/h


EXAMPLE



· Collision that the front of your vehicle goes under the bed of a truck etc.




- 80J104
- Collision with a utility pole or stumpage



· Collision with a fixed wall or guardrail at left and right angles of greater than about 30 degrees (1) from the front of your vehicle

1-28



 Frontal collision with a fixed wall that does not move or deform at less than about 25 km/h

Front airbags do not inflate in rear impacts,

side impacts or rollovers, etc. However, these might inflate in a strong impact.

· Impact from the side

EXAMPLE



80J110

· Vehicle rollover

80J120

Airbag symbol meaning



You may find this label on the sun visor.

WARNING

NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.

A WARNING

If the AIRBAG light in the instrument cluster ever comes on and stays on, it means that something may be wrong with the airbag system. If this ever happens, have the vehicle serviced immediately, because the airbags may not offer the protection for which they were designed.



Front airbags do not inflate

EXAMPLE

· Impact from the rear



How the System Works

In a frontal collision, the collision sensors will detect rapid deceleration, and if the controller judges that the deceleration represents a severe frontal collision, the controller will trigger the inflators. The inflators inflate the appropriate airbags with nitrogen or argon gas. The inflated airbags provide a cushion for your head and upper body. The airbag inflates and deflates so quickly that you may not even realize that it has activated. The airbag will neither hinder your view nor make it harder to exit the vehicle.

Airbags must inflate quickly and forcefully in order to reduce the chance of serious or fatal injuries. However, an unavoidable consequence of the quick inflation is that the airbag may irritate bare skin, such as the facial area against a front airbag. Wash off any residue as soon as possible to prevent skin irritation. Also, upon inflation, a loud noise will occur and some powder and smoke will be released. These conditions are not harmful and do not indicate a fire in the vehicle. Be aware, however, that some airbag components may be hot for a while after inflation. A seat belt helps keep you in the proper position for maximum protection when an airbag inflates. Adjust your seat as far back as possible while still maintaining control of the vehicle. Sit fully back in your seat; sit up straight; do not lean over the steering wheel or dashboard. Please refer to the "Seat Adjustment" section and the "Seat Belts and Child Restraint Systems" in this section for details on proper seat and seat belt adjustments.



65D610S

FOR SAFE DRIVING

A WARNING

- The driver should not lean over the steering wheel. The front passenger should not rest his or her body against the dashboard, or otherwise get too close to the dashboard. In these situations, the outof-position occupant would be too close to an inflating airbag, and may suffer severe injury.
- Do not attach any objects to, or place any objects over, the steering wheel or dashboard. Do not place any objects between the airbag and the driver or front passenger. These objects may interfere with airbag operation or may be propelled by the airbag in the event of a collision. Also, these objects may move when you start moving vehicle or while vehicle is moving, they may interfere with driver's view or safe driving. In each conditions may cause severe injury.
- Do not strike or apply significant levels of impact to the air bag component areas. It can cause the air bags to malfunction.



- Do not modify the system in any way including replacing the steering wheel, placing stickers on the steering wheel pad, painting the steering wheel, or covering the steering wheel with a cover.
- Do not place stickers on or paint the instrument panel. Do not install and set up accessories, air fresheners, ETC readers, or portable navigation systems. Do not stand umbrellas or similar in front of airbags.
- Excluding Maruti Suzuki genuine parts, do not attach accessories to the front windshield or the rearview mirror.

Note that even though your vehicle may be moderately damaged in a collision, the collision may not have been severe enough to trigger the airbags to inflate. If your vehicle sustains any front-end or side damage, have the airbag system inspected by a Maruti Suzuki authorised workshop to ensure it is in proper working order.

Your vehicle is equipped with a diagnostic module which records information about the airbag system if the airbags deploy in a collision. The module records information about overall system status, which sensors activated the deployment, and for a certain vehicle only, whether the driver's seat belt was in use.

Servicing the airbag system

If the airbags inflate, have the airbags and related components replaced by a Maruti Suzuki authorised workshop as soon as possible.

If your vehicle ever gets in deep water and the driver's floor is submerged, the airbag controller could be damaged. If it does, have the airbag system inspected by the Maruti Suzuki authorised workshop as soon as possible.


Special procedures are required for servicing or replacing an airbag. For that reason, only a Maruti Suzuki authorised workshop should be allowed to service or replace your airbags. Please remind anyone who services your MARUTI SUZUKI that it has airbags.

Service on or around airbag components or wiring must be performed only by a Maruti Suzuki authorised workshop. Improper service could result in unintended airbag deployment or could render the airbag inoperative. Either of these two conditions may result in severe injury.

To prevent damage or unintended inflation of the airbag system, be sure the lead-acid battery is disconnected and the ignition switch has been in the LOCK position for at least 90 seconds before performing any electrical service work on your MARUTI SUZUKI. Do not touch airbag system components or wires. The wires are wrapped with yellow tape or yellow tubing, and the couplers are yellow for easy identification.

Scrapping a vehicle that has an uninflated airbag can be hazardous. Ask your dealer, body repair shop or scrap yard for help with disposal.

Exhaust Gas Warning



MARNING

Avoid breathing exhaust gases.
Exhaust gases contain carbon monoxide, a potentially lethal gas that is colorless and odorless. Since carbon monoxide is difficult to detect by itself, be sure to take the following precautions to help prevent carbon monoxide from entering your vehicle.
Do not leave engine running in garages or confined areas, with passengers inside. This may result in accumulation of carbon-monoxide in cabin and may lead to suffocation or breathing problems and lead to death.

(Continued)

A WARNING

(Continued)

- Do not park with the engine running for a long period of time, even in an open area. In case of long periods, danger of choking and death on being inside the vehicle is a possibility when the engine is running. If it is necessary to sit for a short time in a parked vehicle with the engine running, make sure the air intake selector is set to "FRESH AIR" and the blower is at high speed.
- Avoid operating the vehicle with the tailgate or trunk open. If it is necessary to operate the vehicle with the tailgate or trunk open, make sure all windows are closed, and the blower is at high speed with the air intake selector set to "FRESH AIR".
- To allow proper operation of your vehicle's ventilation system, keep the air inlet grille in front of the windshield clear of snow, leaves or other obstructions at all times.


(Continued)

WARNING

(Continued)

- Keep the exhaust tailpipe area clear of snow and other material to help reduce the buildup of exhaust gases under the vehicle. This is particularly important when parked in blizzard conditions.
- Have the exhaust system inspected periodically for damage and leaks. Any damage or leaks should be repaired immediately.

1-32




Keys	2-1
Door Locks	
Keyless entry system transmitter /	
Keyless push start system remote controller	
(if equipped)	2-6
Security System (if equipped)	2-15
Theft deterrent light	
Windows	
Mirrors	2-19
Instrument Cluster (Type A) (if equipped)	2-22
Speedometer	

BEFORE DRIVING

Tachometer	2-23
Fuel gauge	2-23 2
Brightness Control	2-24
Information Display	2-25
Instrument Cluster (Type B) (if equipped)	2-32
Speedometer	2-33
Tachometer	2-33
Fuel gauge	2-33
Temperature Gauge	2-34
Brightness Control	2-34
Information Display	2-35
Warning and Indicator Lights	
Lighting Control Lever	2-66
Front Fog Light Switch (if equipped)	2-67
Headlight Leveling Switch	2-68
Turn Signal Control Lever	2-69
Hazard Warning Switch	2-70
Windshield Wiper and Washer Lever	2-70
Tilt Steering Lock Lever	2-72
Horn	2-72
Heated Rear Window Switch (if equipped)	2-73
Vehicle Loading	2-73
Trailer Towing your vehicle	2-74

Keys



Your vehicle comes with a pair of identical keys. Keep the spare key in a safe place. One key can open all of the locks on the vehicle.

The key identification number is stamped on a metal tag provided with the keys or on the keys. Keep the tag (if equipped) in a safe place. If you lose your keys, you will need this number to have new keys made. Write the number below for your future reference.

KEY NUMBER:

Immobilizer System

This system is designed to help prevent vehicle theft by electronically disabling the engine starting system.

The engine can be started only with your vehicle's original immobilizer ignition key or keyless push start system remote controller, which has an electronic identification code programmed in it. The key or remote controller communicates the identification code to the vehicle when the ignition switch is turned "ON" or pushed to "ON" mode. If you need to make spare keys or remote controllers, see a Maruti Suzuki authorised workshop. The vehicle must be programmed with the correct identification code for the spare. A key made by an ordinary locksmith will not work.



If the immobilizer/keyless push start system warning light blinks when the ignition switch is in "ON" position or the ignition mode is "ON", the engine will not start. For vehicles without a keyless push start system

If this light blinks, turn the ignition switch to LOCK position, and then turn it back to ON position.

If the light still blinks after the ignition switch is turned back to ON position, there may be something wrong with your key or with the immobilizer system. Ask a Maruti Suzuki authorised workshop to have the system inspected.

For vehicles with a keyless push start system

If this light blinks, change the ignition mode to "LOCK" (OFF), and then change it back to "ON". Also refer to "If the master warning indicator light blinks and the engine cannot be started" in "Starting engine (vehicle with keyless push start system) (if equipped)" in "OPERATING YOUR VEHI-CLE" section.

If the light still blinks after the ignition mode is changed back to "ON", there may be something wrong with your key or with the immobilizer system. Ask a Maruti Suzuki authorised workshop to have the system inspected.

The immobilizer/keyless push start system warning light may also blinks if the remote controller is not in the vehicle when you close the door or attempt to start the engine.

NOTE:

- If you lose your immobilizer ignition key or remote controller, ask a Maruti Suzuki authorised workshop as soon as possible to deactivate the lost one, and to make a new key or remote controller.
- If you own other vehicles with immobilizer keys, keep those keys away from the ignition switch or the engine switch when using your MARUTI SUZUKI vehicle. Otherwise, or the engine may not be started because they may interfere with your MARUTI SUZUKI vehicle's immobilizer system.
- If you attach any metal objects to the immobilizer key or remote controller, it may not start the engine.

NOTICE

The immobilizer key and remote controller are sensitive electronic instruments.

To avoid damaging them:

- Do not expose them to impacts, moisture or high temperature such as on the dashboard under direct sunlight.
- Keep them away from magnetic objects.

NOTICE

Do not modify or remove the immobilizer system. If modified or removed, the system cannot be properly operated.


This immobilizer system is maintenance-free.

Ignition Key Reminder

A buzzer sounds intermittently to remind you to remove the ignition key if it is in the ignition switch when the driver's door is opened.

Door Locks

Side Door Locks




(1) UNLOCK(2) LOCK(3) Front(4) Rear

To lock a front door from outside the vehicle:

- Insert the key and turn the top of the key toward the front of the vehicle, or
- Turn the lock knob forward, then pull and hold the door handle as you close the door.

To unlock a front door from outside the vehicle, insert the key and turn the top of the key toward the rear of the vehicle.




(1) LOCK (2) UNLOCK

To lock a door from inside the vehicle, turn the lock knob forward. Turn the lock knob rearward to unlock the door.

To lock a rear door from outside the vehicle, turn the lock knob forward and close the door. You do not need to pull and hold the door handle as you close the door.

NOTE:

Be sure to hold the door handle when you close a locked front door, or the door will not remain locked.




(1) UNLOCK
(2) LOCK
(3) Front
(4) Rear

You can lock and unlock all doors (including the tailgate) simultaneously by using the key in the driver's door lock.

To lock all doors simultaneously, insert the key in the driver's door lock and turn the top of the key toward the front of the vehicle once.

To unlock all doors simultaneously, insert the key in the driver's door lock and turn the top of the key toward the rear of the vehicle twice.

To unlock the driver's door only, insert the key in that door lock and turn the top of the key toward the rear of the vehicle once.





You can also lock or unlock all doors by depressing the front or rear of the switch, respectively.

NOTE:


- You can also lock or unlock all doors by operating the transmitter or remote controller. Refer to "Keyless push start system remote controller / Keyless entry system transmitter (if equipped)" in this section.
- If your vehicle is equipped with the keyless push start system, you can also lock or unlock all doors by pushing the request switch. Refer to "Keyless push start system remote controller / Keyless entry system transmitter (if equipped)" in this section.

2-3

NOTE:

- All doors are automatically unlocked when you change the ignition mode to LOCK (OFF) or turn the ignition switch to the "LOCK" position and pull out the key.
- All doors are automatically locked for safety when the vehicle speed reaches 15 km/h.
- You can change the automatic locking or unlocking function mentioned above via the setting mode of the information display. For details on how to use the information display, refer to "Information display" in this section.

Child-Proof Locks (rear door)



(1) LOCK (2) UNLOCK

Each of the rear doors is equipped with a child-proof lock which can be used to help prevent unwanted opening of the door from inside the vehicle. When the lock lever is in LOCK position (1), the rear door can only be opened from outside. When the lock lever is in UNLOCK position (2), the rear door can be opened from inside or outside.

A WARNING


Place the child-proof lock in LOCK position whenever children are seated in the rear.

Tailgate

A WARNING

Always make sure that the tailgate is closed and latched securely. Completely closing the tailgate helps prevent occupants from being thrown from the vehicle in the event of an accident. Completely closing it also helps keep exhaust gases from entering the vehicle.

Type A



(1) Tailgate handle


You can lock and unlock the tailgate by using the key in the driver's door lock.

To open the tailgate, pull up the tailgate handle (1) and lift the tailgate. If you cannot unlock the tailgate by using

2-4


the key in the driver's door lock due to a discharged lead-acid battery or malfunction, follow the procedure below to unlatch the tailgate from inside the vehicle.

 Fold the rear seat forward for easier access. Refer to "Folding rear seats" section for details on how to fold the rear seat forward.



2) Open the cover (2) in the lock mechanism of the tailgate.


NOTE: Be careful not to lose the cover (2) because it is small and detachable.



- Move the lever (3) in arrow direction by using a flat-bladed screwdriver to unlock the tailgate.
- Push open the tailgate from inside. The tailgate will be latched again by simply closing the tailgate.

If the tailgate cannot be unlatched by pushing the unlatch switch (1), have the vehicle inspected by a Maruti Suzuki authorised workshop.

Check that there is no one near the tailgate when pushing open the tailgate from inside the vehicle.




To open the tailgate, insert the key and turn it clockwise to unlatch and lift the tailgate.

NOTICE

Do not use the key to lift up the tailgate, or the key may break off in the lock.

Keyless entry system transmitter /Keyless push start system remote controller (if equipped)




Your vehicle is equipped with either a keyless entry system transmitter (Type A) or a keyless push start system remote controller (Type B). The transmitter has only a keyless entry function. The remote controller has a keyless entry function and a keyless push start system. The transmitter has only a keyless entry function. For details, refer to the following explanations.

A WARNING

Radio waves from the keyless push start system antenna(s) may interfere with operation of electrical medical equipment such as pacemakers. Failure to take the precautions listed below can increase the risk of severe injury or death due to radio wave interference.

- Anyone who uses electrical medical equipment such as a pacemaker should consult the medical equipment supplier or their medical advisor about whether radio waves from the antenna(s) can interfere with the medical equipment.
- If radio wave interference is a concern, have the function of the antenna(s) disabled by a Maruti Suzuki authorised workshop.

Keyless Entry System Transmitter (Type A)



(1) LOCK button(2) UNLOCK button

You can lock or unlock all doors (including the tailgate) simultaneously by operating the transmitter near the vehicle.

Central door locking system

- To lock all doors, push LOCK button (1) once.
- To unlock only the driver's door, push UNLOCK button (2) once.
- To unlock other doors, push UNLOCK button (2) once again.

NOTE:

You can switch the function that unlocks all doors from requiring two pushes to requiring one push, and vice versa, via the information display setting mode. For details on how to use the information display, refer to "Information display" in this section.

The turn signal lights will flash once and the siren will sound once when the doors are locked.

When the doors are unlocked:

- The turn signal lights will flash twice and the siren will sound twice when unlocked.
- If the interior light switch is in the "DOOR" position, the interior light will turn on for 15 seconds and then fade out. If you insert the key into the ignition switch during this time, the light will start to fade out immediately.

Be sure the doors are locked after you operate the LOCK button (1).

NOTE:

If no door is opened within about 30 seconds after the UNLOCK button (2) is operated, the doors will automatically lock again.

NOTE:

- If the security system was triggered due to an unauthorized entry into the vehicle and then you unlock the doors using the transmitter, the siren will sound 4 times to remind you. If this happens, check whether your vehicle has been broken into while you were away from it.
- Once you push both of the LOCK button (1) and UNLOCK button (2), then you push one of the buttons within 5 seconds, the siren will not sound.

NOTE:

- The maximum operating distance of the keyless entry system transmitter is about 5 m (16 ft.), but this can vary depending on the surroundings, especially near other transmitting devices such as radio towers or CB (Citizen's Band) radios.
- The door locks cannot be operated with the transmitter, if the ignition key is inserted in the ignition switch.
- When any door is open, the door locks can be operated only unlock with the transmitter.
- If you lose one of the transmitters, ask a Maruti Suzuki authorised workshop as soon as possible for a replacement. Be sure to have your dealer program the

new transmitter code in your vehicle's memory so that the old code is erased.

NOTICE

The transmitter is a sensitive electronic instrument. To avoid damaging the transmitter:

- Do not expose it to impacts, moisture or high temperature such as by leaving it on the dashboard under direct sunlight.
- Keep the transmitter away from magnetic objects such as a television.

Car locator alarm function

This function is to get the attention of others. Push both of the LOCK button (1) and UNLOCK button (2) for more than 3 seconds. The turn signal lights will blink for about 27.5 seconds. Also, the siren will sound for about 27.5 seconds at the same time. To cancel the car locator alarm, press any button (LOCK or UNLOCK). You can also cancel the car locator alarm by turning the ignition switch to "ON" position.


NOTE:

The car locator alarm function will not activate when the key is in the ignition switch.


Battery replacement

If the transmitter becomes unreliable, replace the battery.

To replace the battery of the transmitter:



- 1) Remove the screw (1), and open the transmitter cover.
- 2) Remove the transmitter (2).



- (3) Button type lithium battery: CR1616 or equivalent
- 3) Put the edge of a flat blade screwdriver covered with a soft cloth in the slot of the transmitter (2) and pry it open.
- Replace the battery (3) so its + terminal faces the "+" mark of the transmitter.
- 5) Close the transmitter and install it into the transmitter holder.
- 6) Close the transmitter cover, install and tighten the screw (1).
- 7) Make sure the door locks can be operated with the transmitter.
- B) Dispose of the used battery properly according to applicable rules or regulations. Do not dispose of lithium batteries as ordinary household trash.

Swallowing a lithium battery may cause serious internal injury. Do not allow anyone to swallow a lithium battery. Keep lithium batteries away from children and pets. If swallowed, contact a physician immediately.


NOTICE

- The transmitter is a sensitive electronic instrument. To avoid damaging it, do not expose it to dust or moisture or tamper with internal parts.
- When replacing the battery by yourself, the transmitter controller could be damaged affected by static electricity. Discharge the static electricity built up in your body by touching metal before replacing the battery.

NOTE:

Used batteries must be disposed of properly according to applicable rules or regulations and must not be disposed of with ordinary household trash.

2-8



(1) Crossed-out wheeled bin symbol


The crossed-out wheeled bin symbol (1) indicates that a used battery should be collected separately from ordinary household trash.

By ensuring the used battery is disposed of or recycled correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate battery disposal. The recycling of materials will help to conserve natural resources. For more detailed information about disposing of or recycling the used battery, consult a Maruti Suzuki authorised workshop.

Keyless Push Start System Remote Controller (Type B)

The remote controller enables the following operations:

- You can lock or unlock the doors by pushing LOCK/UNLOCK buttons on the remote controller. Refer to the explanation in this section.
- You can lock or unlock the doors by pushing the request switch in the front outside door handles. For details, refer to the explanation in this section.
- You can start the engine without using an ignition key. For details, refer to "Engine Switch (Vehicle with Keyless Push Start System)" in "OPERATING YOUR VEHICLE" section.



(1) LOCK button(2) UNLOCK button

You can lock or unlock all doors (including the tailgate) simultaneously by operating the remote controller near the vehicle.

Central door locking system

- To lock all doors, push LOCK button (1) once.
- To unlock only the driver's door, push UNLOCK button (2) once.
- To unlock other doors, push UNLOCK button (2) once again.

NOTE:

You can switch the function that unlocks all doors from twice operations to once operation, and vice versa, via the setting mode of the information display. For details on how to use the information display, refer to "Information Display" in this section.

The turn signal lights will flash once and the siren will sound once when the doors are locked.

When the doors are unlocked:

- The turn signal lights will flash twice and the siren will sound twice.
- If the interior light switch is in the "DOOR" position, the interior light will turn on for 15 seconds and then fade out. If you press the engine switch during this time, the light will start to fade out immediately.

Be sure the doors are locked after you operate the LOCK button (1).

NOTE:

If no door is opened within about 30 seconds after the UNLOCK button (2) is operated, the doors will automatically lock again.

NOTE:

- If the security system was triggered due to an unauthorized entry into the vehicle and then you unlock the doors using the remote controller, the siren will sound 4 times to remind you. If this happens, check whether your vehicle has been broken into while you were away from it.
- Once you push both of the LOCK button (1) and UNLOCK button (2), then you push one of the buttons within 5 seconds, the siren will not sound.
- You can set whether the siren sounds when locking or unlocking the doors via the setting mode of the information display. For details on how to use the information display, refer to "Information Display" in this section.

NOTE:

 The maximum operating distance of the remote controller is about 5 m (16 ft.), but this can vary depending on the surroundings, especially near other transmitting devices such as radio towers or CB (Citizen's Band) radios.

- The door locks cannot be operated with the remote controller if the ignition mode is other than the "LOCK" (OFF).
- When any door is open, if you push the LOCK button on the remote controller, the siren will sound and doors cannot be locked.
- If you lose one of the remote controllers, ask a Maruti Suzuki authorised workshop as soon as possible for a replacement. Be sure to have your dealer program the new remote controller code in your vehicle's memory so that the old code is erased.

Car locator alarm function


This function is to get the attention of others. Push both of the LOCK button (1) and UNLOCK button (2) for more than 3 seconds. The turn signal lights will blink for about 27.5 seconds. Also, the siren will sound for about 27.5 seconds at the same time. To cancel the car locator alarm, press any button (LOCK or UNLOCK). You can also cancel the car locator alarm in any of the following operations.

- Press the engine switch to change the ignition mode to ON (if car is unlocked).
- Bring the remote controller with you and press the request switch (if car is locked).

NOTE:

The car locator alarm function will not activate when the ignition mode is ACC or ON.

Keyless unlocking/locking using the request switches



73R0022

When the remote controller is within the operating range described in this section, you can lock or unlock the doors (including the tailgate) by pushing the request switch (1) on the driver's door handle, front passenger's door handle or tailgate (2).

To lock all doors when all doors are unlocked:

To lock all doors, push one of the request switches once.

The turn signal lights will flash once and the siren will sound once when the doors are locked.

To unlock a door or all doors:

- Push one of the request switches once to unlock the respective door or the tailgate.
- Push one of the request switches twice to unlock all doors.

NOTE:

You can switch the function that unlocks all doors from twice operations to once operation, and vice versa, via the setting mode of the information display. For details on how to use the information display, refer to "Information Display" in this section.

When the doors are unlocked:


- The turn signal lights will flash twice and the siren will sound twice.
- If the interior dome light switch is in DOOR position, the interior dome light will turn on for 15 seconds and then fade out. If you press the engine switch during this time period, the light will start to fade out immediately.

Be sure the doors are locked after you operate the request switch to lock the doors.

NOTE:

- The door locks cannot be operated by the request switch under the following conditions:
- If any door or tailgate is open or is not completely closed.

- If the ignition mode is other than "LOCK" (OFF).
- If no doors are opened within about 30 seconds after unlocking the doors by pushing the request switch, the doors will be locked again automatically.



(1) 80 cm (2 1/2 feet)

When the remote controller is within approximately 80 cm (2 1/2 feet) from a front door handle or the tailgate switch, which is specified as the operating range, you can lock or unlock the doors by pushing the request switch.

NOTE:

 If the remote controller is outside the operating range described above, you will not be able to operate the request switch.

- If the battery of the remote controller runs down or there are strong radio waves or noise, the operating range may be reduced or the remote controller may become inoperative.
- If the remote controller is too close to the door glass, the request switches may not operate.
- If a spare remote controller is in the vehicle, the request switches may not operate normally.
- The remote controller will only activate a request switch if it is within the activate operating range. For example, if the remote controller is within the operating range for the driver's door request switch but not for the front passenger's door request switch not for the tailgate request switch, the driver's door switch can be operated but the front passenger's door switch or tailgate switch cannot be operated.

NOTICE

The remote controller is a sensitive electronic instrument. To avoid damaging the remote controller:

- Do not expose it to impacts, moisture or high temperature such as by leaving it on the dashboard under direct sunlight.
- Keep the remote controller away from magnetic objects such as a television.

NOTE:


The keyless push start system may not function correctly in certain environments or under certain operating conditions such as the followings:

- When there are strong electromagnetic wave coming from a television, power station or a cellular phone.
- When the remote controller is in contact with or covered by a metal object.
- When a radio wave type remote keyless entry is used nearby.
- When the remote controller is placed near an electronic device such as personal computer.


Some additional precautions you should take and information you should be aware of are:

- Make sure the key is always stowed in the remote controller. If the remote controller becomes unusable, you will not be able to lock or unlock the doors without the key.
- Make sure that the driver always carries the remote controller.
- If you lose one of the remote controllers, ask a Maruti Suzuki authorised workshop as soon as possible for a replacement. Be sure to have your dealer program the new remote controller code in your vehicle's memory so that the old code is erased.

- You can use up to four remote controllers and the keys for your vehicle. Ask a Maruti Suzuki authorised workshop for details.
- The battery life of the remote controller is about two years, but it can vary depending on usage conditions.



To stow the key into the remote controller, push the key in the remote controller until you hear a click.



52RM20090

To remove the key from the remote controller, slide the lock knob (A) in the direction of the arrow and pull the key out from the remote controller.


2-12

Request switch warning buzzer

This exterior buzzer beeps for about 2 seconds in the following conditions to warn you that the request switch is not working:

- The request switch is pressed after all doors and the tailgate are closed with the ignition mode in ACC or ON position by pressing the engine switch.
- The request switch is pressed under any of the following conditions with the ignition mode in "LOCK" (OFF) position.
- The remote controller is left inside the vehicle.
- Any door (including the tailgate) is open.

To securely lock the doors and the tailgate using the remote controller: With the ignition mode changed to "LOCK" (OFF) by pressing the engine switch, bring out the remote controller. Press the request switch again and check that all doors are completely locked.



If the remote controller is not in the vehicle under the following conditions, the buzzer sounds intermittently for about 2 seconds and the immobilizer/keyless push start system warning light on the instrument cluster blinks:

When one or more doors are opened and all of the doors are later closed with the ignition mode is other than "LOCK". While the warning light is on, the engine can not start.

The indicator light will turn off within several seconds after the remote controller is returned to an area of the vehicle other than the rear luggage area.

If the remote controller is left in the vehicle and you try to lock the driver's door or front passenger's door as described below, the door will be automatically unlocked.

- If you open the driver's door and try to lock the door by turning the lock knob forward or pushing the power door locking switch, the driver's door will be automatically unlocked.
- If you open the front passenger's door and try to lock the door by turning the lock knob forward or pushing the power door locking switch, the front passenger's door will be automatically unlocked.

NOTE:

- The reminder will not operate when the remote controller is on the instrument panel, in the glove box, in a storage compartment, in the sun visor or on the floor etc.
- Be sure that the driver always carries the remote controller.
- Do not leave the remote controller in the vehicle when leaving the vehicle.

2-13

Keyless push start system remote controller battery consumption warning light



If the remote controller becomes unreliable, this light appears on the information display for several seconds when the engine switch is pressed to change the ignition mode to ON.

NOTE:

If this light comes on, replace the battery, and then perform the following operation to reset the light.

• Lock and unlock the doors with the remote controller twice or more.


If the power of your spare remote controller is enough, you can reset the light by operating above procedure with the spare remote controller.

Battery replacement

If the remote controller becomes unreliable, replace the battery.


To replace the battery of the remote controller:

EXAMPLE



1) Pull the key out from the remote controller.

2) Insert a flat blade screwdriver covered with a soft cloth in the slot of the remote controller and pry it open.



- (1) Button type lithium battery: CR2032 or equivalent
- 3) Replace the battery (1) so its + terminal faces the bottom of the case as shown in the illustration.
- 4) Close the remote controller case firmly.
- 5) Make sure the door locks can be operated with the remote controller.
- 6) Dispose of the used battery properly according to applicable rules or regulations. Do not dispose of lithium batteries as ordinary household trash.

2-14

MARNING


Swallowing a lithium battery may cause serious internal injury. Do not allow anyone to swallow a lithium battery. Keep lithium batteries away from children and pets. If swallowed, contact a physician immediately.

NOTICE

- The remote controller is a sensitive electronic instrument. To avoid damaging it, do not expose it to dust or moisture or tamper with internal parts.
- When replacing the battery by yourself, the remote controller could be damaged affected by static electricity. Discharge the static electricity built up in your body by touching metal before replacing the battery.

NOTE:

Used batteries must be disposed of properly according to applicable rules or regulations and must not be disposed of with ordinary household trash.



EXAMPLE

(1) Crossed-out wheeled bin symbol

The crossed-out wheeled bin symbol (1) indicates that a used battery should be collected separately from ordinary household trash.

By ensuring the used battery is disposed of or recycled correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate battery disposal. The recycling of materials will help to conserve natural resources. For more detailed information about disposing of or recycling the used battery, consult a Maruti Suzuki authorised workshop.

Security System (if equipped)

The security system sets after you close the all doors, engine hood.

For the system to armed, you must lock the all doors with the keyless entry system transmitter, keyless push start system remote controller or request switch.

Once the system is armed, any attempt to open a door by using any other means (*) than the keyless push start system remote controller, the request switch or the keyless entry system transmitter, or open the engine hood will cause the alarm to be triggered.

^{*} These means include the following:

- The key

80JM133

- The lock knob on a door
- The power door locking switch

Also, in case that you have set the shock sensor to enabled state and set sensitivity of the pre-warning function and full blast warning function to a level other than 0, the alarm will be triggered if any attempt to tamper with the vehicle. The shock sensor can be selected enabled or disabled state, and sensitivity of each warning can be adjusted as desired. To set the shock sensor, ask your Maruti Suzuki authorised workshop or use the setting mode of the information display.

2-15

NOTE:

- The default setting of the shock sensor is in the disabled state. Set to the enabled state and adjust sensitivity of each warning according to your preference. For details on how to use the information display, refer to "Information display" in this section.
- Your dealer may have already set the shock sensor of the vehicle to the enabled state before you purchase it. Consult your dealer for further information.

NOTE:


- The security system generates alarms when any of the predetermined conditions is met. However, the system does not have any function of blocking unauthorized entry into your vehicle.
- Always use the keyless push start system remote controller, the request switch or the keyless entry system transmitter to unlock the doors when the security system has been armed. Using a key instead will trigger the alarm.
- If a person who does not know the security system is going to drive your vehicle, we recommend you explain the system and its operation to the person.
- Even if the security system is armed, you should still be careful to guard against theft. Do not leave money or things of value in your vehicle.

How to arm the security system

With the all door (including engine hood and tailgate) closed, use the keyless entry system transmitter, keyless push start system remote controller or request switch to lock all the doors. The security system will be armed.

While the system is armed, the indicator (1) continues to blink at intervals of approximately 2 seconds.

EXAMPLE



NOTE:

- To prevent the alarm from being accidentally triggered, avoid arming it while anyone remains inside the vehicle. The alarm will be triggered if any person inside opens the door, tailgate, engine hood, or swings the vehicle (if the shock sensor is in the enabled state).
- The security system is not armed when all doors are locked using the key from outside, or using the door lock levers or

the power door locking switch from inside.

 If any door is not operated within approximately 30 seconds after the doors have been unlocked using the keyless entry system transmitter, keyless push start system remote controller or request switch, the doors are automatically locked again. When the doors are locked, the security system will be armed if the system is in the enabled state.

How to disarm the security system

Simply unlock the doors using the keyless push start system remote controller, the request switch or the keyless entry system transmitter. The security system indicator light will go out, indicating that the security system is disarmed.

How to stop the alarm

Should the alarm be triggered accidentally, unlock the doors using the keyless push start system remote controller, the request switch or the keyless entry system transmitter, or press the engine switch to change the ignition mode to ON or turn the ignition switch to "ON" position. The alarm will then stop.

NOTE:

 Even after the alarm has stopped, if you lock the doors using the keyless push start system remote controller or request

switch, the security system will be rearmed.

- If you disconnect the lead-acid battery while the security system is in the armed condition or the alarm is actually in operation, the alarm will be triggered or retriggered when the lead-acid battery is then reconnected, although, in the latter case, the alarm remains stopped for the period between disconnection and reconnection of the lead-acid battery.
- Even after the alarm has stopped at the end of the predetermined operation time, it will be triggered again if any of the doors, tailgate or engine hood is opened, or the vehicle feels a shock (if the shock sensor is in the enabled state), without disarming the security system.

Checking whether the alarm has been triggered during parking

If the alarm was triggered due to an unauthorized entry into the vehicle and you then press the engine switch to change the ignition mode to ON or turn the ignition switch to ON position, the security system indicator light will blink rapidly for about 8 seconds and a buzzer will beep 4 times during this period. If this happens, check whether your vehicle has been broken into while you were away from it.


Security system indication

- If any of the doors or tailgate are opened without unlocking by the keyless entry system transmitter, keyless push start system remote controller or request switch, all turn signal lights start to blink and the interior buzzer beeps intermittently. After 5 seconds, the siren will sound for about 27.5 seconds. The security system indicator continues to blink during this time.
- If the engine hood is opened, all turn signal lights blink, and the siren sounds for about 27.5 seconds. The security system indicator continues to blink during this time.
- (If the shock sensor is in the enabled state)
- The vehicle feels a shock higher than the pre-warning sensitivity, the siren sounds for about 2 seconds (pre-warning). If the vehicle feel a shock higher than the full blast warning sensitivity, the siren sounds for about 5 seconds (full blast warning). The security system indicator continues to blink during this time.

NOTE:

If you set the full blast warning sensitivity higher than the pre-warning sensitivity in the setting mode of the information display, or the vehicle feels such shock as to be able to trigger the full blast warning, the full blast warning will be triggered preferentially. In this case, the pre-warning will not be triggered.

Theft deterrent light (if equipped)



This light will blink with the ignition switch in LOCK or ACC position, or the ignition mode "LOCK" (OFF) or "ACC". The blinking light is intended to deter theft by leading others to believe that the vehicle is equipped with a security system.

NOTE:


For the security system, refer to "Security System (if equipped)" in this section.

Windows


Power Window Controls

The power windows can only be operated when the ignition switch is in the ON position.


Driver's side



The driver's door has a switch (1) to operate the driver's window, and a switch (2) to operate the front passenger's window and there are switches (3) and (4) to operate the rear right and left passenger windows, respectively.




The passenger's door has a switch (5) to operate the passenger's window.



To open a window, push the top part of the switch. To close the window, lift up the top part of the switch.

The driver's window has AUTO-DOWN features for greater convenience (at toll booths or drive-through restaurants, for example). These features allow the driver to open the window without holding the window switch in DOWN position. Press down the driver's window switch completely and release it. To stop the window before it reaches the FULL-DOWN position, pull up the switch briefly.

Lock switch



73R0005

The driver's door also has a lock switch for the passenger's windows. When you push in the lock switch, the passenger's windows cannot be raised or lowered by operating any of the switches (2), (3), (4) or (5). To restore normal operation, release the lock switch by pushing again.

2-18

A WARNING

- You should always lock the passenger's window operation when there are children in the vehicle. Children can be seriously injured if they get part of their body caught by the window during operation.
- To avoid injuring an occupant by window entrapment, check that no part of the occupant's body such as hands or head is in the path of the power windows when closing them.
- Always remove the ignition key or take the keyless push start system remote controller with you when leaving the vehicle even only for a short time. Also do not leave children alone in a parked vehicle. Unattended children could use the power window switches and get trapped by the window.

NOTE:

If you drive with one of the rear windows open, you may hear a loud sound caused by air vibration. To reduce the sound, open the driver's or front passenger's window, or narrow the rear window opening.

Mirrors

WARNING


Failure to observe following point may result in loss of vehicle control and cause an accident, leading to death or serious injury. Always follow below points while driving.


- Do not adjust the mirrors while driving.
- Always unfold all the outside rearview mirrors and adjust properly before driving.
- Do not place objects in the rear of the vehicle which may hinder visibility or interfere with your vision from the rear window glass.


Inside Rearview Mirror

You can adjust the inside rearview mirror by hand to see the rear of your vehicle in the mirror.

Туре А







(2) Day driving(3) Night driving

To adjust the mirror, set the selector tab (1) to the day position, and then move the mirror up, down or sideways by hand to obtain the best view.

When driving at night, you can move the selector tab to the night position to reduce glare from the headlights of vehicles behind you.

2-19

• Always adjust the mirror with the selector set to the day position.

Only use the night position if it is necessary to reduce glare from the headlights of vehicles behind you. Be aware that in this position you may not be able to see some objects that could be seen in the day position.

Do not modify the inside rearview mirror or install a non-genuine wide mirror. It could result in injury during accident.


Outside Rearview Mirrors

Adjust the outside rearview mirrors so you can just see the side of your vehicle in the mirrors.

A WARNING

Be careful when judging the size or distance of a vehicle or other object seen in the side convex mirror. Be aware that objects look smaller and appear farther away than when seen in a flat mirror.

Type A



Adjust the outside rearview mirrors so you can just see the side of your vehicle in the mirrors.

Type B EXAMPLE (2) L R (3) (4) (4) (4) (3) (4) (4)

73R0030

The switch to control the electric mirrors is located on the driver's door panel. You can adjust the mirrors when the ignition switch is in "ACC" or "ON" position, or the ignition mode is "ACC" or "ON". To adjust the mirrors:

- Rotate the selector switch to the left or right to select the mirror you wish to adjust.
- Push the side of the switch to the direction in which you wish to move the mirror.

2-20

NOTICE

- The electric type outside rearview mirror operates even though the ignition switch is in the ACC position. However, to prevent unnecessary battery discharge, do not adjust the mirrors longer than necessary while the engine is not running
- The mirrors stop moving when they reach the maximum adjusting angles, but the motor continues to operate while the switch is pressed. Do not continue to press the switch in such a situation, as the motor may be damaged.
- Do not attempt to adjust the outside rearview mirror by hand which may cause damage to the motor.

NOTE:


To prevent unintended movement of mirror, always return the selector switch to the center position.

Outside Rearview Mirrors Folding Switch (if equipped)

NOTICE

Do not fold the electrical foldable outside rearview mirror by hand. It could cause motor failure.

EXAMPLE



You can fold the mirrors when you park the vehicle in a narrow space. When the ignition switch is in the ACC or ON position, or the ignition mode is "ACC" or "ON", push the folding switch (1) to fold and unfold the mirrors.

Make sure the mirrors are completely unfolded before you start driving.

A CAUTION

Moving mirrors can pinch and injure a hand. Do not allow any one's hand to get near the mirrors when folding and unfolding the mirrors.


NOTE:

- If you press the folding switch to open the outside rearview mirrors and simultaneously start the engine, then the outside rearview mirrors may get stuck during that moment. In such a situation, to open the outside rearview mirrors completely, again press the folding switch after starting the engine.
- Slight time difference in opening of both outside rearview mirrors is due to angular positioning of the driver seat.

2-21


Instrument Cluster (Type A) (if equipped)

- Speedometer
 Tachometer
 Information display
 Trip meter selector knob
 Indicator selector knob
 Warning and indicator lights





Speedometer




The speedometer indicates vehicle speed in km/h.

Speed Alert System

The speed alert system gives audible warning for alert of over-speed to driver. When vehicle speed exceeds about 80 km/ h, primary level warning with two beeps will sound every minute. When the vehicle speed exceeds about 120 km/h, second-ary level warning with continuous beeps will sound. If the vehicle speed is slowed down to about 118 km/h, primary warning will resume. If the vehicle is slowed down to about 78 km/h, speed alert warning will stop. This buzzer does not indicate any malfunction in vehicle.

Tachometer



The tachometer indicates engine speed in revolutions per minute.


72RM02016

NOTICE

Never drive the vehicle with the engine revving in the red zone or severe engine damage can result. Keep the engine speed below the red zone even when downshifting to a lower gear position. Refer to "Downshifting maximum allowable speeds" in the "OPERAT-

ING YOUR VEHICLE" section.

Fuel gauge



When the ignition switch is in "ON" position, this gauge gives a rough indication of the amount of fuel in the fuel tank. "F" stands for full and "E" stands for empty.

If the fuel meter indicator shows only one segment to "E", refill the tank as soon as possible.

NOTE:

If the last segment blinks, it means that the fuel is almost empty.

If the low fuel warning light (1) comes on, refill the fuel tank immediately.

NOTE:


The activation point of the low fuel warning light (1) varies depending on road conditions (for example, slope or curve) and driving conditions because of fuel movement in the tank.

Refer to "Low fuel warning light" in "Warning and indicator lights" in this section for details.

The mark (2) indicates that the fuel filler door is located on the left side of the vehicle.

NOTICE

To minimize the possibility of damage to catalytic converter or other components of the vehicle, avoid driving the vehicle near empty fuel tank level.




When the ignition switch is turned "ON", the instrument panel lights come on.

Your vehicle has a system to automatically dim the brightness of the instrument panel lights when the position lights or headlights are on.

When the position lights and/or headlights are on, you can adjust change the brightness of the instrument cluster lights brightness in seven levels of intensity.

To increase the brightness of the instrument panel lights, turn the brightness control knob (1) clockwise.

To reduce the brightness of the instrument panel lights, turn the brightness control knob (1) counterclockwise.



101102

Do not adjust the brightness of the instrument panel lights while driving. Otherwise, you could lose control of the vehicle.

2-24

NOTE:

- If you do not turn the brightness control knob within several seconds of activating the brightness control display, the brightness control display will be canceled automatically.
- When you reconnect the lead-acid battery, the brightness of the instrument panel lights will be reinitialized. Readjust the brightness according to your preference.


NOTE:

If you adjust to the maximum brightness level when the position lights or headlights are on, the following functions will be cancelled.

- The function which automatically dims the brightness of instrument panel lights.
- The function which operates with the brightness control, except maximum brightness level.

Information Display

Information display is shown when the ignition switch is turned "ON" or pushed to "ON" mode.



EXAMPLE 7 8 (A) (B) (C) (D) (3) 7280054

(1) Trip meter selector knob(2) Indicator selector knob(3) Information display

The information display shows the following information.

Display (A)

Clock

Display (B) Gear shift indicator (for manual transmis-

sion vehicles) / Thermometer (if equipped)

Display (C)

Trip meter / Instantaneous fuel consumption / Average fuel consumption / Driving range / Odometer

Display (D)

Fuel gauge

Clock

The display (A) shows the time.

To change the time indication:

- 1) Push the trip meter selector knob (1) and the indicator selector knob (2) simultaneously.
- 2) To change the hour indication, turn the indicator selector knob (2) left or right repeatedly when the hour indication blinks. To change the hour indication quickly, turn and hold the indicator selector knob (2). To set the hour indication, push the indicator selector knob (2) and the minute indication will blink.
- 3) To change the minute indication, turn the indicator selector knob (2) left or

right repeatedly when the minute indication blinks. To change the minute indication quickly, turn and hold the indicator selector knob (2). To set the minute indication, push the indicator selector knob (2).

To select 12/24H format, refer to "Setting mode" in this section.

A WARNING

If you attempt to adjust the display while driving, you could lose control of the vehicle.

Do not attempt to adjust the display while driving.

NOTE:

When you disconnect either of the terminals to the lead-acid battery and keep it for a minute, the clock indication will be initialized. Change the indication again to your preference after the reconnection. Gear Shift Indicator (for manual transmission vehicle) / Transmission Selector Position Indicator (for automatic transmission vehicle)


Gearshift indicator (for manual transmission vehicles)

Refer to "Gearshift Indicator" in "OPERAT-ING YOUR VEHICLE" section.

Trip meter / Odometer / Instantaneous fuel consumption / Average fuel consumption / Driving range

The display (C) shows one of the following indications; trip meter A, trip meter B, Odometer, instantaneous fuel consumption, average fuel consumption or driving range.

To switch the display indication (C), push the trip meter selector knob (1) or the indicator selector knob (2) quickly.





☆₽	Push the knob (1).	trip meter	selector
☆₽	Push the knob (2).	indicator	selector

- (b) Trip meter A
- (c) Trip meter B
- (d) Odometer
- (e) Instantaneous Fuel Consumption
- (f) Average fuel consumption (g) Driving range

WARNING

If you attempt to adjust the display while driving, you could lose control of the vehicle.

Do not attempt to adjust the display while driving.

NOTE:

- Indications will change when you push and release a knob.
- The display shows estimated values. Indications may not be the same as actual values.

Trip meter

The trip meter can be used to measure the distance traveled on short trips or between fuel stops. You can use the trip meter A or trip meter B independently.

To reset the trip meter, push and hold the trip meter selector knob (1) until the display shows 0.0.

NOTE:

The indicated maximum value of the trip meter is 9999.9. When you run past the maximum value, the indicated value will return to 0.0.

Odometer

The odometer records the total distance the vehicle has been driven.

Instantaneous Fuel Consumption

The display shows the value of instantaneous fuel consumption only when the vehicle is moving.

NOTE:

- The display does not show the value unless the vehicle is moving.
- Depending on the vehicle's specification, the fuel consumption units of initial setting are indicated as L/100km or km/L.
- For "L/100km" setting, the indicated maximum value of instantaneous fuel consumption is 30. No more than 30 will be indicated on the display even if the actual instantaneous fuel consumption is higher.
- For "km/L" setting, the indicated maximum value of instantaneous fuel consumption is 50. No more than 50 will be indicated on the display even if the actual instantaneous fuel consumption is higher.
- The indication on the display may be delayed if fuel consumption is greatly affected by driving conditions.
- The display shows estimated values. Indications may not be the same as actual values.
- For "L/100km" or "km/L" setting, you can change the units that instantaneous fuel consumption is displayed in. Refer to "Average fuel consumption" in this section.

2-27

Average fuel consumption


If you previously selected average fuel consumption setting, the display shows average fuel consumption from the last reset to the present when the ignition switch is turned "ON".

To reset the average fuel consumption, push and hold the indicator selector knob (2) for a while when the display shows the average fuel consumption.

NOTE:

When you reset the indication or reconnect either of the terminals to the lead-acid battery, the value of average fuel consumption will be shown after driving for a while.

To change the unit of average fuel consumption, while pushing and holding the trip meter selector knob (1), turn the indicator selector knob (2).



NOTE:

- When you change the units that average fuel consumption is displayed in, the instantaneous fuel consumption units will be changed automatically.
- When you disconnect either of the terminals to the lead-acid battery and keep it for a minute, the unit of the average fuel consumption will be initialized. Change the unit again to your preference after the reconnection.

Driving range

If you selected driving range the last time you drove the vehicle, the display indicates "---" for a few seconds and then indicates the current driving range when the ignition switch is turned "ON" or pushed to "ON" mode.

The driving range shown in the display is an indicative unit of the approximate distance you can drive until the fuel gauge indicates "E", based on current driving conditions and the current fuel level in the fuel tank.

When the low fuel warning light comes on, the display "---" will appear.

If the low fuel warning light comes on, fill the fuel tank immediately regardless of the value of driving range shown in the display.

When you refuel, the driving range is updated. However, if you only add a small amount of fuel, the correct value will not be displayed.

NOTE:

- If you refuel when the ignition switch is in "ON" position or the ignition mode is "ON", the driving range may not indicate the correct value.
- When you reconnect either of the terminals to the lead-acid battery, the value of driving range will be shown after driving for a while.
- If there are substantial changes in the driving pattern or vehicle usage, the displayed range may vary significantly.


NOTICE


Keep track of your odometer reading and check the maintenance schedule regularly for required services. Increased wear or damage to certain parts can result from failure to perform required services at the proper mileage intervals.

2-28

Setting Mode

In the setting mode, you can set up and customize the following functions.





\$ Turn the indicator selector knob (2).		
Push the knob (2).	indicator	selector

Depending on vehicle's specifications,

some items may not be displayed.

NOTE:

How to operate the setting mode:

- When the ignition switch is in "ON" position and the vehicle is stationary, push the trip meter selector knob (1) to switch the information display indication (C) to the odometer.
- Push and hold the indicator selector knob (2) until the display shows "*LLoLH*".
- Turn and/or push the indicator selector knob (2) to select a function that you want to set up according to the above chart.
- Turn and/or push the indicator selector knob (2) to register settings of the following functions.

Time indication of clock "EL"

- *[L 12h*: 12-hour format
 - (default setting)
- [L-24h: 24-hour format

2-30

Central door locking system "d /"

- d I-5L I: Unlock all doors by turning the key, pushing the keyless push start system remote controller or request switch once
- d I-5L2: Unlock all doors by turning the key, pushing the keyless push start system remote controller or request switch twice (default setting)

Automatic door locking function " d2"

- d2-5L /: Disable the automatic door locking function
- d2-5L2: Lock all doors when the vehicle speed reaches 15 km/h (default setting)

Automatic door

unlocking function "d3"

- <u>d3-5</u>[]: Disable the automatic door unlocking function
- d3-5L2: Unlock all doors when the key is pulled out from the ignition switch (default setting)

Door locking and unlocking siren "45" (if equipped)

d5-5L /: Siren sounds when the door(s) is(are) locked or unlocked by using the keyless entry system transmitter, keyless push start system remote controller or request switch (default setting)

 d5-5L2: Siren does not sound when the door(s) is(are) locked or unlocked by using the keyless entry system transmitter, keyless push start system remote controller or request switch

Additional flashes

of the turn signal "L2"

- L2-5L /: Turn signal flashes three times after the turn signal lever is returned (default setting)
- L2-5L2: Disable the additional flashes of turn signal

Shock sensor "52"

- 52-51 /: Enable the shock sensor
- 52-5L2: Disable the shock sensor
 - (default setting)

Pre-warning sensitivity of the shock sensor "53"

- 53-LOO: Disable the pre-warning
- 53-L0 / to L /5:

Adjust the pre-warning sensitivity of shock sensor (Lowest sensitivity level is L01 and highest is L15, and default setting is L14) Full blast warning sensitivity of the shock sensor "54"

- 54-LOD: Disable the pre-warning
- 54-L0 / to L /5:

Adjust the full blast warning sensitivity of shock sensor (Lowest sensitivity level is L01 and highest is L15, and default setting is L09)

Initialization setting "dE-an" • dE-an: Initialize all settings




NOTE:

- As shown in the above illustration, "SEL" indicates on the display of currently setting item.
- To go back to the higher level display during operation, turn the indicator selector knob (2) to display "BREH" or "-BRE" and then push the indicator selector knob (2).
- To exit the setting mode, switch the display to show "End" and then push the indicator selector knob (2).

Instrument Cluster (Type B) (if equipped)


- Speedometer
 Tachometer

- Fuel gauge
 Fuel gauge
 Temperature gauge
 Information display
 Trip meter selector knob
 Indicator selector knob
- 8. Warning and indicator lights





Speedometer





The speedometer indicates vehicle speed in km/h.

Speed Alert System

The speed alert system gives audible warning for alert of over-speed to driver. When vehicle speed exceeds about 80 km/ h, primary level warning with two beeps will sound every minute. When the vehicle speed exceeds about 120 km/h, second-ary level warning with continuous beeps will sound. If the vehicle speed is slowed down to about 118 km/h, primary warning will resume. If the vehicle is slowed down to about 78 km/h, speed alert warning will stop. This buzzer does not indicate any malfunction in vehicle.

Tachometer






The tachometer indicates engine speed in revolutions per minute.

NOTICE

Never drive the vehicle with the engine revving in the red zone or severe engine damage can result. Keep the engine speed below the red zone even when downshifting to a lower gear position.

lower gear position. Refer to "Downshifting maximum allowable speeds" in the "OPERAT-ING YOUR VEHICLE" section.

Fuel gauge



When the ignition switch is in "ON" position or the ignition mode is "ON", this gauge gives a rough indication of the amount of fuel in the fuel tank. "F" stands for full and "E" stands for empty.

If the indicator approaches a low level (near "E") on fuel gauge, refill the tank as soon as possible.

NOTE:

The indicator moves a little depending on road conditions (for example, slope or curve) and driving conditions because of fuel moving in the tank.

If the low fuel warning light (1) comes on, refill the fuel tank as soon as possible.

NOTE:


The activation point of the low fuel warning light (1) varies depending on road conditions (for example, slope or curve) and driving conditions because of fuel movement in the tank.

Refer to "Low fuel warning light" in "Warning and indicator lights" in this section for details.

The mark (2) indicates that the fuel filler door is located on the left side of the vehicle.

NOTICE


To minimize the possibility of damage to catalytic converter or other components of the vehicle, avoid driving the vehicle near empty fuel tank level.



When the ignition switch is in "ON" position or the ignition mode is "ON", this gauge indicates the engine coolant temperature. Under normal driving conditions, the indicator should stay within the normal, acceptable temperature range between "H" and "C". If the indicator approaches "H", overheating is indicated. Follow the instructions for engine overheating in "EMERGENCY SERVICE" section.


NOTICE

Continuing to drive the vehicle when engine overheating is indicated can result in severe engine damage.



Brightness Control

72R0063



2-34

When the ignition switch is turned "ON" or pushed to "ON" mode, the instrument panel lights come on.

Your vehicle has a system to automatically dim the brightness of the instrument panel lights when the position lights or headlights are on.

You can adjust the meter illumination brightness regardless of whether the position lights or headlights are off or on.

To increase the brightness of the instrument panel lights, turn the brightness control knob (1) clockwise.

To reduce the brightness of the instrument panel lights, turn the brightness control knob (1) counterclockwise.

Do not adjust the brightness of the instrument panel lights while driving. Otherwise, you could lose control of the vehicle.

NOTE:

- If you do not turn the brightness control knob within several seconds of activating, the brightness control display will be canceled automatically.
- When you reconnect the lead-acid battery, the brightness of the instrument panel lights will be reinitialized. Readjust the brightness according to your preference.


NOTE:

If you adjust to the maximum brightness level when the position lights or headlights are on, the following functions will be cancelled.


- The function which automatically dims the brightness of instrument panel lights.
- The function which operates with the brightness control, except maximum brightness level.

Information Display

The information display is shown when the ignition switch is in "ON" position or the ignition mode is "ON".



1. Information display



2-35

(2) Trip meter selector knob(3) Indicator selector knob

The information display shows the following information.

Display (A) Clock

Display (B)

Thermometer (if equipped)

Display (C)

Fuel consumption / Driving range / Average speed / Driving time / Clock and date / Motion / Torque and power / Accelerator and brake / Energy flow (if equipped) / Total idling stop time and Total idling fuel saved (if equipped)


Display (D)

Selector position (for automatic transmission vehicles) / Gearshift indicator (for manual transmission vehicles)

Display (E)

Trip meter

Display (F) Odometer



721

When the ignition switch is turned "ON" or pushed to "ON" mode, the message shown in the above illustration will appear on the display for several seconds.

Some warning and indicator messages may appear on the display when the ignition switch is in "ACC" or "LOCK" position, or the ignition mode is "ACC" or "LOCK" (OFF).

Clock

When the ignition switch is in "ON" position or the ignition mode is "ON", the display (A) shows the time.

To set the clock, follow "Setting mode" instructions in this section.

WARNING

BEFORE DRIVING

If you attempt to adjust the display while driving, you could lose control of the vehicle. Do not attempt to adjust the display

while driving.

Thermometer (if equipped)

When the ignition switch is in "ÓN" position or the ignition mode is "ON", the display (B) shows the thermometer.

The thermometer indicates the outside temperature.

EXAMPLE



52RM21050

If the outside temperature nears freezing condition, the message shown in the above illustration will appear on the display.

2-36


NOTE:

- The outside temperature indication is not the actual outside temperature when driving at low speed, or when stopped.
- If there is something wrong with the thermometer, or just after the ignition switch is turned "ON" or pushed to "ON" mode, the display may not indicate the outside temperature.

You can change the unit of temperature. To change the unit of temperature, refer to "Setting mode" in this section. Fuel Consumption / Driving Range / Average Speed / Driving Time / Total Idling Stop Time and Total Idling Fuel Saved (if equipped) / Clock and Date / Motion (if equipped) / Torque and Power / Accelerator and Brake (if equipped) / Energy flow (if equipped)

When there are no warning or indicator messages on the display (C), you can select one of the following indications to appear on the display: instantaneous fuel consumption, average fuel consumption, driving range, average speed, driving time, total idling stop time and total idling fuel saved (if equipped), clock and date, motion (if equipped), torque and power, accelerator and brake (if equipped), energy flow (if equipped) or no indication.

2-37



To switch the display indication, push the indicator selector knob (3) quickly.

NOTE:

The value of instantaneous fuel consumption, average fuel consumption, driving range, average speed, total idling fuel saved (if equipped), motion (if equipped), torque and power, accelerator and brake (if equipped) and energy flow (if equipped) shown on the display are affected by the following conditions;


- road condition
- surrounding traffic condition
- driving condition
- vehicle condition
- a malfunction which causes the malfunction indicator light to come on or blink

- (a) Instantaneous fuel consumption / Average fuel consumption / Driving range
- (b) Instantaneous fuel consumption / Average fuel consumption / 5-minute average fuel consumption
- (c) Average speed / 5-minute average speed / Driving time
- (d) Total idling stop time / Total idling fuel saved (if equipped)
- (e) Clock and date
- (f) Motion (if equipped)
- (g) Torque and power
- (h) Accelerator and brake (if equipped)
- (i) Energy flow (if equipped)
- (j) No indication

2-38

Instantaneous fuel consumption

The display shows instantaneous fuel consumption with a bar graph only when the vehicle is moving.



(4) Instantaneous fuel consumption

NOTE:

2-39

- The display does not show the bar graph unless the vehicle is moving.
- Depending on the vehicle's specification, the fuel consumption units of initial setting are indicated as L/100km, km/L, MPG (UK).
- The indicated maximum value of instantaneous fuel consumption is one of the followings. No more than the maximum value will be indicated on the display even if the actual instantaneous fuel consumption is higher.
- For L/100km setting: 30
- For km/L setting: 50
- For MPG (UK) setting: 80

- The indication on the display may be delayed if fuel consumption is greatly affected by driving conditions.
- The display shows estimated values. Indications may not be the same as actual values.

Average fuel consumption / 5-minute average fuel consumption / 1-driving cycle average fuel consumption

Average fuel consumption from previous reset and 5-minute average fuel consumption, and 1-driving cycle average fuel consumption are shown.

(Average fuel consumption)

(5) Average fuel consumption

If you selected average fuel consumption the last time you drove the vehicle, the display shows the last value of average fuel consumption from previous driving when the ignition switch is turned "ON" or pushed to "ON" mode. Unless you reset the value of average fuel consumption, the display indicates the value of average fuel consumption based on the average fuel consumption during previous driving.

NOTE:

52RM21080

When you reconnect the negative (–) terminal to the lead-acid battery, the value of average fuel consumption will be shown after driving for a period of time.

You can select the timing to reset the value of average fuel consumption by one of the following three methods;


- Reset after refuel: the value of average fuel consumption will be reset automatically by refueling.
- Reset with trip meter A: the value of average fuel consumption will be reset automatically by resetting trip meter A.
- Reset manually: the value of average fuel consumption will be reset by pushing and holding the indicator selector knob (3) when the display indicates the average fuel consumption.

To change the timing to reset the value of average fuel consumption, refer to "Setting mode" in this section.

NOTE:

If you add only a small amount of fuel when you select "Reset after refuel", the average fuel consumption value may not be reset.


(5-minute average fuel consumption)




72R0136

(6) 5-minute average fuel consumption

(1-driving cycle average fuel consump-Dı





sumption

You can check transition of average fuel consumption every 5 minutes from 15 minutes before up to now. Also, you can check transition of average fuel consumption the past 3 driving cycles. Time indication and driving cycle indication can be changed. For details, refer to "Setting mode" in this section.

riving range	
EXAMPLE	
Average fuel economy	
Range 999 km	- (8)
	52RM21090

(8) Driving range

If you selected driving range the last time you drove the vehicle, the display indicates "---" for a few seconds and then indicates the current driving range when the ignition switch is turned "ON" or pushed to "ON" mode.

The driving range shown in the display is an indicative unit of the approximate distance you can drive until the fuel gauge indicates "E", based on current driving conditions and the current fuel level in the fuel tank.

When the low fuel warning light comes on, the display "---" will appear. If the low fuel warning light comes on, fill the fuel tank immediately regardless of the value of driving range shown in the display.


When you refuel, the driving range is updated. However, if you only add a small amount of fuel, the correct value will not be displayed.

NOTE:

- If you refuel when the ignition switch is in "ON" position or the ignition mode is "ON", the driving range may not indicate the correct value.
- When you reconnect the negative (-) terminal to the lead-acid battery, the value of driving range will be shown after driving for a period of time.
- If there are substantial changes in the driving pattern or vehicle usage, the displayed range may vary significantly.

Average speed / 5-minute average speed

Average speed from previous reset and 5minute average speed are shown.



(9) Average speed


If you selected average speed the last time you drove the vehicle, the display indicates the last value of average speed from previous driving when the ignition switch is turned "ON" or pushed to "ON" mode. Unless you reset the value of average speed, the display indicates the value of average speed which includes average speed during previous driving.

To reset the value of average speed, push and hold the indicator selector knob (3) for about 2 seconds when the display indicates an average speed. The display shows "---" and then indicates a new average speed after driving for a short time.

NOTE:

When you reconnect the negative (-) terminal to the lead-acid battery, the value of average speed will be shown after driving for a period of time.


(5-minute average speed)



52RM21110

(10) 5-minute average speed

You can check transition of 5-minute average speed every 5 minutes from 10 minutes before up to now.




(11) Driving time

Driving time from previous reset is shown. To reset the driving time, push and hold the indicator selector knob (3) for about 2 seconds when the display indicates a driving time. The display shows "---" and then indicates a new driving time after driving for a short time.

NOTE:

- Disconnection of the lead-acid battery negative (-) terminal will reset the indication of the driving time.
- The indicated maximum value of driving time is 99:59:59. No more than this value will be indicated on the display until you reset the driving time.

Total idling stop time and total idling fuel saved (if equipped)



(12) Total idling stop time (13) Total idling fuel saved

(13) Total fulling fuel saved

The display shows the total length (in hours, minutes and seconds) of engine stopping time and the total amount (in milliliters) of fuel conservation by ENG ASTOP system since the indication was reset.

 To reset the total idling stop time and the total idling fuel saved, push and hold the indicator selector knob (3) for a while when the display shows the total idling stop time and the total idling fuel saved.

NOTE:

- The indicated maximum value of the total idling stop time is 99:59:59 and this value is fixed until it is reset.
- When you reconnect the negative (-) terminal to the lead-acid battery, the


value of the total idling stop time and the total idling fuel saved will be reset.

Clock and date

Date and time are shown. For the setting procedure, refer to "Setting mode" in this section.

Motion

52RM217



The meter indication is different depending on whether the vehicle is stopped or running.

When driving, real time movement of imaginal G position (center of gravity) is displayed on the globe (14), which is resultant with inertia force.

When stopped, historical data of imaginal G positions applied to the vehicle body during the driving is shown as a graph (15).

2-42

G position history graph when the vehicle stopped can be changed to indicate or hide. For details, refer to "Setting mode" in this section.

WARNING

Do not look in the display intensively while driving. Doing so may result in an accident.

NOTE:

- If G position history graph at the vehicle stopped has been set in indication mode, the graph (15) is shown for several seconds when you turn the ignition switch to "LOCK" position or change the ignition mode to "LOCK" (OFF) after driving.
- The graph is shown approximately and the actual movement may differ.

Torque and power

Present engine torque and power are shown.

Accelerator and brake

Present accelerator pedal depressing degree and brake line pressure are shown. The display is selectable to indicate or not to indicate. For details, refer to "Setting mode" in this section.

Energy flow (if equipped)


The state of Smart Hybrid operation can be checked on the information display. For details, refer to "Smart Hybrid (if equipped)" in "OPERATING YOUR VEHICLE" section.

Information display	Description
	When the vehicle is running, ISG (Integrated Starter Generator) assists engine power as an electric motor.
	When the vehicle is powered by the engine.
72R0139	
RIGINE ROTOR BATTERY 72R0140	When decelerating your vehicle, the ISG generates elec- tricity without engine power.
	When the engine automatically stops by the ENG A-STOP system.
72R0141	

2-43

Information shown after driving

When you turn the ignition switch to LOCK position or press the engine switch to change the ignition mode to "LOCK" (OFF), the following information appears for several seconds on the information display.



Selector position (for automatic transmission vehicles) / Gearshift Indicator (for manual transmission vehicles)

EXAMPLE	D (1)	
		52RM242

Selector position (for automatic transmission vehicles)

When the ignition switch is turned to ON position or the engine switch is pressed to change the ignition mode to "ON", the display (D) indicates the gear position (I).

For details on how to use the transmission, refer to "Using transmission" in "OPERAT-ING YOUR VEHICLE" section.

Gearshift Indicator (for manual transmission vehicles)

Refer to "Gearshift indicator" in "OPERAT-ING YOUR VEHICLE" section.

Trip meter

The display (E) shows the trip meter.

The trip meter can be used to measure the distance traveled on short trips or between fuel stops.

You can use trip meter A or trip meter B independently.

To reset the trip meter, push and hold the trip meter selector knob (2) for about 2 seconds when the display shows the trip meter.

Odometer

The display (F) shows the odometer.

The odometer records the total distance the vehicle has been driven.

NOTICE

Keep track of your odometer reading and check the maintenance schedule regularly for required services. Increased wear or damage to certain parts can result from failure to perform required services at the proper mileage intervals.


IVI21140

2-44

Setting Mode

When the ignition switch is in "ON" position or the ignition mode is "ON" and the vehicle is stationary, you can enter into the setting mode of the information display by pushing and holding the indicator selector knob (3) for more than 3 seconds.

- To select the setting item that you want to change, turn the indicator selector knob (3) left or right.
- To change the setting, push the indicator selector knob (3).
- To exit the setting mode, select "Back" and push the indicator selector knob (3).



NOTE:

The currently selected setting item is surrounded by a frame.

NOTE:

- If you push and hold the indicator selector knob (3) to enter into the setting mode when the display (C) shows average fuel consumption, average speed, driving time, total idling stop time and total idling fuel saved (if equipped), the value will be reset simultaneously. If you do not want to reset the value, push the indicator selector knob quickly to switch the indication of the display.
- If you turn the ignition switch, press the engine switch or start to move the vehicle when the display is in the setting mode, the setting mode will be canceled automatically.

Distance unit

(Odometer / trip meter / driving range / average speed distance unit setting) You can change the units in which odometer / trip meter / driving range / average speed distance is displayed.

Fuel economy

(Fuel consumption unit setting) You can change the units that fuel consumption is displayed in.

Language

You can change the language of the information display.

Fuel reset

(Average fuel consumption reset setting)

You can change when the value of average fuel consumption is reset.

Temperature

(Temperature unit setting) (if equipped) You can change the units that temperature is displayed in.

 To change the temperature unit, select "Temperature" in "Setting mode". Then, select "°C" or "°F".

NOTE:

When you change the units that temperature is displayed in, the automatic heating and air conditioning system (if equipped) temperature display units will be changed automatically.

Clock setting

(Adjusting the clock)

- Adjust the clock by selecting "Clock setting" in "Setting mode". Then, select "Adjust clock".
- To change the hour indication, turn the indicator selector knob (3) left or right repeatedly when the hour indication blinks. To change the hour indication quickly, turn and hold the indicator selector knob (3). To set the hour indication, push the indicator selector knob (3) and the minute indication blinks.
- To change the minute indication, turn the indicator selector knob (3) left or right

repeatedly when the minute indication blinks. To change the minute indication quickly, turn and hold the indicator selector knob (3). To set the minute indication, push the indicator selector knob (3).

(Selecting 12H/24H format)

• Switch the time indication between 12hour and 24-hour format by selecting "Clock setting" in "Setting mode". Then, select "12H" or "24H".

(Adjusting the date)

- Adjust the date by selecting "Clock setting" in "Setting mode". Then select "Adjust date".
- To adjust year, month and day, operate the indicator selector knob (3) in the same way as adjusting the clock.

Door lock (Door lock setting) (Door unlock)

All Doors:

Unlock all doors by turning the key, or operating the keyless entry system transmitter, keyless push start system remote controller or request switch once • Driver Door:

Unlock all doors by turning the key, or operating the keyless entry system transmitter, keyless push start system remote controller or request switch twice (default setting)

(Auto lock)

Manual Lock:

Disable the automatic door locking function

- Speed Syncro: Lock all doors when the vehicle speed reaches 15 km/h (default setting)
- Shift Syncro: (For automatic transmission vehicle) Lock all doors when the gearshift lever is in other than "P".

(Auto unlock)

Syncro Off:

Disable the automatic door unlocking function (default setting for the vehicle with the keyless push start system)

- Shift Syncro: (For automatic transmission vehicle) Unlock all doors when the gearshift lever is moved to the "P" from other position.
- IG-OFF Sync: Unlock all doors when the key is pulled out from the ignition switch or the engine switch is pressed to change the ignition mode to LOCK (OFF) (default setting for the vehicle without the keyless push start system)

(Alarm)

 You can turn off or on the siren sound when the door(s) is(are) locked or unlocked.

Lights

(Lane change setting) The turn signal and its indi

The turn signal and its indicator can be set whether they flash three times even if you return the turn signal control lever immediately after moving it.

Antitheft

(Shock sensor system setting)

You can change the on/off of the shock sensor.

(Shock sensor P setting)

You can adjust the pre-warning sensitivity of shock sensor.

(Shock sensor F setting)

You can adjust the full blast warning sensitivity of shock sensor.

IS A/C

(ENG A-STOP system setting) (if equipped)

- When the automatic air conditioning system is turned ON (if equipped), you can select one of the following engine auto stop settings.
- Standard
- Economy
- Comfort
- When "Economy" is selected, compared with "Standard" the engine auto stop condition will occur more frequently, the stop time will be longer, leading to reduction of fuel consumption.
- When "Comfort" is selected, compared with "Standard" the engine auto stop

2-46

condition will occur less frequently, the stop time will be shorter, leading to more comfortable cabin condition by the air conditioning system.

Display item

("Car color" setting)

You can change the car color of the information display.

("Calendar dis" setting)

You can select whether you show the calender on the information display or not.

("Calendar form" setting)

You can change the calendar form of the information display. To change the calendar form, select "Cal-

endar form" in "Display item". Then, select the display order of date, month and year.

("Fuel eco hist" setting)

Transitional indication of average fuel consumption can be switched to time indication and driving cycle indication.

("Motion hist" setting)

Indication of G position history graph at the vehicle stopped can be selected to enable or disable.

("Idling disp" setting) (if equipped)

Display of ENG A-STOP operation with the ignition switch in LOCK position or ignition mode "LOCK" (OFF) is selectable to indicate or not to indicate.

("Idling warn" setting) (if equipped)

You can switch whether the information display shows the warning and indicator messages related on the ENG A-STOP system.

("Pedal op disp" setting)

Display of "Accelerator and brake" is selectable to indicate or not to indicate.

Default (initialization setting)

If you select "YES" and push the indicator selector knob (3), all settings will be reinitialized.

Warning and Indicator Messages

The display shows warning and indicator messages to let you know about certain vehicle problems.

A tone may also sound to alert you.

If warning and indicator messages appear on the display, follow the messages. Master warning indicator light



80P0382

When the display shows warning and indicator messages, the master warning indicator light may also blink.

NOTE:

- When the problem that causes a message to appear is corrected, the message will disappear.
- If a message is displayed, and other problems requiring a message occur, the message for each of the problems will be alternately displayed about every 5 seconds.
- When you push and hold the indicator selector knob (2) for about 2 seconds while a message is displayed, the message will disappear temporarily. If the problem that caused the message is not corrected, the message will appear again after 5 seconds.

2-47

Warning and indicator messages

All model

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
72RS080	Blinks (only while vehicle is in motion)	Beep (one time from interior buzzer; only while vehicle is in motion)	A door or tailgate is not properly closed. Stop the vehicle in a safe place and close the door or tailgate properly. (#1)
RELEASE PARKING BRAKE		Continuous beep (from inte- rior buzzer)	The parking brake is not released. Stop the vehicle in a safe place and release the parking brake.
52RS005			

(#1) This message will disappear after a while even if the problem that caused the message to appear is not corrected.

2-48

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
LIGHTS ON	Blinks	Continuous beep (from inte- rior buzzer)	The headlights and/or the position lights are left on. Turn them off.
LOW FUEL	Off	Beep (one time from interior buzzer)	Fuel is low. Refill it immediately. (#1)

(#1) This message will disappear after a while even if the problem that caused the message to appear is not corrected.

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
ICE POSSIBLE DRIVE WITH CARE	Off	Off	The road may be icy. Drive very carefully. (#1)
52RM21190			

(#1) This message will disappear after a while even if the problem that caused the message to appear is not corrected.

2-50

Vehicle with keyless push start system

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
IGNITION SWITCH POSITION 52RM21210	Off	Off	This message is displayed when "ACC" position is selected as the ignition mode. (#1)
PUSH START SWITCH	Off	Off	The brake pedal (for automatic transmission models) or the clutch pedal (for manual transmission models) is depressed. Press the engine switch to start the engine.

(#1) This message will disappear after a while even if the problem that caused the message to appear is not corrected.

2-51

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
SERVICE STEERING LOCK SYSTEM		Beep (one time from interior buzzer)	There is a problem with the steering lock system. Have your vehicle inspected by a Maruti Suzuki authorised workshop.
SERVICE START SYSTEM 52RM21240		Beep (one time from interior buzzer)	There is a problem with the immobilizer/ keyless push start system. Also, the vehicle lead-acid battery voltage may be decreased. When the message is displayed even if you start the engine with normal voltage of the vehicle lead-acid battery, have your vehicle inspected by a Maruti Suzuki authorised workshop.

2-52

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
KEY FOB NOT DETECTED	Blinks	By certain conditions, some kind of sound you will hear from interior and/or exterior of the vehicle.	vehicle or its battery may have become dis-
PLACE KEY FOB ON START SWITCH	121260		

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
IGNITION SWITCH POSITION 52RM21270	Off	Off	This message is displayed when "ON" posi- tion is selected as the ignition mode. (#1)
TRN. STEERING WHEEL TO RELEASE LOCK 52RM21280	Blinks	Beep (one time from interior buzzer)	The steering lock is not disengaged. While lightly turning the steering wheel in both directions, press the engine switch again.

(#1) This message will disappear after a while even if the problem that caused the message to appear is not corrected.

2-54

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
KEY FOB LOW BATTERY 52RM21290	Off	Off	The remote controller battery is about to become flat. Replace the battery. (#1)
Manual transmission	Off	Off	The engine switch is pressed without depressing the brake and clutch pedals. Try again as instructed by the message.
52RM21300			

(#1) This message will disappear after a while even if the problem that caused the message to appear is not corrected.

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
Automatic transmission	Off	Off	The engine switch is pressed with the gear- shift lever in a position other than "P" or "N" and depressing the brake pedal. Try again as instructed by message.
Automatic transmission	Off	Off	The engine switch is pressed with the gear- shift lever in a position other than "P". Try again as instructed by the message.

2-56

Vehicle with $\mathsf{ESP}^{ extsf{B}}$ system

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
ESP SERVICE ESP SYSTEM 52RM21340		Beep (one time from interior buzzer)	There may be a problem with ESP [®] system. Have your vehicle inspected by a Maruti Suzuki authorised workshop.
Hill hold control system ESP HILL HOLD DISABLE		Beep (one time from interior buzzer)	There may be a problem with hill hold con- trol system (if equipped). Have your vehicle inspected by a Maruti Suzuki authorised workshop.
52RM21350			

2-57

Warning and Indicator Lights

Brake System Warning Light



Three different types of operations exist depending on the vehicle's specification.

- The light comes on briefly when the ignition switch is turned "ON" or pushed to "ON" mode.
- The light comes on when the parking brake is engaged with the ignition switch in "ON" position or the ignition mode is "ON".
- The light comes on under either or both of above two conditions.

The light also comes on when the fluid in the brake fluid reservoir falls below the specified level.

The light should go out after starting the engine and fully releasing the parking brake, if the fluid level in the brake fluid reservoir is adequate. The light also comes on together with the ABS warning light when the rear brake force control function (proportioning valve function) of the ABS system fails.

If the brake system warning light comes on while you are driving the vehicle, it may mean that there is something wrong with the vehicle's brake system. If this happens:

1) Pull off the road and stop carefully.

WARNING

Remember that stopping distance may be longer, you may have to push harder on the pedal, and the pedal may go down farther than normal.

- Test the brakes by carefully starting and stopping the vehicle on the shoulder of the road.
- 3) If you determine that it is safe, drive the vehicle cautiously at low speed to the nearest Maruti Suzuki authorised workshop for repairs or tow the vehicle to the nearest Maruti Suzuki authorised workshop for repairs.

A WARNING

If any of the following conditions occur, you should immediately ask a Maruti Suzuki authorised workshop to inspect the brake system.

- If the brake system warning light does not go out after the engine has been started and the parking brake has been fully released.
- If the brake system warning light does not come on when the ignition switch is turned "ON" or pushed to "ON" mode.
- If the brake system warning light comes on at any time during vehicle operation.


NOTE:

Because the brake system is self-adjusting, the fluid level will drop as the brake pads become worn. Replenishing the brake fluid reservoir is considered normal periodic maintenance.

NOTE:

A buzzer sounds intermittently to remind you to release the parking brake if you start the vehicle without releasing the parking brake. Make sure that the parking brake is fully released and the brake system warning light turns off.

Anti-Lock Brake System (ABS) Warning Light



When the ignition switch is turned "ON" or pushed to "ON" mode, this light comes on briefly so you can check that the light is working.

If the light stays on, or comes on when driving, there may be something wrong with the ABS.

If this happens:

- 1) Pull off the road and stop carefully.
- Turn the ignition switch to LOCK position or change the ignition mode to "LOCK" (OFF) by pressing the engine switch and then start the engine again.

If the warning light comes on briefly and then turns off, the system is normal. If the warning light still stays on, something is wrong with the system.

If the light and the brake system warning light stay on or come on simultaneously when driving, your ABS system is equipped with the rear brake force control function (proportioning valve function) and there may be something wrong with both the rear brake force control function and then anti-lock function of the ABS system.

If one of the above occurs, have the system inspected by a Maruti Suzuki authorised workshop.

If the ABS becomes inoperative, the brake system will function as an ordinary brake system that does not have this ABS system.

For details of ABS system, refer to "Anti-Lock Brake System (ABS)" in "OPERAT-ING YOUR VEHICLE" section.

When the ignition switch is turned "ON" or

pushed to "ON" mode, this light comes on.

When the engine is started, the light goes

out. The light will come on and remain on if

there is insufficient oil pressure. If the light

comes on when driving, pull off the road as

Check the oil level and add oil if necessary.

If there is enough oil, the lubrication sys-

tem should be inspected by a Maruti

Suzuki authorised workshop before you

soon as you can and stop the engine.

drive the vehicle again.

Oil Pressure Warning Light

NOTICE

- If you operate the engine with this light on, severe engine damage can result.
- Do not rely on the oil pressure light to indicate the need to add oil. Periodically check the engine oil level.

ESP[®] Warning Light (if equipped)



 $\mathsf{ESP}^{\texttt{®}}$ is a registered trademark of Daimler AG.

This light blinks 5 times per second when one of the following systems is activated.

Stability control system

50G051

Traction control system

If this light blinks, drive carefully.

When the ignition switch is turned "ON" or pushed to "ON" mode, the light comes on briefly so you can check that the light is working. If the light stays on or comes on when driving, there may be something wrong with the ESP[®] systems (other than ABS). You should have the system

2-59



inspected by a Maruti Suzuki authorised workshop.

For details of the ESP[®] systems, refer to "Electronic Stability Program (ESP[®]) (if equipped)" in "OPERATING YOUR VEHI-CLE" section.

WARNING

The ESP[®] systems cannot prevent accidents. Always drive carefully.

ESP[®] OFF Indicator Light (if equipped)




When the ignition switch is turned "ON" or pushed to "ON" mode, this light comes on briefly so you can check that the light is working.

When the ESP[®] OFF switch is pushed to turn off the ESP[®] systems (other than ABS), the ESP[®] OFF indicator light comes on and stays on.

For details of the $ESP^{\ensuremath{\mathbb{R}}}$ systems, refer to "Electronic Stability Program ($ESP^{\ensuremath{\mathbb{R}}}$) (if

equipped)" in "OPERATING YOUR VEHI-CLE" section.

Charging Light



When the ignition switch is turned "ON" or pushed to "ON" mode, this light comes on. When the engine is started, the light goes out. The light will come on and remain on if there is something wrong with the leadacid battery charging system. If the light comes on when the engine is running, the charging system should be inspected immediately by a Maruti Suzuki authorised workshop. Driver's seat belt reminder light / Front passenger's seat belt reminder light



When the driver or front passenger does not buckle his or her seat belt, this light will come on and/or blink.

For details of the seat belt reminder, refer to "Seat Belts and Child Restraint Systems" in "FOR SAFE DRIVING" section.

AIRBAG Light

the light is working.



When the ignition switch is turned "ON" or pushed to "ON" mode, this light comes on for several seconds so you can check that

The light will come on and stay on if there is a problem in the airbag system or the seat belt pretensioner system.

2-60

If the AIRBAG light does not blink or come on briefly when the ignition switch is turned "ON" or pushed to "ON" mode, stays on for more than 10 seconds, or comes on while driving, the airbag system or the seat belt pretensioner system may not work properly, which could result in serious injury in the event of a collision. Have both systems inspected by a Maruti Suzuki authorised workshop.

Malfunction Indicator Light



Your vehicle has a computer-controlled emission control system. A malfunction indicator light is provided on the instrument cluster to indicate when it is necessary to have the emission control system serviced. When the ignition switch is turned "ON" or pushed to "ON" mode, this light comes on. When the engine is started, the light goes out.

If the malfunction indicator light comes on or blinks when the engine is running, there

2-61

is a damage in the emission control system.

Bring the vehicle to a Maruti Suzuki authorised workshop to have the damage fixed.

If this light blinks, stop your vehicle immediately in a safe place to avoid catalyst's melting problem since there may be a misfire in the engine.

- Do not drive or stop over such as withered grasses.
- Drive slowly if required to move the vehicle.

Also, if this light comes on when the engine is running, there is a problem with the automatic transmission system. Ask a Maruti Suzuki authorised workshop to have the system inspected.

Transmission Warning Light (if equipped)



When the ignition switch is turned "ON" or pushed to "ON" mode, this light comes on for several seconds so you can check that the light is working.

If this light comes on when the engine is running, there is a problem with the automatic transmission system. Ask a Maruti Suzuki authorised workshop to have the system inspected.

NOTICE

Continuing to drive the vehicle when the malfunction indicator light is on or blinking can cause permanent damage to the vehicle's emission control system, and can affect fuel economy and driveability.

54G343

Immobilizer/Keyless Push Start System Warning Light



80JM122

When the ignition switch is turned "ON" or pushed to "ON" mode, this light comes on briefly so you can check that the light is working.

If this light blinks or stays on, there is a problem with the system or the steering lock cannot be released. If this happens, press the engine switch, turning the steering wheel to the right or left. If this light still blinks or stays on even if you start the engine with normal voltage of the vehicle lead-acid battery, ask a Maruti Suzuki authorised workshop.

Open Door Warning Light



This light remains on until all doors (including the tailgate) are completely closed.

If any door (including the tailgate) is open when the vehicle is moving, a ding sounds to remind you to close all doors completely.

Main Beam (high beam) Indicator Light



This indicator comes on when headlight main beams (high beams) are turned on.

Low Fuel Warning Light



If this light comes on, refuel the fuel tank as soon as possible.

When this light comes on, a ding sounds once to remind you to refuel.

If you do not refuel, a ding sounds every time when the ignition switch is turned "ON" or pushed to "ON" mode.

NOTE:

The activation point of this light varies depending on road conditions (for example, slope or curve) and driving conditions because of fuel movement in the tank.

2-62

Electric Power Steering Light



When the ignition switch is turned "ON" or pushed to "ON" mode, this light comes on. When the engine is started, the light goes out.

If this light comes on while driving, the power steering system may not work properly. Have the system inspected by a Maruti Suzuki authorised workshop.

NOTE:

The following steering wheel operations may gradually take more effort while parking or driving at a very low speed. This is not a malfunction of the steering system, but the power steering control system limits the power assist in order to prevent it from overheating.

- The steering wheel is operated very often.
- The steering wheel is kept in a fully turned position for a long while.

When the power steering control system cool down, the power steering system will return to its original condition.

However, repeating these operations could cause damage to the power steering system.

 This light comes on when continuing period of time of limiting the power assist in order to prevent from overheating.

NOTE:

If the power steering system does not work properly, it will require greater effort to steer, but you still will be able to steer.

NOTE:

If the steering is operated, you may hear noise caused by electric power steering operation. This is normal and indicates that the power steering system works properly.

Turn Signal Indicators

50G055

When you turn on the left or right turn signals, the corresponding green arrow on the instrument panel will blink along with the respective turn signal lights. When you turn on the hazard warning switch, both arrows will blink along with all of the turn signal lights.

NOTE:

If any abnormality of the turn signals is observed, such as fast blinking, there may be malfunction in the turn signal system. Ask your Maruti Suzuki authorized workshop to inspect the system.

"PUSH" Indicator Light (if equipped)



. ..

If this light comes on when depressing the brake pedal for automatic transmission vehicles, or the clutch pedal for manual transmission vehicles, you can start the engine.

"ACC" Indicator Light (if equipped)



This light comes on when the ignition mode is "ACC".

Ignition "ON" Indicator Light (if equipped)



This light comes on when the ignition mode is "ON" with the engine off.

82K098

72RM02001

"RE-GEN" Indicator Light (if equipped)



This light comes on for several seconds when the ignition switch is turned to the "ON" position or the engine switch is pressed to change the ignition mode to "ON" so you can check that the light is working.

When the deceleration energy regenerating function is working, this indicator light will come on. "SHVS" Indicator Light (if equipped)



This light comes on for several seconds when the ignition switch is turned to the "ON" position or the engine switch is pressed to change the ignition mode to "ON" so you can check that the light is working.

While you are driving the vehicle, when deceleration energy regenerating function, engine power assist function or starter motor function is activated, this indicator light will come on.

Illumination Indicator Light



This indicator light comes on while the position lights, tail light and/or the head-lights are on.

Front Fog Light Indicator Light (if equipped)



The front fog light indicator light comes on when the front fog light operates.

Over Drive Off Indicator (if equipped)



This light comes on when OD switch is OFF.

2-64

Engine Coolant Temperature Light (if equipped)



54G344

When the ignition switch is turned "ON", this light comes on briefly so you can check that the light is working.

This indicator has the following two functions.

Low engine coolant temperature light (blue color)

This light stays on while the engine is still cold and goes off when the engine has warmed up.

If this light blinks, there is a problem with the system. Have your vehicle inspected by a Maruti Suzuki authorised workshop.

High engine coolant temperature warning light (red color)

If this light blinks while driving, it means the engine is running hot. Avoid driving conditions that may lead to actual overheating. If the light stays on without blinking, then the engine is overheating. Follow the instructions in "If the Engine Overheats" of "EMERGENCY SERVICE" section.

NOTICE

Continuing to drive the vehicle when engine overheating is indicated can result in severe engine damage.

Steering Lock Warning Light (if equipped)



52RS20100

If this light stays on, there is a problem with the system or the steering lock cannot be released. If this happens, press the engine switch, turning the steering wheel to the right or left. If this light still stays on, ask a Maruti Suzuki authorised workshop to have the system inspected.

ENG A-STOP Indicator Light (if equipped)



72M00032

When the ignition switch is turned "ON", this light comes on briefly so you can check that the light is working.

When the engine stops automatically, this light comes on.

For details, refer to "ENG A-STOP System (Engine Auto Stop Start System)" in "OPERATING YOUR VEHICLE" section.

2-65

ENG A-STOP OFF Light (if equipped)



Master Warning Indicator Light (if equipped)



72M00159

When the ignition switch is turned "ON", this light comes on briefly so you can check that the light is working.

When you push the ENG A-STOP OFF switch, this light comes on.


If this light blinks when driving, there may be something wrong with the ENG A-STOP system or the Smart Hybrid system. You should have the system inspected by a Maruti Suzuki authorised workshop.

For details, refer to "ENG A-STOP System (Engine Auto Stop Start System)" and "Smart Hybrid" in "OPERATING YOUR VEHICLE" section. 80P0382 When the ignition switch is turned "ON" or pushed to "ON" mode, this light comes on briefly so you can check that the light is working.

When the information display shows warning and indicator messages, this indicator light may also blink.

For details, refer to "Information display" in this section.

Lighting Control Lever




WARNING

To avoid possible injury, do not operate controls by reaching through the steering wheel.

2-66

Lighting Operation



To turn the lights on or off, twist the knob on the end of the lever. There are three positions:

OFF (1)


All lights are off.

∋o∈ **(2)**

Front position lights, tail lights, license plate light and instrument lights are on, but headlights are off.

≣D (3)

Front position lights, tail lights, license plate light, instrument lights and headlights are on.



With the headlights on, push the lever forward to switch to the high beams (main beams) or pull the lever toward you to switch to the low beams. When the high beams (main beams) are on, a light on the instrument cluster will come on. To momentarily activate the high beams (main beams) as a passing signal, pull the lever slightly toward you and release it when you have completed the signal.

Light Reminder Buzzer

The interior buzzer continuously beeps if you open the driver's door without turning off the headlights and position lights. This function is triggered under the following condition:

The headlights and/or position lights are on even after the ignition switch is turned off, or the engine switch is pressed to change the ignition mode to "LOCK" (OFF).

The buzzer stops sounding when you turn off the headlights and position lights.


Front Fog Light Switch (if equipped)

EXAMPLE

73R0058

To turn the front fog light on, twist the knob as shown in the illustration with the position lights, tail lights and/or the headlights are on. When the front fog light is on, an indicator light on the instrument cluster will come on.

Headlight Leveling Switch



Level the headlight beam according to the load condition of your vehicle by turning this switch. The chart shows the appropri-ate switch position for different vehicleload conditions.

Loading Conditions	Switch Position
Driver (1 Seat)	0
Driver + Co-Driver (2 Seats)	0.5
Driver + Co-Driver + 2nd row 3 Seats	1

All Passengers (7 Seats)

All Passengers + Cargo (Evenly distributed load in luggage boot)

Driver + Cargo (Evenly distributed load in lug-

2

2.5

4

(For CNG model)

(Total-5 Seats)


gage boot)

(For petrol engine (without CNG) model)

Loading Conditions	Switch Position
Driver (1 Seat)	0
Driver + Co-Driver (2 Seats)	0.5
Driver + Co-Driver + 2nd row 3 Seats (Total-5 Seats)	1.5
All Passengers (7 Seats)	2.5
All Passengers + Cargo (Evenly distributed load in luggage boot)	3
Driver + Cargo (Evenly distributed load in lug- gage boot)	4.5

2-68

Turn Signal Control Lever




To avoid possible injury, do not operate controls by reaching through the steering wheel.

Turn Signal Operation


With the ignition switch in "ON" position or the ignition mode "ON", move the lever upward or downward to activate the right or left turn signals.

Normal turn signal



Move the lever all the way upward or downward to signal. When the turn is completed, the signal will cancel and the lever will return to its normal position.

Lane change signal



Move the lever partially upward or downward to turn right or left and hold the lever in the moved position.


- The turn signal and its indicator flash while the lever is held at the moved position.
- The turn signal and its indicator flash 3 times even if you returned the lever immediately after the activation.

NOTE:

The turn signal and its indicator can be set whether they flash 3 times after the turn signal lever is returned via the information display. Refer to "Information display" in this section.


2-69

Hazard Warning Switch



Push the hazard warning switch to activate the hazard warning lights. All turn signal lights and both turn signal indicators will flash simultaneously. To turn off the lights, push the switch again.

Use the hazard warning lights to warn other drivers of possible risk of traffic hazard when you park your vehicle in case of emergency. Windshield Wiper and Washer Lever



WARNING

To avoid possible injury, do not operate controls by reaching through the steering wheel.

Wiper and Washer Operation

When the ignition switch is in "ON" position or the ignition mode is "ON", you can use the wiper/washer lever or switch.

When the wipers are under heavy load such as covered by snow, the breaker will be activated and the wipers will stop operating to protect the wiper motor from overheating.


If the wiper stops during operation, do the following methods.

- 1) Stop the vehicle in a safe place, and turn the engine off.
- 2) Move the wiper lever and switch to "OFF" position.
- 3) Remove obstacles such as snow on the wipers.
- 4) After a while, when the temperature of the wiper motor becomes low enough, the breaker will be reset automatically and the wipers will be able to use.

If you cannot use the wipers after a while, there may be another problem. Ask a Maruti Suzuki authorised workshop to have the wipers inspected.

2-70


Windshield Wipers



To turn the windshield wipers on, move the lever down to one of the three operating positions. In "INT" position, the wipers operate intermittently. "INT" position is very convenient for driving in mist or light rain. In "LO" position, the wipers operate at a steady low speed. In "HI" position, the wipers operate at a steady high speed. To turn off the wipers, move the lever back to "OFF" position.

Move the lever up and hold it to "MIST" position, the windshield wipers will turn on continuously at low speed.

Windshield Washer



To spray windshield washer fluid, pull the lever toward you. The windshield wipers will automatically turn on at low speed if they are not already on and "INT" position is equipped.

WARNING

- To prevent windshield icing in cold weather, turn on the defroster to heat the windshield before and during windshield washer use.
- Do not use radiator antifreeze solution in the windshield washer reservoir. This can severely impair visibility when sprayed on the windshield, and also damage your vehicle's paint.


NOTICE

To help prevent damage to the windshield wiper and washer system components, you should take the following precautions:

- Do not continue to hold in the lever when there is no windshield washer fluid being sprayed or the washer motor can be damaged.
- Do not attempt to remove dirt from a dry windshield with the wipers or you can damage the windshield and the wiper blades. Always wet the windshield with washer fluid before operating the wipers.
- Clear ice or packed snow from the wiper blades before using the wipers.
- Check the washer fluid level regularly. Check it often when the weather is bad.
- Only fill the washer fluid reservoir 3/4 full during cold weather to allow room for expansion if the temperature falls low enough to freeze the solution.

2-71

Rear Window Wiper/Washer Switch



Tilt Steering Lock Lever

(1) LOCK (2) UNLOCK

EXAMPLE

To turn the rear wiper on, twist the rear wiper switch on the end of the lever forward to "ON" position. To turn the rear wiper off, twist the switch rearward to "OFF" position.

To spray window washer fluid, twist the switch rearward from "OFF" position, or twist the switch forward from "ON" position. The rear wiper will turn on automatically while spraying the window washer fluid.

NOTICE


Clear ice or snow from the rear window and rear wiper blade before using the rear wiper. Accumulated ice or snow could prevent the wiper blade from moving, causing damage to the wiper motor. The lock lever is located under the steering column. To adjust the steering wheel height:

73R0012

- 1) Push down the lock lever to unlock the steering column.
- Adjust the steering wheel to the desired height and lock the steering column by pulling up the lock lever.
- Try moving the steering wheel up and down to make sure it is securely locked in position.

WARNING


Never attempt to adjust the steering wheel while the vehicle is moving or you could lose control of the vehicle.



Press the horn button of the steering wheel to sound the horn. The horn will sound with the ignition switch in any position or any ignition mode.

2-72

Heated Rear Window Switch (if equipped)



When the rear window is misted, push this switch (1) to clear the window.

An indicator light will come on when the defogger is on. The defogger will work only when the engine is running. To turn off the defogger, push the switch (1) again.

NOTICE

The heated rear window use a large amount of electricity. Turn off the switch after the window have become clear.

NOTE:

- The defogger will work only when the engine is running.
- The defogger will automatically turn off after the defogger remains on for 15 minutes to prevent discharging of the leadacid battery.

Vehicle Loading

Your vehicle was designed for specific weight capacities. The weight capacities of your vehicle are indicated by the Gross Vehicle Weight Rating (GVWR) and the Permissible maximum Axle Weight (PAW, front and rear). The GVWR and PAW (front and rear) are listed in "SPECIFICATIONS" section.

GVWR – Maximum permissible overall weight of the fully loaded vehicle (including all the occupants, accessories and cargo plus the trailer nose weight if towing a trailer).

PAW – (Front and Rear) Maximum permissible weight on an individual axle.

Actual weight of the loaded vehicle and actual loads at the front and rear axles can only be determined by weighing the vehicle. Compare these weights to the GVWR and PAW (front and rear). If the gross vehicle weight or the load on either axle exceeds these ratings, you must remove enough weight to bring the load down to the rated capacity.

A WARNING

Never overload your vehicle. The gross vehicle weight (sum of the weights of the vehicle, all the occupants, accessories, cargo plus trailer nose weight if towing a trailer) must never exceed the Gross Vehicle Weight Rating (GVWR). In addition, never distribute a load so that the weight on either the front or rear axle exceeds the Permissible maximum Axle Weight (PAW).


WARNING

Always distribute cargo evenly. To avoid personal injury or damage to your vehicle, always secure cargo to prevent it from shifting if the vehicle moves suddenly. Place heavier objects on the floor and as far forward in the cargo area as possible. Never pile cargo higher than the top of the seat backs.

Trailer Towing your vehicle

Your MARUTI SUZUKI was originally designed to carry people and a normal amount of cargo, not to tow a trailer.

2-74



OPERATING YOUR VEHICLE


Daily Inspection Checklist	
(Vehicle without Keyless Push Start System) 3-2 3	
Engine Switch (Vehicle with Keyless Push Start System)	
(if equipped)	
Keyless Push Start System (if equipped)	
Parking Brake Lever	
Pedal	
Starting the Engine	
(Vehicle without Keyless Push Start System)	
Starting the Engine	
(Vehicle with Keyless Push Start System) 3-12	
Using the Transmission	
Gearshift Indicator (if equipped)	
Smart Hybrid (Vehicle with instrument cluster (Type A))	
(if equipped) 3-20	
Smart Hybrid (Vehicle with instrument cluster (Type B))	
(if equipped) 3-21	
ENG A-STOP System	
(Engine Auto Stop Start System) (if equipped) 3-23	
Parking Sensors	
Rearview Camera (if equipped) 3-38	
Braking	
Electronic stability program (ESP [®]) (if equipped)	

and the second	
, //	

60G408

Daily Inspection Checklist

Before Driving



- Make sure that windows, mirrors, lights and reflectors are clean and unobstructed.
- Visually check the tires for the following points:
- the depth of the tread groove
- abnormal wear, cracks and damage
- loose wheel nuts
- existence of foreign material such as nails, stones, etc.

Refer to "Tires" in "INSPECTION AND MAINTENANCE" section for details. 3) Look for fluid and oil leakage.

NOTE:

It is normal for water to drip from the air conditioning system while and after use.

- 4) Make sure the hood is fully closed and latched.
- Check the headlights, turn signal lights, brake lights and horn for proper operation.
- Adjust the seat and head restraint (if equipped).
- 7) Check the brake pedal and the parking brake lever.
- 8) Adjust the mirrors.
- 9) Make sure that you and all passengers have properly fastened the seat belts.
- 10)Make sure that all warning lights come on as the ignition switch is turned to ON position or the ignition switch is turned "ON" or pushed to "ON" mode.
- 11)Check all gauges.
- 12)Make sure that the BRAKE SYSTEM WARNING light turns off when the parking brake is released.

Once a week, or each time you fill your fuel tank or before a long distance driving (like highway driving), perform the following under-hood checks:

- 1) Engine oil level
- 2) Coolant level
- 3) Brake fluid level
- 4) Battery fluid (acid) level
- 5) Windshield washer fluid level
- 6) Hood latch operation
 - Pull the hood release handle inside the

vehicle. Make sure that you cannot open the hood all the way without releasing the secondary latch. Be sure to close the hood securely after checking for proper latch operation. See the item "All latches, hinges and locks" of "CHASSIS AND BODY" in "Periodic Maintenance Schedule" in "INSPEC-TION AND MAINTENANCE" section for lubrication schedule.

Make sure the hood is fully closed and latched before driving. If it is not, it can fly up unexpectedly during driving, obstructing your view and resulting in an accident.

Once a month, or each time you fill your fuel tank or before a long distance driving (like highway driving), check the tire pressure using a tire pressure gauge. Also check the tire pressure of the spare tire.

Engine Oil Consumption

It is normal for the engine to consume some engine oil during normal vehicle operation.

The amount of engine oil consumed depends on viscosity and quality of the oil and your driving conditions.

More oil is consumed during high-speed driving and when there is frequent acceleration and deceleration. Under high loads, your engine also will consume more oil. A new engine also consumes more oil, since its pistons, piston rings and cylinder walls have not yet become conditioned. New engines reach the normal level of oil consumption only after approximately 5000 km driving.


Oil consumption:

Max. 1.0 L per 1000 km

When judging the amount of oil consumption, note that the oil may become diluted and it is difficult to judge the accurate oil level.

As an example, if a vehicle is used for repeated short trips, and consumes a normal amount of oil, the dipstick may not show any drop in the oil level at all, even after 1000 km or more of driving. This is because the oil is gradually becoming diluted with fuel or moisture, making it appear that the oil level has not changed. You should also be aware that the diluting ingredients evaporate out when the vehicle is subsequently driven at high speeds, such as on an expressway, making it appear that oil is excessively consumed after high-speed driving.


Ignition Switch (Vehicle without Keyless Push Start System)



65D611S

A WARNING


To avoid possible injury, do not operate controls by reaching through the steering wheel.



The ignition switch has the following four positions:

LOCK

This is the normal parking position. It is the only position in which the key can be removed.



• **Manual Transmission vehicles** You must push in the key to turn it to LOCK position. It locks the ignition, and prevents normal use of the steering wheel after the key is removed.

Automatic Transmission vehicles

The gearshift lever must be in P (Park) position to turn the key to LOCK position. It locks the ignition and prevents normal use of the steering wheel and gearshift lever.

To release the steering lock, insert the key and turn it clockwise to one of the other positions. If you have trouble turning the key to unlock the steering wheel, try turning the steering wheel slightly to the right or left while turning the key.

ACC

Accessories such as the radio can operate, but the engine is off.

ON

This is the normal operating position. All electrical systems are on.

START

This is the position for starting the engine using the starter motor. The key should be released from this position as soon as the engine starts.

Ignition key reminder

A buzzer sounds intermittently to remind you to remove the ignition key if it is in the ignition switch when the driver's door is opened.

EXAMPLE



A WARNING

- Never return the ignition switch to the LOCK position and remove the ignition key while the vehicle is moving. The steering wheel will lock and you will not be able to steer the vehicle.
- Always return the ignition switch to LOCK position and remove the ignition key when leaving the vehicle even only for a short time. Also do not leave children alone in a parked vehicle. Unattended children may be able to start the vehicle or shift the transmission into neutral, which could result in an accident. There is also a danger that children may injure themselves by playing with the power windows or other moving features of the vehicle. In addition, heat built-up or extremely cold temperatures inside the vehicle can be fatal to children.

NOTICE

- Do not use the starter motor for more than 12 seconds at a time. If the engine does not start, wait 15 seconds before trying again. If the engine does not start after several attempts, check the fuel and ignition systems or consult a Maruti Suzuki authorised workshop.
- Do not leave the ignition switch in ON position if the engine is not running as the lead-acid battery will discharge.

NOTICE

If you stop the engine while the vehicle is in motion, the automatic transmission may be damaged. Avoid stopping the engine while driving. Engine Switch (Vehicle with Keyless Push Start System) (if equipped)

EXAMPLE



LOCK (OFF)

This mode is for parking the vehicle. When this mode is selected by pressing the engine switch and then any door (including the tailgate) is opened or closed, the steering will be locked automatically.

ACC

Press the engine switch to select this ignition mode to use such electric equipment as the audio system, outside rearview mirrors and accessory socket with the engine off. When this position is selected, the "ACC" indicator light in the instrument cluster comes on. Refer to "Warning and Indi-

cator Lights" in "BEFORE DRIVING" section for details.

ON

· With the engine off

You can use such electric equipment as the power windows and wipers with the engine off. When this ignition mode is selected by pressing the engine switch, the Ignition "ON" indicator light in the instrument cluster will come on.

· With the engine on

All electric equipment is operational. The vehicle can be driven when you have selected this ignition mode by pressing the engine switch.

START

Manual Transmission – Provided you have the keyless push start system remote controller with you, the engine automatically starts when you press the engine switch to select this ignition mode after shifting to "N" (Neutral) and depressing the brake and clutch pedals.

Automatic Transmission – Provided you have the keyless push start system remote controller with you, the engine automatically starts when you press the engine switch to select this ignition mode after placing the gearshift lever in P position and depressing the brake pedal. (If you need to re-start the engine while the vehicle is moving, shift into "N".) NOTE: You do not need to keep the engine switch pressed to start the engine.

NOTICE

Do not leave the engine switch in "ACC" or "ON" mode when the engine is not running. Avoid using the radio or other electric accessories for a long time when the engine switch is in the "ACC" or "ON" mode when the engine is not running, otherwise the lead-acid battery may discharge.

NOTE:

- The steering lock may not be released and the immobilizer/ keyless push start system warning light turns on if some load is applied on the steering wheel. If this happens, turn the steering wheel to the right or left to relieve it from the load before you press the engine switch again to change to the desired ignition mode.
- In the presence of strong radio wave or noise, you may not be able to change the ignition mode to "ACC" or "ON" or to start the engine using the engine switch.

Keyless Push Start System (if equipped)

Provided the keyless push start system remote controller is within the interior workable area (refer to the related explanation in this section), you can use the engine switch for starting the engine and selecting an ignition mode ("ACC" or "ON"). In addition, the following functions can be used:

- Keyless entry function. Refer to "Keyless entry system transmitter /Keyless push start system remote controller (if equipped)" in "BEFORE DRIVING" section for details.
- Locking and unlocking doors (including the tailgate) using a request switch. Refer to "Keyless entry system transmitter /Keyless push start system remote controller (if equipped)" in "BEFORE DRIVING" section for details.
- Immobilizer (anti-theft) function. Refer to "Immobilizer System" in "BEFORE DRIVING" section for details.

Engine Switch Illumination

The engine switch is illuminated (lit) in the following situations:

- When the engine is off and the driver's door is open, or for 15 seconds after the driver's door is closed. The illumination will fade out after 15 seconds passed.
- When the engine is off and the position lights are on. The illumination will go out when the position lights are turned off.

Selection of Ignition Modes • When the engine is on and the position Manual Transmission Press the engine switch to select "ACC" or lights and/or the headlights are on. The illumination will go out when the position "ON" mode as follows when you use an lights and the headlights are turned off. electric accessory or check the operation of instruments without running the engine. **EXAMPLE** 1) Bring the keyless push start system remote controller with you and sit in the LOCK ACC ON driver's seat. 2) Manual Transmission – Without (Audio equipment) (OFF) depressing the clutch pedal, press the ENGINE engine switch (1). START Automatic Transmission - Without STOP depressing the brake pedal, press the engine switch (1). 68PH00322 EXAMPLE **Automatic Transmission** 82K253 Gearshift lever in NOTE: To save the lead-acid battery, the illumina-ENGINE tion will be automatically turned off when STA/ both of the following conditions are simul-ST LOCK ACC taneously met: · The headlights and position lights are (1)

the ignition mode changes as follows.

- turned off. 15 minutes has elapsed since opening
- the driver's door.

(Audio equipment) (OFF) Gearshift lever in a position other than 82K254 Every time you press the engine switch,

57L31006

3-6


NOTE:

3-7

 Automatic Transmission – If the gearshift lever is in any position other than "P", or if the knob button is pushed when the gearshift lever is in P position, the ignition mode cannot be returned to "LOCK" (OFF).

If the "PUSH" indicator light blinks and the ignition modes cannot be selected

Your keyless push start system remote controller may not be sensed as being within the "interior workable area" (refer to the related explanation in this section). Try again after making sure you have the remote controller with you. If the ignition modes still cannot be selected, the battery of the remote controller may be discharged. To be able to select an ignition mode, you must then use the following method:



- 1) Without depressing the brake pedal and the clutch pedal, push the engine switch (1).
- Within about 10 seconds during which the "PUSH" indicator light in the instrument cluster is blinking, touch the engine switch with the LOCK button end of the remote controller (2) for about 2 seconds.

NOTE:


- If you still cannot select the ignition modes, there may be some problems with the keyless push start system. Contact a Maruti Suzuki authorised workshop for an inspection of the system.
- The immobilizer/keyless push start system warning light come on for about 5 seconds while the "PUSH" indicator light is blinking. Refer to "Warning and Indicator Lights" in "BEFORE DRIVING" section for details.
- You may customize the system to cause the interior buzzer to sound once for the "remote controller out of sensing range" warning. To incorporate this customization, please contact a Maruti Suzuki authorised workshop.
- If the battery of the remote controller is about to become completely discharged, the keyless push start system remote controller battery consumption warning light in the instrument cluster will come on for a few seconds when you press the engine switch to change the ignition mode to "ON". Refer to "Keyless Push Start System

Remote Controller Battery Consumption Warning Light" in "Keyless Entry System Transmitter/Keyless Push Start System Remote Controller (if equipped)" in "BEFORE DRIVING" section for details. For details on replacing the battery, refer to "Keyless Entry System Transmitter/Keyless Push Start System Remote Controller (if equipped)" in "BEFORE DRIVING" section.

"Remote Controller Outside" Warning

When either of the conditions described below is met, the system causes a "Remote Controller Outside" warning by sounding the interior and exterior buzzers. At the same time, the immobilizer/keyless push start system warning light blinks.

- Any door is opened and then closed while the remote controller is not inside the vehicle and the engine is running or the ignition mode has been changed to "ACC" or "ON" by pressing the engine switch.
- The remote controller is not inside the vehicle when you attempt to start the engine after changing the ignition mode to "ACC" or "ON" by pressing the engine switch.



(1) Immobilizer/keyless push start system warning light (blinks)

NOTE:


- If the warning is given, relocate the remote controller as soon as possible.
- Any attempt to start the engine will fail while the warning is active. Blinking of the immobilizer/keyless push start system warning light in the instrument cluster will indicate this condition. Refer to "Warning and Indicator Lights" in "BEFORE DRIVING" section for details.
- Blinking of the immobilizer/keyless push start system warning light should stop shortly after the remote controller is brought back inside the vehicle. If the immobilizer/keyless push start system warning light does not stop blinking, change the ignition mode to "LOCK" (OFF) by pressing the engine switch and

then perform the engine starting operation.

• Always keep the remote controller with you as the driver.

Interior Workable Area for Engine Starting, Ignition Mode Selection and "Remote Controller Outside" Warning

EXAMPLE



(1) Interior workable area

The "interior workable area" for these functions is defined as all the interior spaces except for the space above the instrument panel.

NOTE:


 Even when the remote controller is in the "interior workable area", if it is in any of the following conditions, you may not be able to start the engine or select the igni-

OPERATING YOUR VEHICLE

tion modes, and the "remote controller outside" warning may be given.

- -The remote controller's battery is low.
- -The remote controller is affected by strong radio signals or noise.
- -The remote controller is in contact with or covered by a metallic object.
- -The remote controller is in stowage like the glove box or a door pocket.
- -The remote controller is in the sun visor pocket or on the floor.
- Even when the remote controller is outside the "interior workable area", if it is in any of the following conditions, you may be able to start the engine or select the ignition mode. The "remote controller outside" warning may not be given at that time.
- -The remote controller is outside the vehicle but very close to a door.
- The remote controller is on the instrument panel.

Parking Brake Lever



(1) To set

(2) To release (3) To release

The parking brake lever is located between the front seats. To set the parking brake, depress the brake pedal and pull the parking brake lever all the way up. To release the parking brake, depress the brake pedal and pull up slightly on the parking brake lever, push the button on the end of the lever with your thumb, and lower the lever to its original position.

For automatic transmission vehicles, always set the parking brake before moving the gearshift lever to P (PARK) position. If you park on an incline and shift into "P" before setting the parking brake, the weight of the vehicle may make it difficult to shift out of " $\ensuremath{\mathsf{"P}}\xspace$ when you are ready to drive the vehicle.

When preparing to drive the vehicle, move the gearshift lever out of P position before releasing the parking brake.

WARNING

- Never drive your vehicle with the parking brake on: rear brake effectiveness can be reduced from overheating, brake life may be shortened, or permanent brake damage may result.
- If the parking brake does not hold the vehicle securely or does not fully release, have your vehicle inspected immediately by a Maruti Suzuki authorised workshop.
- When parking on an uphill, turn the steering wheel so that the front wheels point to the center of the road.
- When parking on a downhill, turn the steering wheel so that the front wheels point to the curb.

Whenever parking, make sure the gearshift lever for manual transmission vehicles is in 1st gear or "R" (Reverse) and the gearshift lever for automatic transmission vehicles is in "P" (Park). Remember, even though the transmission is in gear or in Park, you must set the parking brake fully.

WARNING

When parking the vehicle in extremely cold weather, the following procedure should be used:

- 1) Set the parking brake.
- 2) Manual Transmission turn off the engine, then shift into reverse or first gear.

Automatic Transmission - shift into "P" (Park) and turn off the engine.

- Get out of the vehicle and put chocks under the wheels.
- 4) Release the parking brake.
- When you return to your vehicle, you must remember to first set the parking brake, then remove the wheel chocks.

WARNING

Do not leave cigarette lighters, spray cans, soft drink cans or plastic articles (such as glasses, CD cases, etc.) in sun-heated vehicle. The temperature inside the vehicle may cause as follows:


- Gas may leak from a cigarette lighter or spray can and may lead to a fire.
- The glasses, plastic cards or CD cases, etc. may deform or crack.
- Soft drink cans may fracture.

Parking Brake Reminder Buzzer


A buzzer sounds intermittently to remind you to release the parking brake if you start the vehicle without fully releasing the parking brake. Make sure that the parking brake is fully released and the brake system warning light turns off.

Pedal

Manual Transmission



Automatic Transmission



80J2122

Clutch Pedal (1)

(for manual transmission) A clutch pedal is used to disengage the driving force to the wheels when starting the engine, stopping, or shifting the gearshift lever. Depressing the pedal disen-

Do not drive with your foot resting on the clutch pedal. It could result in excessive clutch wear, clutch damage, or unexpected loss of engine braking.

Brake Pedal (2)

gages the clutch.

Your vehicle is equipped with front disc brakes and rear drum brakes. Depressing the brake pedal applies both sets of brakes.

You may hear occasional brake squeal when you apply the brakes. This is a normal condition caused by environmental factors such as temperature, humidity, snow or dust, etc.

Automatic Transmission – You may hear occasional sound when you release brake pedal while vehicle is in "D" (Drive) mode and about to move. This is a normal phenomenon.

3-10

If brake squeal is excessive and occurs each time the brakes are applied, you should have the brakes checked by a Maruti Suzuki authorised workshop.


Do not apply brakes continuously or rest your foot on the brake pedal. This will result in overheating of the brakes which could cause unpredictable braking action, longer stopping distances, or permanent brake damage.

Accelerator Pedal (3)

An accelerator pedal controls the speed of the engine. Depressing the accelerator pedal increases power output and speed.

Starting the Engine (Vehicle without Keyless Push Start System)

Before Starting the Engine



72RM03001

 Make sure the parking brake is set fully.
 Manual Transmission – Shift into "N" (Neutral). Hold the clutch pedal and brake pedal fully depressed. Automatic Transmission – If the gearshift lever is not in P (Park) position, shift into "P" (Park). (If you need to restart the engine while the vehicle is moving, shift into "N".)

NOTE:

Automatic Transmission vehicles have a starter interlock device which is designed to keep the starter from operating if the

Transmission is in any of the drive positions.

WARNING

Make sure that the parking brake is set fully and the Transmission is in Neutral (or Park for vehicles with an automatic transmission) before attempting to start the engine.

Starting a Cold and Warm Engine

With your foot taken off the accelerator pedal, crank the engine by turning the ignition key to "START". Release the key when the engine starts.


NOTICE

Stop turning the starter immediately after the engine has started or the starter system can be damaged.
Do not crank the engine for more than 12 seconds at a time. If the engine does not start on the first try, wait 15 seconds before trying again.

If the engine does not start after 12 seconds of cranking, wait 15 seconds, and then press down the accelerator pedal to 1/3 of its stroke and try cranking the engine again. Release the key and accelerator pedal when the engine starts.


If the engine still does not start, depress the accelerator pedal all the way to the floor while cranking. Starting the Engine (Vehicle with Keyless Push Start System)

Before Starting the Engine



- 1) Make sure the parking brake is set fully.
- Manual Transmission Shift to "N" (Neutral) and fully depress the clutch pedal. Ho the clutch and brake pedals fully depressed.

Automatic Transmission – If the gearshift lever is not in the P (Park) position, shift it to "P". Hold the brake pedal fully depressed.



 The "PUSH" indicator light in the instrument cluster will come on. Push the engine switch (1). When the engine is started, the starter motor will automatically stop.

WARNING

Make sure that the parking brake is set fully and the transmission is in Neutral (or Park for vehicles with an automatic transmission) before attempting to start the engine.

3-12

NOTICE

- Do not depress the accelerator during the engine starting procedure.
- If the engine does not respond when you try to start it with the engine switch or if the engine switch repeats cycling through "LOCK"(OFF) - "ACC" - "ON" mode, the lead-acid battery may be discharged. Check the voltage of the lead-acid battery before trying again.

NOTE:

- You do not need to keep the engine switch pressed to start the engine.
- The engine of a manual transmission vehicle will not start unless the clutch pedal is depressed.
- Automatic transmission vehicles have a starter interlock device which is designed to keep the starter from operating if the transmission is in any of the drive positions.
- You should turn off such loads as the headlights and air conditioning system to facilitate starting of the engine.
- Even if you fail to start the engine, the starter motor will stop turning automatically after a short time. After the starter motor has stopped or if there is some problem with the system, the starter

motor will rotate only while the engine switch is being pressed.

Stopping the Engine

- Depress the engine switch to stop the engine after the vehicle stopped completely.
- In case of emergency, you can stop the engine by quickly pushing the engine switch more than 3 times, or pushing and holding the engine switch for more than 2 seconds while the vehicle in motion.

NOTE:

Except in cases of emergency, do not stop the engine while the vehicle is in motion. The steering and braking operation will require more effort when the engine is stopped.

Refer to "Braking" in this section.

NOTICE

If you stop the engine while the vehicle is in motion, the automatic transmission may be damaged. Avoid stopping the engine while driving.

 If the engine remains stopped for while after it was stopped unexpectedly or was raced before stopping, a clicking sound may be heard from around the engine when it is restarted. This is not a malfunction. Always let the engine idle before stopping it.

Starting a Cold and Warm Engine

With your foot taken off the accelerator pedal, crank the engine by pressing the engine switch to change the ignition mode to "START".

NOTICE

Do not crank the engine for more than 12 seconds at a time. If the engine does not start on the first try, wait 15 seconds before trying again.


After pressing the engine switch to change the ignition mode to "START", the starter cranks the engine for about 12 seconds before it can start the engine. If the engine fails to start at the first attempt, wait 15 seconds, and then try again while keeping the engine switch pressed while pressing down the accelerator pedal to 1/3 of its stroke. Release the accelerator pedal when the engine starts.

If the engine still does not start, try holding the accelerator pedal all the way to the floor while cranking.

If you are unable to start the engine using this procedure, consult a Maruti Suzuki authorised workshop.

If the "PUSH" indicator light blinks and the engine cannot be started

Your keyless push start system remote controller may not be sensed as being within the interior workable area. Try again after checking that you have the remote controller with you. If the engine still cannot be started, the battery of the remote controller may be discharged. To start the engine, use the following method:



52RM30020

- 1) Make sure the parking brake is set fully.
- Manual Transmission Shift to "N" (Neutral) and fully depress the clutch pedal. Hold the clutch and brake pedals fully depressed.

Automatic Transmission – If the gearshift lever is not in the P (Park) position, shift it to "P". Hold the brake pedal fully depressed.

- The "PUSH" indicator light in the instrument cluster will come on. Press the engine switch (1).
- Within about 10 seconds of blinking of the "PUSH" indicator light in the instrument cluster, touch the engine switch with the LOCK button end of the remote controller (2) for about 2 seconds.
- If you still cannot start the engine after several attempts using the above method, there may be a problem elsewhere, such as a low battery. Contact a Maruti Suzuki authorised workshop for inspection.
- The immobilizer/keyless push start system warning light will come on for about 5 seconds while the "PUSH" indicator light is blinking.
- You may customize the system to cause the interior buzzer to sound once for warning that remote controller is out of sensing range. Please contact a Maruti Suzuki authorised workshop for the customization.
- If the battery of the remote controller is about to become completely discharged, the keyless push start system remote controller battery consumption warning light in the instrument cluster will come on for a few seconds when you press the engine switch to change the ignition mode to "ON". For details on replacing the battery, refer to "Keyless Entry System Transmitter/Keyless Push Start Sys-

tem Remote Controller (if equipped)" in "BEFORE DRIVING" section.

3-14

Returning the Ignition Mode to "LOCK" (OFF)

Automatic Transmission – To ensure safety, the ignition mode can be returned to "LOCK" (OFF) by pressing the engine switch only when the gearshift lever is placed in P position without pressing the knob button.

NOTE:

In the case of an automatic transmission model, the ignition mode cannot be returned to "LOCK" (OFF) mode if the gearshift lever is in any other position than "P".

Certain problems like a fault in engine system may prevent the engine switch from going back to "LOCK" (OFF) mode. If this happens, have the vehicle inspected by a Maruti Suzuki authorised workshop after doing the following:

- Lock the doors using the key to prevent theft. (The request switches and the keyless push start system remote controller cannot be used to lock them.)
- Disconnect the negative cable from the lead-acid battery to prevent discharge.

"LOCK" (OFF) mode reminder buzzer If the driver's door is opened without returning the ignition mode to "LOCK" (OFF) by pressing the engine switch, a buzzer sounds to warn you of this state.

- If you open the driver's door after pressing the engine switch to change the ignition mode to "ACC", the interior buzzer beeps intermittently.
- The buzzer will stop sounding if you then push the engine switch twice, thus bringing it back the ignition mode to "LOCK" (OFF).

NOTE:

Whenever you leave the vehicle, make sure you have returned the ignition mode to "LOCK" (OFF) using the engine switch and then lock the doors. Without returning the ignition mode to "LOCK" (OFF), you cannot use a request switch or keyless push start system remote controller to lock the doors.

Steering lock warning buzzer

If the steering lock fails to engage due to a fault in the system when the ignition mode is turned to "LOCK" (OFF) by pressing the engine switch and any door (including the tailgate) is opened or closed, the interior buzzer will warn you of this condition with repeated short beeps. If this happens, have the vehicle inspected by a Maruti Suzuki authorised workshop.

Using the Transmission


A WARNING

Do not hang any items on the gearshift lever and do not use the gearshift lever as a handrest. Otherwise, it could prevent proper operation of the gearshift lever and cause its malfunction, resulting in an accident.

Manual Transmission

MT model

EXAMPLE



Starting off

To start off, depress the clutch pedal all the way to the floor and shift into 1st gear. After releasing the parking brake, gradually release the clutch. When you hear a change in the engine's sound, slowly press

the accelerator while continuing to gradually release the clutch.

Shifting

All forward gears are synchronized, which provides for quiet and easy shifting. Always depress the clutch pedal all the way to the floor before shifting gears. Ke ep the engine speed below the red zone of the tachometer.

Downshifting maximum allowable speeds

MT model

Downshifting	km/h
2nd to 1st	20
3rd to 2nd	80
4th to 3rd	115
5th to 4th	155*

*NOTE:

You may not accelerate to the maximum allowable speed because of the driving situation and/or the vehicle condition.

NOTICE

Do not downshift to a lower gear at the speed faster than the maximum allowable speeds for the next lower speed, or severe damage to engine and transmission can result.

WARNING

- Reduce your speed and downshift to a lower gear before going down a long or steep hill. A lower gear will allow the engine to provide braking. Avoid riding the brakes or they may overheat, resulting in brake failure.
- When driving on slippery roads, slow down before downshifting. Excessive and/or sudden changes in engine speed may cause loss of traction, which could cause you to lose control.

NOTICE

Before engaging reverse gear [R], check that the vehicle is completely stationary and gear lever is in neutral [N] position. After depressing clutch pedal fully, shift to [R].

NOTE:

If it is difficult to engage reverse gear [R], follow below procedure.


- 1. Put gear lever in neutral [N].
- 2. Release clutch pedal once.

3. Again depress the clutch pedal and shift from [N] to [R].

NOTICE


- To help avoid clutch damage, do not use the clutch pedal as a footrest while driving or use the clutch to keep the vehicle stationary on a slope. Depress the clutch fully when shifting.
- When shifting or starting off, do not race the engine. Racing the engine can shorten engine life and cause negative effect to smooth shifting.

4-Speed Automatic Transmission



(1) Overdrive off switch

3-16




The 3-speed mode is suitable for the following driving conditions:

- Driving on hilly, winding roads
- You can drive more smoothly with less frequent gear changing
- Going down a steep hill
- Some engine braking is provided

Gearshift lever

EXAMPLE




(1) knob button

The gearshift lever is designed so that it cannot be shifted out of P position unless the ignition switch is in "ON" position or the ignition mode is "ON" and the brake pedal is depressed.

WARNING

Always depress the brake pedal before shifting from "P" (Park) (or "N" (Neutral) if the vehicle is stationary) to a forward or reverse gear, to help prevent the vehicle from moving unexpectedly when you shift.

The gearshift lever has a lock mechanism to help prevent accidental shifting. To shift the gearshift lever:



NOTE:

73R0069

- Always shift the gearshift lever without pushing in the knob button (1) except when you shift from "P" to "R", from "D" to "2", from "2" to "L", from "N" to "R" or from "R" to "P". If you always push in the knob button (1) when shifting the gearshift lever, you could shift into "P", "R", "2", or "L" by mistake.
- If driver's or passenger's knee hits the gearshift lever while driving, the lever

Overdrive off switch

The transmission is a 4-speed (3-speed plus overdrive) automatic transmission. By operating the overdrive off switch, the transmission can be converted to a 3-speed automatic transmission that will not move to the overdrive position. To convert the transmission to the 3-speed mode, push in the overdrive off switch and release it.

To return the transmission to the 4-speed mode, push in the overdrive off switch again.

When the ignition switch is turned to ACC position or the engine switch is pressed to change the ignition mode to "ACC", the transmission in the 3-speed mode is converted to the 4-speed mode automatically.

3-17

could move and the gear could be changed unexpectedly.

Use the gearshift lever positions as described below:

P (Park)

Use this position to lock the transmission when the vehicle is parked or when starting the engine. Shift into Park only when the vehicle is completely stationary.

R (Reverse)

Use this position to reverse the vehicle from stop. Make sure that vehicle is completely stationary before shifting into Reverse.

N (Neutral)

Use this position for starting the engine if the engine stalls and you need to restart it while the vehicle is moving. You may also shift into Neutral and depress the brake pedal to hold the vehicle stationary during idling.

D (Drive)

Use this position for all normal driving.

With the gearshift lever in "D" range you can get an automatic downshift by pressing the accelerator pedal. The higher the vehicle speed is, the more you need to press the accelerator pedal to get a downshift.

2 (Low 2)

Use this position to provide extra power when climbing hills, or to provide engine braking when going down hills.

L (Low 1)

Use this position to provide maximum power when climbing steep hills or driving through deep snow or mud, or to provide maximum engine braking when going down steep hills.

NOTE:

If you move the gearshift lever to a lower gear while driving faster than the maximum allowable speed for the lower gear, the transmission will not actually downshift until your speed drops below the maximum speed for the lower gear.

NOTICE

- Do not shift the gearshift lever into "R" while moving forward, or the transmission may be damaged. If you shift into "R" when the vehicle speed is over 11 km/h, the transmission will not shift into reverse.
- Be sure to take the following precautions to help avoid damage to the automatic transmission:


(Continued)

NOTICE

(Continued)

- Make sure that the vehicle is completely stationary before shifting into "P" or "R".
- Do not shift from "P" or "N" to "R", "D", "2", or "L" when the engine is running above idle speed.
- Do not rev the engine with the transmission in a drive position ("R", "D", "2", or "L") and the front wheels not moving.
- Do not use the accelerator to hold the vehicle on a hill. Use the vehicle's brakes.

If You Cannot Shift Automatic Transmission Gearshift Lever Out of "P" (PARK)





Vehicles with an automatic Transmission have an electrically operated park-lock feature. If the vehicle's lead-acid battery is discharged, or there is some other electrical failure, the automatic Transmission cannot be shifted out of Park in the normal way. Jump starting may correct the condition. If not, follow the procedure described below. This procedure will permit shifting the transmission out of Park.

- 1) Be sure the parking brake is firmly applied.
- 2) If the engine is running, stop the engine.
- Make sure the key is in ON or ACC position, or the ignition mode is "ON" or "ACC".
- 4) With the release button (1) pushed, push the knob button (2) and shift the gearshift lever to the desired position.

This procedure is for emergency use only. If repeated use of this procedure is necessary, or the procedure does not work as described, take the vehicle to a Maruti Suzuki authorised workshop for repair.

Gearshift Indicator (if equipped)

EXAMPLE



When the gearshift lever is in a position other than "N" (Neutral), the gearshift indicator is indicated on the information display when the ignition switch is in "ON" position or the ignition mode is "ON".

The electronic control system monitors driving condition (such as vehicle speed and/or engine revolution), and it shows which gear position is optimal for your driving with the indication on the display.

Vehicle with instrument cluster (Type A) If UP/DOWN arrow and the gear position other than currently selected are indicated on the display while driving, we recommend you to shift up or down the gear to indicated position. It is the optimal gear position for a driving condition that reduces the over revolution and stress to the engine, and improves fuel consumption. Vehicle with instrument cluster (Type B) If UP/DOWN arrow is indicated on the display while driving, we recommend you to shift up or down the gear until the arrow disappears. It is the optimal gear position for a driving condition that reduces the over revolution and stress to the engine, and improves fuel consumption.

For details on how to use the transmission, refer to "Using the Transmission" in this section.

WARNING

The gearshift indicator is designed to indicate optimal gear position for your driving, however, a driver will not be relieved from the duty of care of driving operation or gear change with this indicator.

To drive safe, do not gaze the gearshift indicator, pay attention to your driving situation and shift up or down if necessary.

NOTE:

72R0074

- The gearshift indicator is not indicated when the gear position is in "N" (Neutral).
- If you depress the clutch pedal while UP/ DOWN arrow is indicated, the indication will disappear.
- If you release your foot from the accelerator pedal while UP arrow is indicated, the indication will display the currently

selected gear position for vehicle with the instrument cluster (Type A), or UP arrow will disappear for vehicle with the instrument cluster (Type B).

• The indication of gearshift indicator timing may differ depending on the vehicle condition and/or driving situation even in the same vehicle speed and engine revolution.

Example of the gearshift indicator

Indication	Description
^ 4	 Lower gear position is selected for the vehicle speed and/or engine revolution. Changing to a higher gear position is recommended. In this case, shifting up to 4th gear position is recommended.
• 3	Current gear position is optimal for the vehicle speed and/or engine revolution. • In this case, 3rd gear position is the best.
-2	 Higher gear position is selected for the vehicle speed and/or engine revolution. Changing to a lower gear position is recommended. In this case, shifting down to 2nd gear position is recommended.

Smart Hybrid (Vehicle with instrument cluster (Type A)) (if equipped)

Smart Hybrid has an Integrated Starter Generator (ISG) instead of conventional generator to get a better fuel consumption.

Integrated Starter Generator (ISG) is a generator which incorporated a motor function.

The ISG has the following 3 functions.

- Deceleration energy regenerating function
- Engine power assist function
- Starter motor function

Deceleration Energy Regenerating Function

While decelerating your vehicle, the ISG generates electricity without engine power. This reduces engine loads and improves fuel consumption.

While decelerating your vehicle, deceleration energy regenerating function will be activated when the following conditions are satisfied.

- Gearshift lever is not in "N" (Neutral).
- · Clutch pedal is not depressed.
- · Engine speed is more than 950 rpm.
- Inside temperature of lead-acid battery is in normal condition.
- Lithium-ion battery is not fully charged and inside temperature is in normal condition etc.

3-20

NOTE:

The deceleration energy regenerating function may not work depending on vehicle conditions.

Engine Power Assist Function

While the vehicle is running, ISG assists engine power as a motor in the following limited condition. This reduces engine loads and improves fuel consumption.

While the vehicle is running with the engine speed at approximately 2500 rpm or less, engine power assist function will be activated when all of the following conditions are satisfied.

- Smart Hybrid system and ENG A-STOP system are working properly. ("ENG A-STOP OFF" indicator light is not blinking.)
- Clutch pedal is not depressed.
- ESP[®] (if equipped) is not activated.
- Accelerator pedal is excessively depressed.
- · Lead-acid battery and lithium-ion batterv are fully charged and each inside temperature is in normal condition.
- Engine coolant temperature is in normal condition.
- · ISG inside temperature is in normal condition.

NOTE:

The engine power assist function may not work depending on vehicle conditions.

Starter Motor Function

After the engine auto stop by the ENG A-STOP system, the engine will be restarted using a cranking power of the ISG.

The starting with the ISG is guiet compared with starting by the conventional starter motor.

NOTE:

When you restart the engine by pushing the engine switch, the conventional starter motor is used and you will hear a gear engagement sound.

"SHVS" Indicator Light



Smart Hybrid has an Integrated Starter Generator (ISG) instead of conventional generator to get a better fuel consumption.

Integrated Starter Generator (ISG) is a generator which incorporated a motor function.

The ISG has the following 3 functions.

- · Deceleration energy regenerating function
- Engine power assist function
- Starter motor function




operation of deceleration energy regenerating function, engine power assist function or starter motor function. Refer to "Warning and Indicator Lights" in the "BEFORE DRIVING" section for details.



Deceleration Energy Regenerating Function

EXAMPLE



While decelerating your vehicle, the ISG generates electricity without engine power. This reduces engine loads and improves fuel consumption.

While decelerating your vehicle, deceleration energy regenerating function will be activated when the following conditions are satisfied.


- Gearshift lever is not in "N" (Neutral).
- · Clutch pedal is not depressed.
- Engine speed is more than 950 rpm.
- Inside temperature of lead-acid battery is in normal condition.
- Lithium-ion battery is not fully charged and inside temperature is in normal condition etc.

NOTE:

The deceleration energy regenerating function may not work depending on vehicle conditions.

Engine Power Assist Function

EXAMPLE



72R0097

While the vehicle is running, ISG assists engine power as a motor in the following limited condition. This reduces engine loads and improves fuel consumption.

While the vehicle is running with the engine speed at approximately 4000 rpm or less, engine power assist function will be activated when all of the following conditions are satisfied.

- Smart Hybrid system and ENG A-STOP system are working properly. ("ENG A-STOP OFF" indicator light is not blinking.)
- · Clutch pedal is not depressed.

OPERATING YOUR VEHICLE


- ESP[®] (if equipped) is not activated.
- Accelerator pedal is excessively depressed.
- Lead-acid battery and lithium-ion battery are fully charged and each inside temperature is in normal condition.
- Engine coolant temperature is in normal condition.
- ISG inside temperature is in normal condition.

NOTE:

The engine power assist function may not work depending on vehicle conditions.

Starter Motor Function

EXAMPLE



72R0098

After the engine auto stop by the ENG A-STOP system, the engine will be restarted using a cranking power of the ISG.

The starting with the ISG is quiet compared with starting by the conventional starter motor.

NOTE:

When you restart the engine by pushing the engine switch, the conventional starter motor is used and you will hear a gear engagement sound.

Lithium-ion Battery Indication

EXAMPLE




72R0099

The segments in the lithium-ion battery indicator (1) give an approximate indication of the charge of the lithium-ion battery. The number of segments that appear in the indication increases or decreases with the charge of the lithium-ion battery.

NOTE:

The indicator gives an approximate indication. The indication may be delayed or differ from the actual charge of the lithium-ion battery under certain conditions, for example, when the outside temperature is low. Also, the minimum segment is 1 bar and the bar will never be 0. Even when 1 bar is shown, the battery level may be close to be flat.

ENG A-STOP OFF Light



If this indicator blinks when driving, there may be something wrong with the ENG A-STOP system or the Smart Hybrid system. You should have the system inspected by a Maruti Suzuki authorised workshop.

ENG A-STOP System (Engine Auto Stop Start System) (if equipped)

The ENG A-STOP system (engine auto stop start system) automatically stops the engine while waiting briefly at a traffic light, etc., and automatically restarts the engine afterward. This system helps reduce emissions, improve fuel consumption and lower engine noise.

This system stops the engine temporarily under specific conditions. Before parking the vehicle for an extended period of time or leaving the vehicle, properly apply the parking brake and stop the engine with the ignition switch or the engine switch.

Once the specific conditions are met, the engine will stop automatically after the vehicle has stopped. However, the engine will not be stopped automatically until confirmation of the system function is finished.

NOTE:

If your vehicle is equipped with the auto air conditioning system, you can change the automatic engine stop condition via the information display. Refer to "Information display" in "BEFORE DRIVING" section.

3-23

 Do not get out of the vehicle while the engine is automatically stopped by the ENG A-STOP system. Doing so may lead to an accident. Manual Transmission vehicle – If the driver's seat belt is unfas- tened or the driver's door is opened, the engine will restart. Automatic Transmission vehicle – If the driver's seat belt is unfas- tened, even if the brake pedal is pressed down, or the driver's door is opened, the engine will be restarted to warn you that the engine was stopped automati- cally by the ENG A-STOP system. If the engine does not restart auto- matically after having been stopped automatically by the ENG A-STOP system, push the engine switch to start the engine. Trying to move the vehicle when the engine has not yet restarted requires a strong force to turn the steering wheel or depress the brake pedal, potentially leading to an accident.

- Vehicle should not be left with ignition in ON or ACC position, or the ignition mode is "ON" or "ACC" for extended periods of time.
- Do not add any external electrical load to lithium-ion battery.

- The lithium-ion battery is maintenancefree.
- To replace or dispose of the lithium-ion battery, consult a Maruti Suzuki authorised workshop.

A WARNING

Wrong handling of the lithium-ion battery may result in fire, electric shock or system malfunction. Accordingly, observe the instructions listed below:

- Do not dismount or disassemble the lithium-ion battery.
- Do not let the lithium-ion battery come in contact with water or other liquids.
- Do not apply strong impact on the lithium-ion battery.
- Do not step on the lithium-ion battery or put articles on the lithiumion battery.
- Do not disconnect the lithium-ion battery terminals or draw power from the terminals for electrical products.

NOTE:

Lithium-ion battery, if not disposed in an eco-friendly manner and in accordance with the applicable laws, may pose safety and environmental hazard.

Maruti Suzuki ensures proper disposal of this battery through established channels in an eco-friendly manner. Owner shall return this lithium-ion battery to Maruti Suzuki authorized dealerships as soon as it is not fit for use in vehicle. Once the owner returns the lithium-ion battery, Maruti Suzuki will ensure proper disposal in compliance with the laws to avoid legal implications to owners.

If batteries are not returned to Maruti Suzuki, it will become owners' responsibility and accountability to ensure proper disposal in accordance with the applicable laws. Maruti Suzuki will not take any responsibility for consequences such as accidents or damages arising due to the abandonment, resale, inappropriate use, modification, dismantling and improper disposal of Lithium-ion battery.


Contact your nearby Maruti Suzuki authorized workshop to dispose the used lithium-ion battery. 'Battery Recycling Information' and necessary handling instructions are also affixed on the battery pack. For more information, connect Maruti Suzuki customer care.

Automatic Stopping/Restarting of the Engine

Manual transmission vehicle

1) With the brake pedal depressed, decelerate the vehicle.

EXAMPLE



72R0101

 After the vehicle has stopped with the clutch pedal depressed and the gearshift lever shifted to "N", and then release the clutch pedal, the engine will stop automatically.

The ENG A-STOP indicator light (green) (1) will come on.

- The ENG A-STOP system will not stop the engine automatically if all the automatic engine stop conditions are not met. For details, refer to the section, "Automatic engine stop conditions".
- During the automatic engine stop, the engine may shut down, accompanied

by an interior buzzer or restarted, to ensure safety.

For details, refer to the section, "Points to note during the automatic engine stop".


NOTICE

During the automatic engine stop, do not shift the gearshift lever to a position other than "N" without depressing the clutch pedal. If the gear shift lever is in a position other than "N", the engine will not restart automatically even if the clutch pedal is depressed.

NOTE:

The ENG A-STOP system will not operate and engine does not stop automatically under the following conditions:

- Engine auto stop function will be ready once the vehicle runs at a speed exceeding 3 km/h after restart of the engine.
- The audio and other electrical component can be used during the automatic engine stop, but the air conditioner will switch to the fan mode.
- If the vehicle is equipped with an auto air conditioner, the fan speed will be limited during the automatic engine stop (only in the auto control mode) to keep the cabin air-conditioned for a longer time.



 Regardless of whether the vehicle has stopped or not, depressing the clutch pedal will restart the engine and ENG A-STOP indicator light (green) (1) will go off.

While the engine is stopped automatically, depressing the clutch pedal will restart the engine consuming fuel. Therefore, for fuel economy, it is recommended to depress the clutch pedal just before the vehicle start.


- Without depressing the clutch pedal, the engine may restart automatically if the automatic engine restart conditions are met.
- For details, refer to the section, "Automatic engine restart conditions".

OPERATING YOUR VEHICLE

Automatic Transmission vehicle

1) With the brake pedal depressed, decelerate the vehicle.

EXAMPLE



 While depressing the brake pedal, place the gearshift lever in "D" or "N" position.

The ENG A-STOP indicator light (green) (1) will come on.

- The ENG A-STOP system will not stop the engine automatically if all the automatic engine stop conditions are not met. For details, refer to the section, "Automatic engine stop conditions".
- During the automatic engine stop, the engine may shut down, accompanied by an interior buzzer or restarted, to ensure safety.


For details, refer to the section, "Points to note during the automatic engine stop".

3-26

NOTE:

The ENG A-STOP system will not operate and engine does not stop automatically under the following conditions:

- Engine auto stop function will be ready once the vehicle runs at a speed exceeding 1 km/h after restart of the engine.
- The audio and other electrical component can be used during the automatic engine stop, but the air conditioner will switch to the fan mode.
- If the vehicle is equipped with an auto air conditioner, the fan speed will be limited during the automatic engine stop (only in the auto control mode) to keep the cabin air-conditioned for a longer time.



72R0147

 Remove your foot from the brake pedal. "ENG A-STOP" indicator light (green) (1) in the instrument cluster will be turned off and the engine will restart automatically.

When restarting the engine, keeping brake force temporarily prevents the vehicle from moving forward by the creeping function. Also, this prevents the vehicle from rolling downward on a hill. For details, refer to the section "Hill hold control system".

NOTE:

When the engine is restarted automatically, the following conditions may be found as the hill hold control system is activated, but this is not a malfunction.

- You may hear a sound from the engine room.
- As brake pedal becomes heavy, it may be difficult for you to depress it.

Points to note during the automatic engine stop

When the following operations are performed during the automatic engine stop, the engine may shut down, accompanied by an interior buzzer or restarted, to ensure safety.

- When the hood is opened, an interior buzzer will sound intermittently and the engine will come out of the automatic engine stop mode and shut down. The ENG A-STOP indicator light (green) will go off.
- When the driver releases the seat belt or opens the driver's door, the engine will restart automatically. The ENG A-STOP indicator light (green) will blink for approximately 5 seconds and then go off.
- During the automatic engine stop, if the gearshift lever is shifted to a position other than "N" without depressing the clutch pedal and open the driver's door with the driver's seat belt unfastened, an interior buzzer will sound and the engine will shut down without control of automatic engine stop. The ENG A-STOP indicator light (green) will go off.

NOTE:

The power steering warning light, oil pressure warning light and charge warning light on the meter panel do not come on during the automatic engine stop, but they will come on once the engine shuts down.

3-27

Actuation conditions for ENG A-STOP system

Standby conditions

When all of the following conditions are met while the vehicle is traveling, ENG ASTOP system will be permitted:

- The engine is started with the hood completely closed.
- The ENG A-STOP OFF switch has not been pressed to deactivate the ENG ASTOP system.
- The lead-acid battery and the lithium-ion battery are fully charged and the temperature inside the lead-acid battery or the lithium-ion battery is within the specified range (#1).
- The engine has warmed up and the engine coolant temperature is within the specified range.
- The driver is wearing seat belts.
- The driver's door is completely closed.
- The hood is completely closed.
- No electronically controlled system besides the ENG A-STOP system is issuing a signal to inhibit stopping of the engine (#2).

<Vehicle equipped with auto air conditioner>

- The temperatures at air-conditioner outlets are sufficiently low in the cooling mode or sufficiently high in the heating mode.
- The defroster is turned off.
- #1 If the vehicle has not been in use for an extended period of time or the audio or

other electrical component was used for an extended period of time while the engine was stopped, the lead-acid battery may have discharged and it may take some time before the standby mode is achieved.

#2 If any of the warning and indicator lights affecting the ENG A-STOP system come on, the engine will not be stopped automatically.

Automatic engine stop conditions

When all of the following conditions are met under the standby conditions, the engine will stop automatically after the vehicle has stopped:

- The gearshift lever is in "N" (Neutral) position (for manual transmission vehicle).
- The clutch pedal is released (for manual transmission vehicle).
- The vehicle has stopped.
- The accelerator pedal is not depressed.
- Neither the ABS nor ESP® is in operation.
- The negative pressure of the brake booster is normal.
- The vehicle is stopped on a steep hill (for automatic transmission vehicle).
- The gearshift lever is in a position other than "D" or "N" (for automatic transmission vehicle).
- When the vehicle has stopped without depressing the brake pedal (for automatic transmission vehicle).

OPERATING YOUR VEHICLE

Automatic engine restart conditions

If one of the following operations is performed or the vehicle enters one of the following modes during the automatic engine stop, the engine will restart automatically and the ENG A-STOP indicator light (green) will go off:

Common

- · The clutch pedal is depressed.
- The ENG A-STOP OFF switch is pressed to deactivate the ENG A-STOP system.
- The lead-acid battery or the lithium-ion battery has discharged substantially (#).
- A malfunction of the system is detected (#).
- The negative pressure of the brake booster has dropped (#).

<Vehicle equipped with auto air conditioner>


- The temperatures at air conditioner outlets have changed considerably after the automatic engine stop to the point of affecting the cooling/heating performance (#).
- The temperature selector has been turned considerably to the COOL side in the cooling mode or to the HOT side in the heating mode (#).
- The defroster is turned on (#).
- The accelerator pedal depressed (for automatic transmission vehicle) (#).
- The gearshift lever is put in "P" or "R" (for automatic transmission vehicle) (#).

- After the gearshift lever is shifted to "N", it is returned to "D" (for automatic transmission vehicle) (#).
- The driver releases the seat belt (#).
- The driver's door is opened (#).
- The vehicle starts to move on a slope, etc. (#).
- Some time (3 minutes or so) has elapsed after the start of the automatic engine stop (#).
- # The ENG A-STOP indicator light (green) will blink and then go off.

ENG A-STOP OFF Switch

The ENG A-STOP system can be deactivated.

- To deactivate the system, press the ENG A-STOP OFF switch (1) to turn on ENG A-STOP OFF light (2).
- To activate the system once again, press the switch (1) again to turn off the indicator.
- Every time the engine is stopped manually, the system is enabled again and the ENG A-STOP OFF light (2) goes off.



NOTE:

Pressing the ENG A-STOP OFF switch (1) during the automatic engine stop will restart the engine automatically and the ENG A-STOP OFF light (2) will come on.

ENG A-STOP OFF Light



This indicator comes on in the information display.

- This indicator comes on when the ENG A-STOP system is deactivated.
- The indicator blinks when the engine switch is pressed to change the ignition mode to ON, if one of the conditions listed below is met.

The ENG A-STOP system or the Smart Hybrid system does not actuate correctly while the indicator is blinking. Have the system inspected by a Maruti Suzuki authorised workshop.

- There may be something wrong with the ENG A-STOP system or the Smart Hybrid system.
- An engine component (ISG) or the lead-acid battery is due for replacement.

NOTE:

If the indicator blinks during the automatic engine stop, the engine may shut down.

3-29

Parking Sensors


Parking sensor system (Type A) (if equipped)

The parking sensor system uses ultrasonic sensors to detect obstacles near the rear bumper. If obstacles are sensed while you are parking or moving the vehicle slowly, the system warns you by sounding a buzzer.

- The system emits an ultrasonic wave and the relevant sensor detects the return of the wave reflected by an obstacle. The system measures the time taken by the ultrasonic wave to reach the obstacle and return from it, from which it determines the obstacle's position.
- The parking sensor function can be used when the ignition switch is turned "ON" or the engine switch is pressed to change the ignition mode to "ON", the gearshift lever is in R position. This function is helpful in the following cases: pulling over to the curb; parallel-parking the vehicle; steering the vehicle into a garage; driving along an alley; and moving slowly in a place with obstacles.

A WARNING

- The parking sensor warns you of obstacles with buzzers. However, you must still pay full attention yourself while driving.
- The sensors can detect obstacles only within a limited area and only when the vehicle is moving within a limited speed range. So, in tricky areas, you must move the vehicle slowly while checking around it using your direct vision or rearview mirrors. There is increased risk of an accident if you control the vehicle relying only on the parking sensor.



(1) Rear center sensors (2 places)(2) Rear corner sensors (2 places)


NOTICE

- Avoid hitting the sensor areas or directing the nozzle of a high-pressure car washer onto the sensor areas. Otherwise, the sensors may be damaged.
- If the bumper hits a hard object, the sensors on it may not work properly. If this occurs, have the sensors inspected by a Maruti Suzuki authorised workshop.

Working sensors The sensors work depending on the position of gearshift lever as shown in the below table:

Gearshift lever position		Manual Transmission		Automatic Transmission	
Gearstillt level	Gearshint level position		N, 1st - 5th	R	N, D, 2 or L
Rear sensors	Center	On	Off	On	Off
	Corner	On	Off	On	Off

Approximate areas where obstacles can be detected



- An obstacle within about 20 cm (8 in) from a sensor or just below a sensor is not detectable.
- The sensors can detect an obstacle up to about 1.5 m (5 ft) from the rear of vehicle.

3-31

A WARNING

 Under the following conditions, the parking sensor system may not work normally because the sensors cannot detect obstacles correctly.

- Sensors are covered with mud, ice or other materials. (Such materials must be removed for normal operation.)
- Sensors are wet from water splashes or heavy rain.
- Sensors are covered by a hand, sticker, accessory, etc.
- There is an accessory or other object attached within the sensor's sensing area.
- Items such as tow hooks, commercially available corner poles, radio antenna, etc. are installed on the bumper.
- The height of the bumper is changed due to alteration to the suspension or other causes.
- The sensor areas are extremely hot from direct sunlight or cold due to freezing weather.
- The vehicle is on a rough surface, slope, gravel road or grass field.
- The vehicle is at a steep angle. (Continued)

A WARNING

(Continued)

- Sensors have intercepted ultrasonic noise from another vehicle's horn, engine, air braking system (large vehicles), or parking sensor.
- Obstacles are too close to the sensors.
- Sensors are at an angle to a highly reflective object such as glass. (Ultrasonic waves are not reflected back from the obstacle.)
- Sensors may not be able to correctly detect the following types of obstacles:
- Objects made of a thin material like wire netting and ropes
- Square-shaped curbstones or other objects with sharp edges
- Tall objects with a large upper part like a road sign
- Low-profile objects such as curbstones
- Sound-absorbing objects such as cotton and snow

NOTE:

- Thin poles or obstacles lower than the sensors may become undetectable as the vehicle moves closer to them even if they have been detected from longer distances.
- The system may calculate the distance to a road sign or similar obstacle to be shorter than the actual distance.

3-32

Obstacle Indication by Parking Sensor

Upon detecting an obstacle, the parking sensor causes an interior buzzer to sound.

 A buzzer located behind the rear seat sounds when a sensor at the rear detects an obstacle.

· Warnings when obstacles such as wall are detected by corner sensors

Distance (approx.)	Buzzer
45 – 60 cm (18 – 24 in)	Short beeps at short intervals
35 – 45 cm (14 – 18 in)	Short beeps at very short intervals
Less than 35 cm (14 in)	Continuous beep

Warnings when obstacles such as wall are detected by center sensors

Distance (approx.)	Buzzer
60 – 150 cm (24 – 59 in)	Short beeps at long intervals
45 – 60 cm (18 – 24 in)	Short beeps at short intervals
35 – 45 cm (14 – 18 in)	Short beeps at very short intervals
Less than 35 cm (14 in)	Continuous beep

Warning and Indicator Messages

if there is a problem or warning on the parking sensor system, the buzzer sound intermittently. If the buzzer does not stop, there may be a problem with the parking sensor system. Have your vehicle inspected by a Maruti Suzuki authorised workshop


Parking sensor system (Type B) (if equipped)

The parking sensor system uses ultrasonic sensors to detect obstacles near the rear bumper. If obstacles are sensed while you are parking or moving the vehicle slowly, the system warns you by sounding a buzzer and displaying symbols representing the obstacles on the information display in the instrument cluster.

- The system emits an ultrasonic wave and the relevant sensor detects the return of the wave reflected by an obstacle. The system measures the time taken by the ultrasonic wave to reach the obstacle and return from it, from which it determines the obstacle's position.
- The parking sensor function can be used when the ignition switch is turned "ON" or the engine switch is pressed to change the ignition mode to "ON", the gearshift lever is in R position. This function is helpful in the following cases: pulling over to the curb; parallel-parking the vehicle; steering the vehicle into a garage; driving along an alley; and moving slowly in a place with obstacles.

Information Display Symbol

EXAMPLE




 (1) Symbol representing an obstacle detected by parking sensor*
 * This symbol shows that an obstacle is located on the right rear of vehicle.

A WARNING

The parking sensor warns you of obstacles with buzzers and by showing you the location of the obstacles on the information display. However, you must still pay full attention yourself while driving.
The sensors can detect obstacles only within a limited area and only when the vehicle is moving within a limited speed range. So, in tricky areas, you must move the vehicle

areas, you must move the vehicle slowly while checking around it using your direct vision or rearview mirrors. There is increased risk of an accident if you control the vehicle relying only on the parking sensor.



(1) Rear center sensors (2 places)(2) Rear corner sensors (2 places)


NOTICE

- Avoid hitting the sensor areas or directing the nozzle of a high-pressure car washer onto the sensor areas. Otherwise, the sensors may be damaged.
- If the bumper hits a hard object, the sensors on it may not work properly. If this occurs, have the sensors inspected by a Maruti Suzuki authorised workshop.

Working sensors The sensors work depending on the position of gearshift lever as shown in the below table:

Gearshift lever position		Manual Transmission		Automatic Transmission	
		R	N, 1st - 5th	R	N, D, 2 or L
Rear sensors	Center	On	Off	On	Off
	Corner	On	Off	On	Off

Approximate areas where obstacles can be detected



60MH126

- An obstacle within about 20 cm (8 in) from a sensor or just below a sensor is not detectable.
- The sensors can detect an obstacle up to about 1.5 m (5 ft) from the rear of vehicle.

3-35

A WARNING

 Under the following conditions, the parking sensor system may not work normally because the sensors cannot detect obstacles correctly.

- Sensors are covered with mud, ice or other materials. (Such materials must be removed for normal operation.)
- Sensors are wet from water splashes or heavy rain.
- Sensors are covered by a hand, sticker, accessory, etc.
- There is an accessory or other object attached within the sensor's sensing area.
- Items such as tow hooks, commercially available corner poles, radio antenna, etc. are installed on the bumper.
- The height of the bumper is changed due to alteration to the suspension or other causes.
- The sensor areas are extremely hot from direct sunlight or cold due to freezing weather.
- The vehicle is on a rough surface, slope, gravel road or grass field.
- The vehicle is at a steep angle. (Continued)

A WARNING

(Continued)

- Sensors have intercepted ultrasonic noise from another vehicle's horn, engine, air braking system (large vehicles), or parking sensor.
- Obstacles are too close to the sensors.
- Sensors are at an angle to a highly reflective object such as glass. (Ultrasonic waves are not reflected back from the obstacle.)
- Sensors may not be able to correctly detect the following types of obstacles:
- Objects made of a thin material like wire netting and ropes
- Square-shaped curbstones or other objects with sharp edges
- Tall objects with a large upper part like a road sign
- Low-profile objects such as curbstones
- Sound-absorbing objects such as cotton and snow

NOTE:

- Thin poles or obstacles lower than the sensors may become undetectable as the vehicle moves closer to them even if they have been detected from longer distances.
- The system may calculate the distance to a road sign or similar obstacle to be shorter than the actual distance.


3-36

Obstacle Indication by Parking Sensor

Information display symbol

EXAMPLE

sors



· Warnings when obstacles such as wall are detected by corner sensors

Distance (approx.)	Buzzer	Symbol
45 – 60 cm (18 – 24 in)	Short beeps at short intervals	Three lines
35 – 45 cm (14 – 18 in)	Short beeps at very short intervals	Two lines
Less than 35 cm (14 in)	Continuous beep	One line

· Warnings when obstacles such as wall are detected by center sensors

Distance (approx.)	Buzzer	Symbol
60 – 150 cm (24 – 59 in)	Short beeps at long intervals	Three lines
45 – 60 cm (18 – 24 in)	Short beeps at short intervals	
35 – 45 cm (14 – 18 in)	Short beeps at very short intervals	Two lines
Less than 35 cm (14 in)	Continuous beep	One line

(1) Obstacle detected by rear center sen-

72R0037

(2) Obstacle detected by rear corner sensors

Upon detecting an obstacle, the parking sensor causes an interior buzzer to sound and a symbol representing the obstacle appears on the information display in the instrument cluster.

- · A different symbol is displayed depending on the direction and distance of the obstacle.
- · A buzzer located behind the rear seat sounds when a sensor at the rear detects an obstacle.

NOTE:

• Symbols are displayed with a short delay after the detection of obstacles.

• If the system detects multiple obstacles simultaneously, the display shows all of their positions using the corresponding symbols. However, the buzzers will sound only for the nearest obstacles.

Warning and Indicator Messages

If there is a problem or warning regarding the parking sensor system, a message is displayed on the information display in the instrument cluster, and a symbol blinks and the buzzer sounds. If a message is displayed, follow its instruction.

Message	Symbol	Buzzer	Probable cause and remedy
PMA SERVICE PARKING SENSORS 68PH02303	Two blinking lines in a sen- sor location.	Series of double beeps	There may be a problem with the parking sensor system. Have your vehicle inspected by a Maruti Suzuki authorised work- shop.
CLEAN PARKING SENSORS 68PH02304	One blinking line in a sensor location.	Series of single beeps	The indicated sensor is contami- nated. Wipe it clean with a soft cloth.

Rearview Camera (if equipped)

When the gearshift lever is shifted to "R" position while the ignition mode is "ON", the rearview camera system automatically shows the view behind the vehicle on the display.

WARNING


The distance viewed in the rearview camera may differ from the actual distance according to the condition of road or the load the vehicle is carrying. Since the camera display area is also limited, backing up by only looking at the display may cause an accident or a collision with an object. The rearview camera cannot replace the driver's attention. The driver alone is responsible for parking and similar driving maneuvers.

- Use the rearview camera only to provide driving assistance.
- Always drive carefully confirming the safety of the rear and the surrounding conditions by looking directly with your eyes and using the rear view mirror.
- Check that the tailgate is securely closed when backing up.

NOTICE

If you use the rearview camera for a long time when the ignition mode is "ON", but the engine is not running, the lead-acid battery may discharge. Do not leave the ignition mode "ON" for a long time when the engine is not running.

Rearview Camera Location



(1) Rearview camera

The rearview camera is installed beside the license plate light.

NOTICE

The rearview camera is a precision instrument. If you strike the camera, it may be broken and cause damage resulting in a catch fire or a malfunction.

- Do not strike the camera.
- Do not remove snow or mud on the camera lens with a stick.

NOTICE

If water enters the rearview camera, it may cause a malfunction or catch fire. Do not use high pressure water

around the camera.

NOTICE

This lens is hard coated to prevent damage or discoloration. Damage or discoloration of lens may obscure the image.

- Do not use a brush to clean lens.
- Do not use alcohol, benzene or thinner to clean the lens.
- Do not use wax on the camera lens.

NOTE:

If body wax gets on the camera lens, wipe off the wax with a clean cloth dampened with mild detergent diluted with water, and then wipe the lens with a dry cloth.

How to Use Rearview Camera

- 1) Press the engine switch to change the ignition mode to "ON".
- 2) Šhift the gearshift lever in "R" position.
 - •The display automatically shows the view behind the vehicle.
 - •When the gearshift lever is shifted from "R" to another gearshift lever position, the display returns to the previous display.

NOTE:


The rearview camera display has first priority in any display mode. However, the rearview camera display does not show the rear view while the system is initializing.


Display Range of Rearview Camera

The rearview camera display shows the area behind the rear end of the tailgate. The display cannot show objects which are close to the bumper or under the bumper. The rearview camera display cannot show obstacles which are higher than the camera. Upper parts of tall objects such as road signs cannot be viewed on the display.

3-39

Display range of rearview camera





(1) Display range

NOTE:

- Images shown on the display from the rearview camera are reversed images (mirror images).
- The colors of objects on the rearview camera may differ from the actual object colors.
- The rearview camera display may be difficult to see under the following conditions, but this is not a system malfunction.
- In dark areas, on a rainy day or at night.
- When the temperature around the lens is too high/low, or the camera is wet such as on a rainy day or during periods of high humidity (dew condensation may occur on the camera lens).
- When a foreign object such as mud or a drop of water is stuck around the camera lens.
- When strong light directly enters the camera (vertical lines may be seen on the display).
- Under fluorescent light. (The display may flicker.)
- When the outside temperature is low (the image on the display may be darkened).

Rearview camera screen indication

The distance viewed in the rearview camera may differ from the actual distance according to the condition of the road or the load the vehicle is carrying. Uphill incline behind the vehicle EXAMPLE (1) (2) (3)


72R0040

(1) Object(2) Actual distance(3) Distance on the display

When there is an uphill incline behind the vehicle, the object shown on the display appears farther away than the actual distance.

3-40

Downhill incline behind the vehicle



(1) Object
 (2) Actual distance
 (3) Distance on the display


When there is a downhill incline behind the vehicle, the object shown on the display appears closer than the actual distance.

If the rear view from the rearview camera is not shown or there is a poor image

- If the rear view from the rearview camera is not shown.
- Check that the ignition mode is "ON".
 Check that the gearshift lever is shifted to "R" position.
- If the image from the rearview camera is poor.
 - Check that the camera lens is not dirty.
- Check that light from the sun or the beam of the headlights from the vehicle behind is not shining directly into the lens.

If the rearview camera system is still not working properly after checking the above, have the system inspected by a Maruti Suzuki authorised workshop as soon as possible.

Braking



The distance needed to bring any vehicle to a halt increases with the speed of the vehicle. The braking distance needed, for example, at 60 km/h will be approximately 4 times greater than the braking distance needed at 30 km/h. Start to depress the brake pedal when there is plenty of distance between your vehicle and the stopping point, and slow down gradually.

If water gets into the brake devices, brake performance may become poor and unpredictable. After driving through water or washing the underside of the vehicle, test the brakes while driving at a slow speed to see if they have maintained their normal effectiveness. If the brakes are less effective than normal, dry them by repeatedly applying the brakes while driving slowly until the brakes have regained their normal effectiveness.

Power-Assisted Brakes

Your vehicle has power-assisted brakes. If power assistance is lost due to a stalled engine or other failures, the system is still fully operational on reserve power and you can bring the vehicle to a complete stop by pressing the brake pedal once and holding it down. The reserve power is partly used up when you depress the brake pedal and reduces each time the pedal is pressed. Apply smooth and even pressure to the pedal. Do not pump the pedal.

Even without reserve power in the brake system, you can still stop the vehicle by pressing the brake pedal harder than normally required. However, the stopping distance may be longer.

OPERATING YOUR VEHICLE

Anti-Lock Brake System (ABS) ABS will help you avoid skidding by electronically controlling braking pressure. It will also help you maintain steering control when braking on slippery surfaces or when braking hard.


The ABS works automatically, so you do not need any special braking technique. Just push the brake pedal down without pumping. The ABS will operate whenever it senses that the wheels are locking up. You may feel the brake pedal moves a little while the ABS is operating.

NOTE:

- The ABS will not work if vehicle speed is under about 9 km/h.
- If the ABS system is activated, you may hear a clunking noise and/or feel pulsating in the brake pedal. This is normal and indicates that the brake fluid pressure is being controlled properly.
- You may hear an operation sound when you start the engine or after the vehicle begins to move. This means that the above systems are in the self-check mode. This sound does not indicate a malfunction.

3-42

- On some types of loose surfaces (such as gravel, snow-covered roads, etc.), the stopping distance required for a vehicle with ABS may be slightly greater than the one required for a comparable vehicle with a conventional brake system. With a conventional brake system, skidding tires are able to plow the gravel or snow layer, shortening the stopping distance. ABS minimizes this resistance effect. Allow for extra stopping distance when driving on loose surfaces.
- On regular paved roads, some drivers may be able to obtain slightly shorter stopping distances with conventional brake systems than with ABS.
- In both of the above conditions, ABS will still offer the advantage of helping you maintain directional control. However, remember that ABS will not compensate for bad road or weather conditions or poor driver judgment. Use good judgment and do not drive too fast.



54MN069

(1) ABS warning light(2) Brake system warning light

- If the ABS warning light (1) on the instrument panel comes on and stays on while driving, there may be a problem with the ABS system. Ask a Maruti Suzuki authorised workshop to inspect the ABS system immediately. If the ABS system becomes inoperative, the brake system will function as an ordinary brake system that has no ABS.
- If the ABS warning light (1) and the Brake system warning light (2) on the instrument panel simultaneously stays on or comes on while driving, both anti-lock function and rear brake force control function (proportioning valve function) of the ABS system may have failed. If so, the rear wheels may easily skid or the vehicle can even spin in the worst case when braking on a slippery road or when hard braking even on a dry paved road. Ask a Maruti Suzuki authorised workshop to inspect the ABS system immediately. Drive carefully, avoiding hard braking as much as possible.

3-43

How the ABS Works

A computer continuously monitors wheel speed. The computer compares the changes in wheel speed when braking. If the wheels slow suddenly, indicating a skidding situation, the computer will change braking pressure several times each second to prevent the wheels from locking. When you start your vehicle or when you accelerate after a hard stop, you may hear a momentary motor or clicking noise as the system resets or checks itself. "This is absolutely normal and indicate that ABS is functioning properly".

WARNING

The ABS may not work properly if tires or wheels other than those specified in the owner's manual are used. This is because the ABS works by comparing changes in wheel speed. When replacing tires or wheels, use only the size and type specified in this owner's manual.

Electronic stability program (ESP[®]) (if equipped)

 $\mathsf{ESP}^{\mathbb{R}}$ is a registered trademark of Daimler AG.

The Electronic Stability Program (ESP[®]) helps to control the vehicle during cornering if front wheels or rear wheels skid. It also assists you in maintaining traction while accelerating on loose or slippery road surfaces. It does this by regulating the engine's output, and by selectively applying the brakes. In addition, ESP[®] helps to avoid skidding by controlling braking pressure.

WARNING

The ESP[®] cannot enhance the vehicle's driving stability in all situations and does not control your vehicle's entire braking system. The ESP[®] cannot prevent accidents, including those resulting from excessive speed in turns, or hydroplaning. Only safe and attentive drive can prevent accidents. The capabilities of an ESP[®]equipped vehicle must never be used as a substitute for careful driving.

The ESP[®] totally manages following four systems, (stability control, traction control, ABS and Brake assist) to help enhance vehicle stability in response to various driving conditions;

Stability control system

The vehicle stability control system helps provide integrated control of systems such as anti-lock brakes, traction control, engine control, etc. This system automatically controls the brakes and engine to help prevent the vehicle from skidding when cornering on a slippery road surface or when turning the steering wheel abruptly.

Traction control system

The traction control system automatically helps prevent the spinning of wheels when the vehicle is started or accelerated on slippery road surfaces. The system operates only if it senses that some of the wheels are spinning or beginning to lose traction. When this happens, the system operates the front or rear brakes and reduces engine power to limit wheel spin.

NOTE:

You may hear an operation sound when you start the engine or after the vehicle begins to move. This means that the above systems are in the self-check mode. This sound does not indicate a malfunction.

3-44

Anti-Lock Brake System (ABS)

ABS will help you avoid skidding by electronically controlling braking pressure. It will also help you maintain steering control when braking on slippery surfaces or when braking hard. The ABS works automatically, so you do not have to use any special braking technique. Just push the brake pedal down without pumping. The ABS will operate whenever it senses that wheels are locking up. You may feel the brake pedal pulsate while the ABS is operating. (For more information on ABS, see "Braking" in this section.)

NOTE:

- The ABS will not work if vehicle speed is under about 9 km/h.
- If the ABS system is activated, you may hear a clunking noise and/or feel pulsating in the brake pedal. This is normal and indicates that the brake fluid pressure is being controlled properly.

Brake assist system

When you step on the brake pedal, the brake assist system determines it to be an emergency stop and provides more powerful braking for a driver who cannot hold down the brake pedal firmly.

NOTE:

If you quickly and forcefully depress the brakes, you may hear a clicking sound in the brake pedal. This is normal and indicates that the brake assist system is activated properly.

WARNING

- The ESP[®] may not work properly if tires or wheels other than those specified in the owner's manual are used. When replacing tires or wheels, use only the size and type specified in this owner's manual.
- The ESP[®] may not work properly if tires are not inflated to the recommended tire pressure.
- The ESP[®] may not work properly if tires are fitted with tire chains.
- The ESP[®] may not work properly if the tires are excessively worn. Replace tires when the tread wear indicators in the grooves appear on the tread surface.
- The ESP[®] is not a substitute for winter tires or tire chains on a snow-covered road.

- The ESP[®] may not work properly if engine related parts such as the muffler are not equivalent to standard equipment or are extremely deteriorated.
- Do not modify the vehicle's suspension since the ESP[®] may not work properly.

NOTE:

- If the ESP[®] system is activated, you may hear a clunking noise and/or feel pulsating in the brake pedal. This is normal and indicates that the brake fluid pressure is being controlled properly.
- You may hear an operation sound when you start the engine or after the vehicle begins to move. This means that the above systems are in the self-check mode. This sound does not indicate a malfunction.

The ESP[®] indicator lights are described below:

ESP[®] warning light



This light blinks 5 times per second when one of the following systems is activated.

- Stability control system
- Traction control system

If this light blinks, drive carefully,

When the ignition switch is turned "ON" or pushed to "ON" mode, this light comes on briefly so you can check that the light is working.

NOTICE

If the ESP[®] warning light comes on and stays on while driving, there may be a malfunction of the ESP[®] systems (other than ABS). You should have the systems inspected by a Maruti Suzuki authorised workshop.

NOTE:

When the ESP[®] warning light comes on and stays on while driving, indicating a malfunction of the ESP[®] systems (other than ABS), the brake system will function as an ordinary ABS with no additional ESP[®] functions.


ESP[®] OFF indicator light



You should turn the $\text{ESP}^{\textcircled{R}}$ on during your ordinary driving, so that you have the benefits of all of the $\text{ESP}^{\textcircled{R}}$ systems.

It may be required to turn the ESP[®] systems (other than ABS) off if your vehicle is stuck in sand, mud, or snow, where wheel spin is necessary.

ESP[®] OFF switch



(1) ESP[®] OFF switch

When the ESP[®] OFF switch located at the instrument panel is pushed and held to turn off the ESP[®] systems (other than ABS), the ESP[®] OFF indicator light in the instrument cluster comes on. When you have turned the ESP[®] systems

(other than ABS) off, turn them back on before resuming ordinary driving. When you push the $\mathsf{ESP}^{\texttt{B}}$ OFF switch again, the $\mathsf{ESP}^{\texttt{B}}$ OFF indicator light will go

out and all of the $ESP^{\mathbb{R}}$ systems will be activated.

ABS warning light / brake system warning light

See "Braking" in this section.

Hill hold control system (if equipped)

The hill hold control system is designed to assist you in starting to move up hills. When you start to move up a hill, the system helps to prevent the vehicle from rolling downward (for approximately 2 seconds) while you move your foot from the brake pedal to the accelerator pedal.

3-46

- Do not rely excessively on the hill hold control system. The hill hold control system may not prevent the vehicle from rolling downward on a hill under all load or road conditions. Always be prepared to depress the brake pedal to prevent the vehicle from rolling downward. Failure to pay attention and depress the brake pedal to hold the vehicle on a hill when necessary, may result in loss of control or an accident.
- The hill hold control system is not designed to stop the vehicle on a hill.
- After you release your foot from the brake pedal, accelerate the vehicle to move up immediately. If you release your foot from the brake pedal over 2 seconds, the hill hold control system will be canceled. If so, the vehicle may roll downward, which can result in an accident depending on the degree of slope. And, the engine may stall and the power assist for the steering and brakes will not work so steering and braking will be much harder than usual which can result in an accident or vehicle damage.

The hill hold control system activates for a maximum of about 2 seconds if your foot is moved from the brake pedal when the following conditions are all met.

- 1) The gearshift lever is in a forward gear or reverse gear.
- 2) The parking brake is released.
- 3) The vehicle is on an upward incline.


On models equipped with the ENG A-STOP system, the hill hold control system is activated when the engine is restarted after being stopped automatically, even if the previous conditions are not met.

NOTE:

When the hill hold control system is activated, the following conditions may be found, but this is not a malfunction.

- You may hear a sound from the engine room.
- As brake pedal becomes heavy, it may be difficult for you to depress it.


DRIVING TIPS



DRIVING TIPS

Running-in	4-1	
Catalytic Converter	4-1	
Improving Fuel Economy	4-2	
Highway Driving	4-3	
Driving on Hills	4-3	4
Driving on Slippery Roads	4-4	4
Off-road Driving	4-6	
When Encountering a Flooded Area	4-6	
Do's and Dont's for safe driving	4-7	
Margin for safety		

DRIVING TIPS



55RM04002

- Fasten Your Seat Belts at All Times. Even though airbags are equipped at the front seating positions, the driver and all passengers should be properly restrained at all times, using the seat belts provided. Refer to "Seat Belts and Child Restraint Systems" section for instructions on proper use of the seat belts.
- Never drive while under the influence of alcohol or other drugs. Alcohol and drugs can seriously impair your ability to drive safely, greatly increasing the risk of injury to yourself and others. You should also avoid driving when you are tired, sick, irritated, or under stress.


Running-in

NOTICE

The future performance and reliability of the engine depends on the care and restraint exercised during its early life. It is especially important to observe the following precautions during the first 960 km of vehicle operation.

- After starting, do not race the engine. Warm it up gradually.
- Avoid prolonged vehicle operation at a constant speed. Moving parts will break in better if you vary your speed.
- Start off from a stop slowly. Avoid full throttle starts.
- Avoid hard braking, especially during the first 320 km of driving.
- Do not drive slowly with the transmission in a high gear.
- Drive the vehicle at moderate engine speeds.

Catalytic Converter



The purpose of the catalytic converter is to minimize the amount of harmful pollutants in your vehicle's exhaust. Use of leaded fuel in vehicles equipped with catalytic converters is prohibited, because lead deactivates the pollutant-reducing components of the catalyst system.

The converter is designed to last the life of the vehicle under normal usage and when unleaded fuel is used. No special maintenance is required on the converter. However, it is very important to keep the engine properly tuned. Engine misfiring, which can result from an improperly tuned engine, may cause overheating of the catalytic converter. This may result in permanent heat damage to the catalytic converter and other vehicle components.

NOTICE

To minimize the possibility of catalytic converter or other vehicle damage:

- Maintain the engine in the proper operating condition.
- In the event of an engine malfunction, particularly one involving engine misfiring or other apparent loss of performance, have the vehicle serviced promptly.
- Do not turn off the engine or interrupt the ignition when the transmission is in gear and the vehicle is in motion.
- Do not try to start the engine by pushing or towing the vehicle, or coasting down a hill.
- Do not idle the engine with any spark plug wires disconnected or removed, such as during diagnostic testing.
- Do not idle the vehicle for prolonged periods if idling seems rough or there are other malfunctions.
- Do not allow the fuel tank to get near the empty level.
- Avoid driving your vehicle at excessively high engine speed in or around the red zone of the tachometer.

EXAMPLE



WARNING

54G584S

Be careful where you park and drive; the catalytic converter and other exhaust components can get very hot. As with any vehicle, do not park or operate this vehicle in areas where combustible materials such as dry grass or leaves can come in contact with a hot exhaust system.

Improving Fuel Economy

Fuel economy (mileage) of the vehicle may vary due to several factors i.e., driving

vary due to several factors i.e., driving habits - gear change pattern, usage of A.C, Air pressure in the tyres, wind speed, traffic conditions, fuel quality- non adulterated standard fuel, maintenance of vehicle, road conditions, braking etc.

The following instructions will help you improve fuel economy.

Avoid excessive idling

If you park your vehicle for more than one minute, stop the engine and start it again later. When warming up a cold engine, do not allow the engine to idle or apply full throttle until the engine has reached operating temperature. Allow the engine to warm up by driving.

Avoid sudden acceleration

Sudden acceleration starting from rest or while driving will consume fuel unnecessarily and shorten engine life. Start off slowly.

Avoid unnecessary stops

Avoid unnecessary deceleration and stopping. Try to maintain a moderate, steady speed whenever possible. Slowing down and then accelerating again uses more fuel.

Keep a steady cruising speed

Drive at a constant speed that road and traffic conditions will permit.

4-2

Keep the air cleaner clean

60A183S

If the air cleaner is clogged with dust, there will be greater intake resistance, resulting in decreased power output and increased fuel consumption.

Keep weight to a minimum

The heavier the load is, the more fuel the vehicle consumes. Unload any unnecessary luggage or cargo.

Keep tire pressures correct


Under-inflation of the tires can waste fuel due to increased rolling resistance of the tires. Keep your tires inflated to the correct pressure shown in the label on driver's door lock pillar.

Highway Driving

When driving at highway speeds, pay attention to the following:

- Stopping distance progressively increases with vehicle speed. Apply the brakes far enough ahead of the stopping point to allow for the extra stopping distance.
- On rainy days, hydroplaning can occur. Hydroplaning is the loss of direct contact between the road surface and the vehicle's tires due to a water film forming between them. Steering or braking the vehicle during hydroplaning can be very difficult, and loss of control can occur. Keep speed down when the road surface is wet.
- At high speeds, the vehicle may be affected by side winds. Therefore, reduce speed and be prepared for unexpected buffeting, which can occur at the exits of tunnels, when passing by a cut of a hill, or when being overtaken by large vehicles, etc.

Driving on Hills



72RM04008

- When climbing steep hills, the vehicle may begin to slow down and show a lack of power. If this happens, you should shift to a lower gear so that the engine will again be operating in its higher power range. Shift rapidly to prevent the vehicle from losing momentum.
- When driving down a hill, the engine should be used for braking by shifting to the next lower gear.

4-3

While moving uphill/gradient from a stand still condition - For manual transaxle

- Apply the parking brake firmly so that the vehicle does not roll backwards.
- Depress the Clutch pedal and Shift the gearshift lever to 1st Select position.
- Do not slip the clutch.
- When ready to start, press accelerator pedal and slowly release the clutch pedal simultaneously. When the vehicle starts to move, gradually release the parking brake.


A WARNING

Do not hold the brake pedal down too long or too often while going down a steep or long hill. This could cause the brakes to overheat, resulting in reduced braking efficiency. Failure to take this precaution could result in loss of vehicle control.

NOTICE

When descending a downhill, Never turn the ignition key to "LOCK" position or press the engine switch to change the ignition mode to "LOCK" (OFF). Emission control system and automatic transmission (if equipped) damage may result.

Driving on Slippery Roads



On wet roads, you should drive at a lower speed than you do on dry roads due to possible slippage of tires during braking. When driving on icy, snow-covered, or muddy roads, reduce your speed and avoid sudden acceleration, abrupt braking, or sharp steering movements.

Snow Chains

Snow chains should only be used if they are needed to increase traction or are required by law. Make sure that the chains you use are the correct size for your vehicle's tires. Also make sure that there is enough clearance between the fenders and the chains as installed on the tires.

Install the chains on the front tires tightly, according to the chain manufacturer's instructions. Retighten the chains after driving about 1.0 km if necessary. With the chains installed, drive slowly.

NOTICE

- If you hear the chains hitting against the vehicle body while driving, stop and tighten them.
- If your vehicle is equipped with full wheel caps, remove the wheel caps before installing the chains or the wheel caps can be damaged by the chain bands.



Stuck Vehicle

If your vehicle gets stuck in snow, mud, or sand, follow the directions below:

 Shift the transmission back and forth between a forward range (or first gear for manual transmission) and reverse. This will create a rocking motion which may give you enough momentum to free the vehicle. Press gently on the accelerator to keep wheel spinning to a minimum wheel rpm. Remove your foot from the accelerator while shifting.

Do not race the engine. Excessive wheel spin will cause the tires to dig deeper, making it more difficult to free the vehicle.

NOTE:

If your vehicle is equipped with the ESP®, you may have to turn the ESP® system off in order to allow spinning the wheels.


2) If your vehicle remains stuck after a few minutes of rocking, we recommend you to consult a Maruti Suzuki authorised workshop or a roadside assistance service. If a towing service is not available in an emergency, your vehicle may be temporarily towed by other vehicle with a towing cable or chain secured to the towing eye either on the front of the vehicle or on the rear of the vehicle. Refer to "Frame Hooks" in "OTHER CONTROLS AND EQUIPMENT" section.

A WARNING

Do not allow anyone to stand near the vehicle when you are rocking it, and do not spin the wheels faster than an indicated 40 km/h on the speedometer. Personal injury and/ or vehicle damage may result from spinning the wheels too fast.

NOTICE

Do not continue rocking the vehicle for more than a few minutes. Prolonged rocking can cause engine overheating or transmission damage.



A WARNING

In addition to following the driving tips in this section, it is important to observe the following precautions.

- Make sure your tires are in good condition and always maintain the specified tire pressure. Refer to "Tires" in the "INSPECTION AND MAINTENANCE" section for details.
- Do not use tires other than those specified by MARUTI SUZUKI. Never use different sizes or types of tires on the front and rear wheels. For information regarding the specified tires, refer to the tire information label located on the driver's door lock pillar.
- Never use oversized tires or special shock absorbers and springs to raise (jack up) your vehicle. This will change the handling characteristics. Oversized tires may also rub against the fender over bumps, causing vehicle damage or tire failure.

(Continued)

4-5

A WARNING

(Continued)

 After driving through water, test the brakes while driving at a slow speed to see if they have maintained their normal effectiveness. If the brakes are less effective than normal, dry them by repeatedly applying the brakes while driving slowly until the brakes have regained their normal effectiveness.

Off-road Driving

Do not drive in the field covered with grown grass

If you drive in the field covered with grass, it may cause accident or vehicle damage by getting caught in grown grass.

When Encountering a Flooded Area



Avoid driving in a flooded area or a deep puddle. If driving in a flooded area is unavoidable, go slowly in the lowest gear. In case that you have driven in a flooded area, stop the vehicle in a safe and non flooded place while checking the brake effectiveness. Then, ask a Maruti Suzuki authorised workshop to check the following inspection items.

- Function of brake
- Function of electrical components
- Changes of oil level and quality for engine, transmission and differential (if equipped). In case that the oil is turbid whitely, water has been mixed in the oil and an oil change is required.
- Lubricant condition of the bearings, suspension joints, etc.

NOTICE

- Avoid driving in a flooded area or a deep puddle. It may cause an engine stall, short in electrical components, engine and transmission damages, etc.
- If the vehicle get stuck in deep water do not start the engine.

4-6


Do's and Dont's for safe driving

Exercise care in handling your vehicle. Be conscious of not only your own safety but also the safety of others on the road, and thus enjoy the best and most comfortable driving experience.

Following are basic rules for safe driving. Read them carefully for good understanding of the content so that you can enjoy safe and pleasant driving in your vehicle.

Starting

- 1) Adjust the driver's seat for the proper driving posture.
- 2) Adjust the rear view mirror so as to obtain the best possible rear view.




- Before moving, look around your vehicle to confirm safety.
- 4) Don't accelerate suddenly, since it is dangerous and wastes fuel.


General Driving

- Be sure to stop before a stop light or stop sign. When moving into an intersection without any traffic lights or signs, drive slowly to confirm safety.
- Always follow other vehicles at a safe distance in order to prevent a rear-end collision, in case the vehicle ahead makes a sudden stop.

- When overtaking other vehicles, watch out for oncoming vehicles and carefully ensure safety.
- Don't attempt zigzag driving as it will hinder your control over the vehicle and may cause an accident.
- Avoid reckless high speed driving and try to drive at a safe speed suitable for the road conditions while maintaining a constant speed.
- 8) The higher the speed, the narrower the driver's visual range becomes. In such a state, it is difficult to anticipate any hazard and the driver feels fatigued.




- 3) Turn on the turn signal at least 30 meters before making a turn or changing the lane so as not to be hit.
- Before entering a corner, decelerate to a safe speed. Don't apply brakes during cornering, or skidding may occur.



72RM04003

- Do not attempt sharp handling during high speed driving. You may lose your control over your vehicle.
- 10)When overtaking or changing lanes while driving at a high speed, keep ample vehicle-to-vehicle distance.



- than in the daytime, as the visual range is restricted at night.
- 2) Avoid overtaking other vehicles at night. Darkness bothers your sense of speed and hinders your judgment of vehicleto-vehicle distance.

- - 1. Warn the vehicle behind you.
 - 2. Gradually apply the brake.
 - 3. Bring the vehicle to a halt.
- 3) When driving downhill, try not to apply the brake but use the engine brake effectively. Overuse of the foot-brake may result in reduction of brake effectiveness.

Long Distance Driving

72RM04004

unless

1) Use the parking brake when parking

position for the sake of safety.

2) Don't use hand-braking

worn out as they skid more.

your vehicle and shift the gear shift

lever into the first gear or reverse gear


unavoidable. It causes the vehicle to

skid and a collision may occur. It is

especially dangerous when the tires are

- 1) Be sure to perform safety checks before starting a trip.
- 2) Take rest at regular intervals to prevent accidents which may occur due to feeling sleepy or tired.

4-8



- 3) Don't use headlights on high beam unless its use is inevitable. It may cause visual impairment to the driver of the oncoming vehicle or the vehicle ahead of you, which may cause an accident.
- Always keep the window glasses clean. Don't operate the windshield wiper when the windshield glass is dry else the wiper blade and glass may get damaged.

Margin for safety


It is important to allow yourself a margin for safety during driving so that you can cope with erroneous or unexpected driving of other drivers. For that, observe the following.

- Drive at a safe speed.
- Maintain a sufficient distance between your vehicle and the vehicle ahead.
- Don't force yourself to overtake other vehicles.
- Don't accelerate suddenly, steer sharply or stop suddenly.
- Keep ample gaps between driving schedules.
- Observe traffic rules and regulations.

Conclusion

A perfect driver does not exist. The endeavour of every motorist should be to strive for perfection. Safety consciousness not only ensures your safety and the safety of other road users, it also helps reduce the wear and tear on your vehicle, lengthens its life, gives better fuel efficiency and ensures a comfortable driving experience. Follow the do's and dont's listed, and driving will never be the same again.

4-9



OTHER CONTROLS AND EQUIPMENT

Heating and Air Conditioning System	5-1
Manual Heating and Air Conditioning System	
Automatic Heating and Air Conditioning System	
(climate control)	5-9
Radio Antenna	5-15
Installation of Radio Frequency Transmitters	5-15
Audio System (if equipped)	5-15 5
Fuel Filler Cap	
Engine Hood	5-49
Sun Visor	
Interior Light	5-52
Accessory Socket	5-53
Assist Grips	5-55
Glove Box	5-55
AUX/USB Socket (if equipped)	5-56
Cup Holder and Storage Area	5-57
Footrest (if equipped)	5-59
Front Seat Back Pocket (if equipped)	5-60
Luggage Box (if equipped)	
Frame Hooks	5-60


Heating and Air Conditioning

Air Outlet

System

There are two types of heating and air conditioning systems as follows:Manual heating and air conditioning sys-


- tem
- Automatic heating and air conditioning system (climate control)



1. Windshield defroster outlet

- 2. Side defroster outlet 3. Side outlet
- 4. Center outlet
- 5. Floor outlet
 6. Cup holder outlet





Move the knob (1) vertically or horizontally to adjust the direction of air flow as desired.

73R0076

When open, air comes out regardless of the air flow selector position.

Move the knob (1) vertically or horizontally, to adjust the direction of air flow as desired.


The side outlet opens when you turn the dial (2) upward and closes when you turn it downward.



Prolonged exposure to hot air from the heater or air conditioner could result in low temperature burns. All vehicle occupants, particularly children, the elderly, those with special needs, individuals with delicate skin, and sleeping individuals, should maintain sufficient distance from the air outlets to prevent prolonged exposure to hot airflow.

Overhead rear air conditioning system






To turn on the overhead rear air conditioning system, set the blower speed selector of the heating and air conditioning system to a position other than off and push in "A/ C" switch. Refer to "Air conditioning switch" in this section. And set the rear blower speed selector (2) to a position other than off.

Move the knob (1) vertically or horizontally to adjust the direction of air flow as desired.

During operation of the air conditioner, you may notice slight changes in engine speed. These changes are normal, the system is designed so that the compressor turns on or off to maintain the desired temperature. Less operation of the compressor results in better fuel economy.

5-3

Manual Heating and Air Conditioning System **Description of Controls**



- 1. Temperature selector
- 2. Blower speed selector 3. Air intake selector
- 4. Air flow selector
- 5. Air conditioning switch


OTHER CONTROLS AND EQUIPMENT

Temperature selector (1) This is used to adjust the temperature.

Blower speed selector (2) This is used to turn on the blower and to select blower speed.

Air intake selector (3)

EXAMPLE فرد



72R0016

This selector is used to select the following modes.

FRESH AIR (a)

When this mode is selected by moving the lever to right, outside air comes in.

5-4

RECIRCULATED AIR (b)

When this mode is selected by moving the lever to left, outside air is shut out and inside air is recirculated. This mode is suitable when driving through dusty or polluted air such as in a tunnel, or when attempting to guickly cool down or warm up the interior or to reduce unwanted odor from entering the vehicle.

NOTE:

EXAMPLE

(4)

If you select RECIRCULATED AIR for an extended period of time, the air in the vehicle may become contaminated and the windows tend to get misted. Therefore, you should occasionally select FRESH AIR.

USE WITH-(6)


52RS50181

 \sim




The mark of "USE WITH" (6) To clear fog on the windshield and/or the side windows quickly, set the air flow selector (4) to "HEAT & DEFROST" or "DEFROST" and air intake selector (3) to "FRESH AIR". These positioning will clear the fogged windshield and/or the side windows faster than the "RECIRCULATED AIR".

Air flow selector (4)



This is used to select one of the following functions.


VENTILATION (c)




72R0144

Temperature-controlled air comes out of the center, side and cup holder outlets.


BI-LEVEL (d)



Temperature-controlled air comes out of the floor outlets and cooler air comes out of the center, side and cup holder outlets. When the temperature selector (1) is in the fully cold position or fully hot position, however, the air from the floor outlets and the air from the center, side and cup holder outlets. will be the same temperature.




Temperature-controlled air comes out of the floor outlets and the side outlets, also comes out of the windshield defroster outlets and the side defroster outlets slightly. HEAT & DEFROST (f)



Temperature-controlled air comes out of the floor outlets, the windshield defroster outlets, the side defroster outlets and the side outlets.

5-6

DEFROST (g)



Temperature-controlled air comes out of the windshield defroster outlets, the side defroster outlets and the side outlets.

Air conditioning switch (5)

To turn on the air conditioning system, set the blower speed selector to a position other than off and push in "A/C" switch. With this "A/C" switch operation, a indicator light will come on when the air conditioning system is working. To turn off the air conditioning system, push "A/C" switch again.

During operation of the air conditioner, you may notice slight changes in engine speed. These changes are normal, the system is designed so that the compressor turns on or off to maintain the desired temperature. Less operation of the compressor results in better fuel economy.

System Operating Instructions

Natural ventilation

Select VENTILATION and FRESH AIR, the temperature selector to the desired temperature position, and the blower speed selector to off. Fresh air will flow through the vehicle during driving.

Forced ventilation

The base settings are the same as for natural ventilation except you set the blower speed selector to a position other than off.

Normal heating (using outside air)

Select HEAT and FRESH AIR, the temperature selector to the desired temperature position and the blower speed selector to the desired blower speed position. Setting the blower speed selector to a higher blower speed position increases heating efficiency

Quick heating (using recirculated air)

The base settings are the same as for normal heating except you select RECIRCU-LATED AIR. If you use this heating method for an extended period of time, the air in the vehicle may become contaminated and the windows can become misty. Therefore, use this method only for quick heating and change to the normal heating method as soon as possible.

Head cooled/Feet warmed heating

Select BI-LEVEL and FRESH AIR, the temperature selector to the desired temperature position, and the blower speed selector to the desired blower speed position. Unless the temperature selector is in the fully cold position or fully hot position, the air that comes out of the center and side outlets will be cooler than the air that comes out of the floor outlets.

Normal cooling

Set the air flow selector to VENTILATION, the temperature selector to the desired temperature position and the blower speed selector to the desired blower speed position, and turn on "A/C" switch. Setting the blower speed selector to a higher blower speed position increases cooling efficiency.

You can switch the air intake selector to either FRESH AIR or RECIRCULATED AIR as you desire. Choosing RECIRCU-LATED AIR increases cooling efficiency.

Quick cooling (using recirculated air)

The base settings are the same as for normal cooling except you select RECIRCU-LATED AIR and the highest blower speed.

NOTE:

 If you select RECIRCULATED AIR for an extended period of time, the air in the vehicle may become contaminated and the windows tend to get misted. Therefore, you should select FRESH AIR whenever possible.


If your vehicle has been left in the sun with the windows closed, it will cool faster if you open the windows briefly while you operate the air conditioner with the air intake selector at FRESH AIR and the blower at high speed.

Dehumidifying

Set the air flow selector to a desired air flow selector position, the temperature selector to the desired temperature position and the blower speed selector to the desired blower speed position. Also select FRESH AIR and turn on "A/C" switch.

NOTE:

Because the air conditioner dehumidifies the air, turning it on will help keep the windows clear, even when blowing heated air using DEFROST or HEAT & DEFROST functions.



NOTE:

- If you need maximum defrosting:
- select DEFROST and FRESH AIR,
- set the blower speed selector to high,
- adjust the temperature selector to the hot end,
- turn on "A/C" switch, and
- adjust the side outlets so the air blows on the side windows.

Models with ENG A-STOP System (if equipped)

- If the air conditioning performance can no longer perform at a sufficient level due to automatically stopping the engine, press the "ENG A-STOP OFF" switch to deactivate the ENG A-STOP system. (The engine will automatically restart and the air conditioning performance will be restored.)
- If the windshield and/or the driver's side/ passenger side door windows are fogged during automatically stopping the engine, stop the ENG A-STOP system and restart the engine. Then, turn the air flow selector (4) to change the air flow to the "Heat & defrost" or "Defrost" position to defog the windows.

Maintenance

If you do not use the air conditioner for a long period, such as during winter, it may not give the best performance when you start using it again. To help maintain optimum performance and durability of your air conditioner, it needs to be run periodically. Operate the air conditioner at least once a month for one minute with the engine idling. This circulates the refrigerant and oil and helps protect the internal components.

OTHER CONTROLS AND EQUIPMENT

If your air conditioner is equipped with air filters, clean or replace them as specified in "Maintenance schedule" in "INSPEC-TION AND MAINTENANCE" section.

NOTE:


Your vehicle uses the air conditioning refrigerant HFC-134a, commonly called "R-134a". R-134a replaced R-12 around 1993 for automotive applications. Other refrigerants are available, including recycled R-12, but only R-134a should be used in your vehicle.

NOTICE

Using the wrong refrigerant may damage your air conditioning system. Use R-134a only. Do not mix or replace the R-134a with other refrigerants.


Automatic Heating and Air Conditioning System (climate control)

Description of Controls



- 1. Temperature selector
- 2. Blower speed selector
- 3. Air intake selector
- 4. Air flow selector
- 5. Defrost switch
- 6. Air conditioning switch
- 7. "OFF" switch 8. "AUTO" switch
- 9. Display

Temperature selector (1)



Turn the temperature selector (1) to adjust the temperature.

NOTE:

If you turn the temperature selector (1) until "HI" or "LO" appears on the display, the climate control system will operate at maximum heating or cooling. The tempera-ture of the air from the outlets may change

5-9


suddenly while "LO" or "HI" is displayed, but this is normal.

NOTE:

When you change the unit of temperature in the information display, the unit of temperature in the air conditioning system will be changed. Refer to "Information display" in the "BEFORE DRIVING" section for details.

Blower speed selector (2)


EXAMPLE



The blower speed selector (2) is used to turn on the blower and to select blower speed.

If "AUTO" switch (8) is pushed, the blower speed will vary automatically as the climate control system maintains the selected temperature.

Air intake selector (3)



Push the air intake selector (3) to change between the recirculated air and fresh air mode.

If "AUTO" switch (8) is pushed, the air intake will vary automatically as the climate control system maintains the selected temperature.

NOTE:

When the recirculated air mode is selected, the automatic operation system is deactivated even if you push "AUTO" switch (8).

OTHER CONTROLS AND EQUIPMENT

RECIRCULATED AIR (a)

When this mode is selected, outside air is shut off and inside air is recirculated. This mode is suitable when driving through dusty or polluted air such as a tunnel, or when attempting to quickly cool down or warm up the interior or to reduce unwanted odor from entering the vehicle.

FRESH AIR (b)


When this mode is selected, outside air is introduced.

FRESH AIR and RECIRCULATED AIR are selected alternately each time the air intake selector is pushed.


NOTE:

If you select RECIRCULATED AIR for an extended period of time, the air in the vehicle may become contaminated and the windows tend to get misted. Therefore, you should select FRESH AIR whenever possible.

5-10




VENTILATION (c)




Temperature-controlled air comes out of the center, side and cup holder outlets.

BI-LEVEL (d)



When the temperature selector (1) is in the fully cold position or fully hot position, however, the air from the floor outlets and the air from the center, side and cup holder outlets will be the same temperature. HEAT (e)

of the center, side and cup holder outlets.



72R0006

Temperature-controlled air comes out of the floor outlets and the side outlets, a small amount of air comes out of the windshield defroster outlets and also comes slightly out of the side defroster outlets.


Push the air flow selector (4) to change among the following functions. The indication of the selected mode appears in the display.

If "AUTO" switch (8) is pushed, the air flow will vary automatically as the climate control system maintains the selected temperature.

Temperature-controlled air comes out of the floor outlets and cooler air comes out




HEAT & DEFROST (f)



Temperature-controlled air comes out of the floor outlets, the windshield defroster outlets, the side defroster outlets and the side outlets.

Defrost switch (5)




Push the defrost switch (5) to turn on the defroster.

This is used to clear the windscreen and side windows by pushing the switch when the defroster switch is ON, the indicator light above the defroster switch will come ON and the defroster display is shown is the display.

OTHER CONTROLS AND EQUIPMENT

DEFROST




Temperature-controlled air comes out of the windshield defroster outlets, the side defroster outlets and the side outlets.

NOTE:


When the defrost switch (5) is pushed to turn on the defroster, the air conditioning system will operate and FRESH AIR mode will be selected automatically. In very cold weather, however, the air conditioning system will not operate.

5-12



The air conditioning switch (6) is used to turn on and off the air conditioning system only when the blower is on. To turn on the air conditioning system, push in the switch and "A/C" will appear in the display. To turn off the air conditioning system, push in the switch again and "A/C" will go off. System Operating Instructions

Automatic operation



You can let the climate control system work automatically. To set the system for fully-automatic operation, follow the procedure below.

- 1) Start the engine.
- 2) Push "AUTO" switch (8).
- 3) Set the desired temperature by turning the temperature selector (1).

The blower speed, air intake and air flow are controlled automatically to maintain the set temperature. However, the air flow is not changed to DEFROST position automatically.

NOTE:

When the recirculated air mode is selected, the automatic operation system

is deactivated even if you push "AUTO" switch (8).

You can use the air conditioning switch (6) to manually turn the air conditioner on or off according to your preference. When you turn the air conditioning switch off, the climate control system cannot lower the inside temperature below outside temperature.

To turn the climate control system off, push "OFF" switch (7).

NOTE:


If "AUTO" in the display blinks, there is a problem in the heating system and/or air conditioning system. You should have the system inspected by a Maruti Suzuki authorised workshop.

NOTE:

- To find the temperature at which you are most comfortable, start with the 22°C (72°F) or 25°C (75°F) setting. (the temperature vary depending on vehicle specifications.).
- If you turn the temperature selector (1) until "HI" or "LO" appears on the display, the climate control system will operate at maximum heating or cooling and the blower will run at full speed.
- To avoid blowing cold air in cold weather or hot air in hot weather, the system will delay turning on the blower until warmed or cooled air is available.

5-13

- If your vehicle has been left in the sun with the windows closed, it will cool faster if you open the windows briefly.
- Even under the automatic operation, you can set individual selectors to the manual mode. The manually selected functions are maintained, and the other functions remain under automatic operation.
- If the windshield and/or the front door windows are fogged, push the defrost switch (5) to turn on the defroster, or push the air flow selector (4) to change the air flow to HEAT & DEFROST position to defog the windows.
- To return the blower speed selector (2), air intake selector (3), and air flow selector (4) to automatic operation, push "AUTO" switch (8).




Be careful not to cover the interior temperature sensor (10) located between the steering wheel and the climate control panel, or the solar sensor (11) located at the top of the driver's side dashboard. These sensors are used by the automatic system to regulate temperature. Even if the engine is turned OFF, the tem-

perature setting remains in the memory.

Manual operation

You can manually control the climate control system. Set the selectors to the desired positions.



NOTE:

If you need maximum defrosting:

- push the defrost switch (5) to turn on the defroster (the air conditioning system will operate and FRESH AIR mode will be selected automatically),
- set the blower speed selector to high,
- adjust the temperature selector to "HI" indication on the display, and
- adjust the side outlets so the air blows on the side windows.

Maintenance

If you do not use the air conditioner for a long period, such as during winter, it may not give the best performance when you start using it again. To help maintain optimum performance and durability of your air conditioner, it needs to be run periodically. Operate the air conditioner at least once a month for one minute with the engine idling. This circulates the refrigerant and oil and helps protect the internal components.

If your air conditioner is equipped with air filters, clean or replace them as specified in "Maintenance schedule" in "INSPEC-TION AND MAINTENANCE" section. Have this job done by a Maruti Suzuki authorised workshop as the lower glove box must be lowered for this job.

NOTE:


Your vehicle uses the air conditioning refrigerant HFC-134a, commonly called R-134a. R-134a replaced R-12 around 1993 for automotive applications. Other refrigerants are available, including recycled R-12, but only R-134a should be used in your vehicle.

NOTICE

Using the wrong refrigerant may damage your air conditioning system. Use R-134a only. Do not mix or replace the R-134a with other refrigerants.

5-14

Radio Antenna



The radio antenna on the roof is removable. To remove the antenna, turn it counterclockwise. To reinstall the antenna, turn it clockwise firmly by hand.

NOTICE

То	avoid	damage	to	the	radio
ante	enna:				
_		la a	- · · · I -		1

- Remove the antenna when using an automatic car wash.
- Remove the antenna when the antenna hits anything such as a low ceiling in a parking garage or putting a car cover over your vehicle.

Installation of Radio Frequency Transmitters

We recommend that you always ask a Maruti Suzuki authorised workshop about frequency band, max output power, antenna position at vehicle and specific conditions for installation and/or use before installing a radio transmitter in your vehicle. Such equipments may cause the electronic control system to malfunction if they are incorrectly installed or they are not suited for the vehicle.

Audio System (if equipped)

Safety Information

WARNING

If you pay too much attention to operating the audio system or watching the audio system display while driving, an accident can occur. If you set the sound volume too loud, it could prevent you from being aware of road and traffic conditions.

- Keep your eyes on the road and your mind on the drive. Avoid paying too much attention to operating the audio system or watching the audio system display.
- Familiarize yourself with the audio system controls and operation of the audio system before driving.
- Preset your favorite radio stations before driving so that you can quickly tune to them using the presets.
- Set the sound volume to a level that will allow you to continue to be aware of surrounding road and traffic conditions while driving.

Bluetooth*

The Bluetooth[®] word mark and logo are registered trademarks and are owned by the Bluetooth SIG, Ink.

Stop using this unit and a Bluetooth[®] ready device whenever requested.


This unit shares the communication frequency with other private or public wireless communication equipment such as a wireless LAN and other wireless communication radios.

You should stop using this unit immediately whenever you are notified that your unit disturbs other wireless communication.

NOTE:

For vehicle equipped with SMARTPLAY INFOTAINMENT SYSTEM, refer to the audio manual available with the vehicle. Remote controller is not provided with the vehicles equipped with SMARTPLAY INFOTAINMENT SYSYTEM.

Basic Operations



(1) POWER button

- (2) "TUNE/TRACK" Up/Down button
- (3) "ENT" (enter) button
- (4) BACK button
- (5) "SETUP" button
- (6) "VOLUME" button
- (7) "MEDIA" button
- (8) "RADIO" button

Turning power on/off

Touch the POWER button (1). The audio system starts in the function mode it was in when the power was turned off last.

 Touching the POWER button (1) for 1 second or longer can turn off the audio system.

Slide touch operation

Operate several functions with the slide touch operation. Touch the panel and slide up or down with your finger for increase/ decrease or up/down operation.

NOTE:

Pay caution to the following content regarding slide touch operation:

- The touch button may not operate properly when the touch panel or your fingers are wet. Remove any liquid before operating.
- Depending on the operation method it may react without touching.
- It may not react properly when operated with gloves on.
- When metal objects are placed near the touch panel it may cause a malfunction.
- Do not attach protective film. Otherwise, the touch panel may not operate properly.

5-16

Functions available with the slide touch operation

Mode	Function	÷	∧ ∨
Common	Volume up/down	0	-
	Item selection	-	0
Radio	TUNE up/down	Ι	0
USB	File up/down	-	0
	Folder up/down (folder operation mode)	-	0
iPod [®]	TRACK up/down	-	0
	Category selection (iPod [®] menu)	-	0
Bluetooth [®] audio	TRACK up/down	-	0
	Group up/down (Group operation mode)	-	0
Hands-free	Reception/ringtone/incoming call volume up/down	0	-
	Switching pages of the speed dial selec- tion screen	-	0

Adjusting the volume

Touch or slide the "VOLUME" button (6).

• To increase the volume, touch 🖪 or slide upwards.

To decrease the volume, touch a or slide downwards.

NOTE:

While driving, adjust the volume to an extent that sound and/or noise coming from outside can be heard.

Sound settings

- Touch the "SETUP" button (5).
 Touch for 1 second or longer when using radio mode.
- Touch or slide the "TUNE/TRACK" Up/ Down button (2), select "Sound", and touch the "ENT" button (3).
 - •The sound setting screen will be displayed.
- Touch or slide the "TUNE/TRACK" Up/ Down button (2), select the desired item, and touch the "ENT" button (3).
 - •The sound settings will change as follows:

 $\begin{array}{l} \bullet EQ \leftrightarrow Bass \leftrightarrow Treble \leftrightarrow Balance \leftrightarrow \\ Fader \leftrightarrow AVC \end{array}$

Preset EQ

The preset EQ can set various types of sounds depending on the type of music. 1) Touch or slide the "TUNE/TRACK" Up/

- Touch or slide the "TUNE/TRACK" Up/ Down button (2) from the "Sound" screen, select "EQ", and touch the "ENT" button (3).
- Touch or slide the "TUNE/TRACK" Up/ Down button (2), select the desired item, and touch the "ENT" button (3).
- The preset EQ settings will change as follows:

 $\begin{array}{l} \text{Off (Flat)} \leftrightarrow \text{Jazz} \leftrightarrow \text{Rock} \leftrightarrow \text{Pop} \leftrightarrow \\ \text{Classic} \leftrightarrow \text{Hip-hop} \end{array}$

Adjusting bass/treble/balance /fader

The preset EQ can set various types of sounds depending on the type of music.

- Touch or slide the "TUNE/TRACK" Up/ Down button (2) from the "Sound" screen, select "Bass", "Treble", "Balance", or "Fader" and touch the "ENT" button (3).
- Touch or slide the "TUNE/TRACK" Up/ Down button (2), adjust to the desired settings and touch the "ENT" button (3).
- "Bass"/"Treble":
- Can be adjusted in stages from -6 to 0 to +6.
- Touch ▲ to emphasize the low or high sounds, and touch ▼ to quiet.
- "Balance":
 - Can be adjusted in 9 stages left to right.
 - Touch ▲ to emphasize the right speaker, and touch ▲ to emphasize the left speaker.
- "Fader":
- Can be adjusted in 9 stages back to front.
- Touch ▲ to emphasize the front speaker, and touch ▲ to emphasize the rear speaker.

Adjusting the AVC (Auto volume control)

The Auto Volume Control (AVC) function automatically adjusts (increases/ decreases) the sound volume in accordance with vehicle speed. The AVC control is provided with three selectable levels (LEVEL OFF, 1, 2, 3). The range of volume adjustment increases together with the LEVEL number.

- Touch or slide the "TUNE/TRACK" Up/ Down button (2) from the "Sound" screen, select "AVC", and touch the "ENT" button (3).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (2), select the desired level, and touch the "ENT" button (3).

 The AVC will change as follows: Off ↔ Level 1 ↔ Level 2 ↔ Level 3

 $\bigcirc \square \leftrightarrow Level \square \leftrightarrow Level \square \leftrightarrow Level$

Switching the mode

- Press the "MEDIA" button (7) for 1 second or more in radio mode. You can switch the radio mode to media mode.
- 2) Touch the "RADIO" button (8) in media mode. You can switch the media mode to radio mode.

System settings

Change the "Beep", "Slide", and "SW Sensitivity" settings.

- 1) Touch the "SETUP" button (5).
- Touch for 1 second or longer when using radio mode.
- Touch or slide the "TUNE/TRACK" Up/ Down button (2), select "System", and touch the "ENT" button (3).
- The system setting screen will be displayed.
- Touch or slide the "TUNE/TRACK" Up/ Down button (2), select the desired item, and touch the "ENT" button (3).
- The system settings will change as follows:

 $\mathsf{Beep} \leftrightarrow \mathsf{Slide} \leftrightarrow \mathsf{SW} \mathsf{Sensitivity}$

BEEP on/off

- Touch or slide the "TUNE/TRACK" Up/ Down button (2) from the "System" screen, select "Beep", and touch the "ENT" button (3).
- Touch or slide the "TUNE/TRACK" Up/ Down button (2), select on or off, and touch the "ENT" button (3).

Slide touch operation settings

Turn the slide operation on/off.

- 1) Touch or slide the "TUNE/TRACK" Up/ Down button (2) from the "System" screen, select "Slide", and touch the "ENT" button (3).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (2), select on or off, and touch the "ENT" button (3).

5-18

Touch panel sensitivity settings

touch the "ENT" button (3).

and touch the "ENT" button (3).

Change the touch panel sensitivity. 1) Touch or slide the "TUNE/TRACK" Up/

Down button (2) from the "System"

screen, select "SW Sensitivity", and

Down button (2), select Low or High,

2) Touch or slide the "TUNE/TRACK" Up/


Display



NOTE:

If the touch button sensitivity is too high, set to "Low".

Radio




- (1) "TUNE/TRACK" Up/Down button
- (2) Preset button
- (3) "RADIO" button*1
- (4) "CH" (channel) button
- (5) "AS" (auto store) button
- *1 Use this button to switch between manual preset and auto preset.



73R0139

Auto preset



(A) Frequency (B) Band

(C) Auto Store mode display

NOTE:

Radio Reception

Radio reception can be affected by environment, atmospheric conditions, or radio signal's power and distance from the station. Nearby mountains and buildings may interfere or deflect radio reception, causing poor reception. Poor reception or radio static can also be caused by electric current from overhead wires or high voltage power lines.

Selecting the band

- 1) Touch the "RADIO" button (3) for 1 second or longer.
- Each time the button is touched, the mode will change as follows:
- AM \rightarrow FM1 \rightarrow FM2 \rightarrow AM (AS) \rightarrow FM (AS)

Seek tuning

- 1) Touch the "TUNE/TRACK" Up/Down button (1) for 1 second or longer.
- The audio system stops searching for a station at a frequency where a broadcast station is available.

Manual tuning

1) Touch the "TUNE/TRACK" Up/Down button (1) to select the desired station.

Storing the station

Manual store

- 1) Select the station and frequency.
- 2) Touch and hold the "CH" button (4) for at least 1 second.
- 3) Hold down a desired button ([1] to [6]) of the Preset buttons (2) to which you want to store the station for 2 seconds or longer.

NOTE:

6 stations can be stored for AM, and 6 stations for each of FM1 and FM2, thus 18 stations can be stored in total.

Auto store

- 1) Touch the "AS" button (5) for 1 second or longer.
- Start searching from a station whose frequency is the lowest. When a broadcast station that can be received with a sufficient strength is discovered, it will be assigned to the AM (AS)/FM (AS) band's preset button (2). Once this process is completed the tuner will return to the first stored broadcast station.

NOTE:

- Auto store can be released by touching the "AS" button (5) while auto store is under way.
- When the auto store is performed, the station previously stored in the memory at the position is overwritten.
- 6 stations can be preset for FM, and 6 stations for AM in auto store mode.

Select from the preset channels Manual preset channel

- 1) Select the radio station and frequency.
- 2) Touch the "CH" button (4) for 1 second or longer.
- 3) Touch a desired button ([1] to [6]) of the Preset buttons (2).


NOTE:

Touch and hold the "CH" button (4) for at least one second to select from the preset channel list.

Auto preset channel

- Touch the "RADIO" button (3) for 1 second or longer and select AM (AS) or FM (AS).
- 2) Touch the "CH" button (4) for 1 second or longer.
- The preset channel list is displayed.
- 3) Touch a desired button ([1] to [6]) of the Preset buttons (2).

USB




(1) "TUNE/TRACK" Up/Down button (2) "DISP/ENT" (display/enter) button

- (3) BACK button
- (4) "FLD" (folder operation) button
- (5) "SETUP" (random/repeat) button
- (6) "MEDIA" button

Display

(A) Play time



(B) Text information display

WARNING

Do not connect any USB device other than a USB memory or a USB audio player. Do not connect multiple USB devices to the USB connector using a USB hub, etc. Supplying power to multiple USB devices from the connector could cause overheating and smoking.

Selecting a USB device mode

 Press the "MEDIA" button (6) for 1 second or more for changing from radio mode, or

Touch the "MEDIA" button (6) if the audio is in other than radio mode.

 Each time the button is touched, the mode will change as follows: USB (iPod[®]) (if equipped) → Bluetooth[®] audio (if equipped) → AUX (if equipped)...

5-20

Fast forwarding/Rewinding a track

- 1) Hold down the "TUNE/TRACK" Up/ Down button (1).
- M: Hold down the Up button for 1 second or longer to fast forward the track.
- Note: Hold down the Down button for 1 second or longer to fast rewind the track.
- Releasing the button can stop the fast forwarding/rewinding.

Selecting a track

- 1) Touch the "TUNE/TRACK" Up/Down button (1).
- Touch the Up button to listen to the next track.
- When the Down button is touched once, the track currently being played will start from the beginning again. Touch the Down button twice to listen to the previous track.

Selecting a folder

- 1) Touch the "FLD" (folder operation) button (4).
- 2) Touch the "TUNE/TRACK" Up/Down button (1).
- Touch the Up button to move to the next folder.
- V: Touch the Down button to move to the previous folder.

Repeat playback

- 1) Touch the "SETUP" (random/repeat) button (5).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Repeat", and touch the "DISP/ENT" button (2).
- Each time the "DISP/ENT" button (2) is touched, the mode will change as follows: Off → One song repeat → Folder repeat ...

Random playback

- 1) Touch the "SETUP" (random/repeat) button (5).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Random", and touch the "DISP/ENT" button (2). Each time the "DISP/ENT" button (2) is touched, the mode will change as follows:

 $Off \rightarrow Folder random \rightarrow All random ...$

Display change

- 1) Touch the "DISP/ENT" button (2).
- Each time the button is touched, display will change as follows: MP3/AAC:

Artist name/Track title \rightarrow Album name/ Track title \rightarrow Folder name/File name... WMA: Artist name/Track title \rightarrow Folder name/

File name ...

NOTE:

- "NO TITLE" will be displayed when there is no text information in the USB device currently being played.
- "..." is displayed if all text data cannot be displayed. Touch and hold the "DISP/ ENT" button (2) for at least 1 second to automatically display the rest of the text data.

Notes on USB device

Compatible USB devices

- USB Mass Storage Class For details as to whether your USB memory/USB Audio is compatible with USB Mass Storage Class, please contact the USB memory/USB Audio manufacturer.
- Audio file MP3 (.mp3)/WMA (.wma)/AAC (.m4a)/ AAC (.aac)
- File System FAT 12/16/32,VFAT (supporting long file name)
- USB Standard Compatibility 1.1/2.0 Full Speed
- If a USB hub or extension cable is connected to the audio system, it may not be recognized. In this case, directly connect the USB device to the audio system.
- Devices such as MP3 players/mobile phones/digital cameras may not be recognized as audio systems for playing music.

5-21

USB device connection

- When connecting a USB device, make sure that the connector is pushed all the way into the port.
- Depending on the USB flash drive that you are using, (non-brand product, USB flash drive that has been externally damaged) it may disable connection or cause unstable operation.
- Do not leave the USB device for long periods of time in places inside the vehicle where the temperature can rise too high.
- Back up any important data beforehand. We cannot accept responsibility for any lost data.
- It is recommended not to connect a USB device that contains data files other than MP3/WMA format.

Recording MP3/WMA/AAC files on a USB device

- Playback or display may not be possible depending on the type of USB device in use or the condition of the recording.
- Depending on the connected USB memory, the files may be played in different order from the order that the files were stored.
- The DRM (Digital Rights Management) file cannot be played.

Compression formats

MP3 • Bit rate

MPEG1 Audio Layer III: 32 up to 320 kbps MPEG2 Audio Layer III: 8 up to 160 kbps MPEG2.5 Audio Layer III: 8 up to 160 kbps

VBR: up to 384 kbps (MAX.)

- Sampling frequency MPEG1 Audio Layer III: 32/44.1/48 kHz MPEG2 Audio Layer III: 16/22.05/24 kHz MPEG2.5 Audio Layer III: 8/11.025/12 kHz
- Channel Stereo/Joint stereo/Dual channel/Monaural
- ID3 tag
- ID3v1.x/ID3v2.x

WMA

- Windows Media Audio Ver.7/Ver.8/Ver.9
 Standard compliant
- Bit rate: 32 up to 320 kbps
- VBR: up to 384 kbps (MAX.)
- Sampling frequency: 32/44.1/48 kHz
- WMA tag: Ver.8.0
- Channel: 2 Channels

AAC

- Bit rate: 16 up to 320 kbps
- VBR: up to 320 kbps (MAX.)
- Sampling frequency: 32/44.1/48 kHz
- AAC tag: iTunes m4a metadata

Maximum number of files/folders


- Maximum number of files: 2500
- · Maximum number of files in a folder: 255
- Maximum number of folders: 255
- Root folder and empty folder are included.
- Maximum depth of tree structure: 8

NOTICE


Never use ".mp3", ".wma" or ".m4a" as a file name extension if it is not in the MP3/WMA/AAC format file. Failure to observe this may result in damage to the speaker due to noise production.

5-22

iPod®



- (1) "TUNE/TRACK" Up/Down button
- (2) "DISP/ENT" (display/enter) button
- (3) BACK button
- (4) "FLD" (iPod[®] menu) button
- (5) "SETUP" (shuffle/repeat) button
- (6) "MEDIA" button



(A) Play time(B) Text information display

Selecting an iPod[®] mode

- 1) Touch the "MEDIA" button (6).
- Each time the button is touched, the mode will change as follows: USB (iPod[®]) (if equipped) → Bluetooth[®] audio (if equipped) → AUX (if equipped)

Fast forwarding/Rewinding a track

- Hold down the "TUNE/TRACK" Up/ Down button (1).
- Image: Hold down the Up button for 1 second or longer to fast forward the track.
- Image: Hold down the Down button for 1 second or longer to fast rewind the track.
- Releasing the button can stop the fast forwarding/rewinding.

Selecting a track

- 1) Touch the "TUNE/TRACK" Up/Down button (1).
- Touch the Up button to listen to the next track.
- ■ : When the Down button is touched once, the track currently being played will start from the beginning again. Touch the Down button twice to listen to the previous track.

Select a category

- Touch the "FLD" (iPod[®] menu) button (4).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the desired category, and touch the "DISP/ENT" button (2).
- The Song selection mode for each category will be displayed as follows.
- Playlists: Playlists \rightarrow Songs
- Artists: Artists \rightarrow Albums \rightarrow Songs
- Songs: Songs
- Genres: Genres \rightarrow Artists \rightarrow Albums \rightarrow Songs
- Radio: Station
- Audiobooks: Audiobooks
- Podcasts: Podcasts \rightarrow Episodes
- i Tunes U: i Tunes U \rightarrow Épisodes

NOTE:

Categories is not displayed if the no files in the category.

Repeat playback

- Touch the "SETUP" (shuffle/repeat) button (5).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Repeat", and touch the "DISP/ENT" button (2).
- Touch the "DISP/ENT" button (2). Each time the button is touched, display will change as follows:

The repeat mode will vary depending on your device.

 \hat{O} ff \rightarrow 1 song repeat \rightarrow All repeat ...

Random plavback

- 1) Touch the "SETUP" (shuffle/repeat) button (5).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Shuffle", and touch the "DISP/ENT" button (2).
- Touch the "DISP/ENT" button (2). Each time the button is touched, display will change as follows:
- $Off \rightarrow Shuffle \rightarrow Album shuffle ...$

Display change

- 1) Touch the "DISP/ENT" button (2).
- Each time the button is touched, display will change as follows: Artist name/Track title → Album name/ Track title \rightarrow Playlist name/Track title ...

NOTE:

- "NO TITLE" is displayed if the file currently being played has no text data.
- "..." is displayed if all text data cannot be displayed. Touch and hold the "DISP/ ENT" button (2) for at least one second to automatically display the rest of the text data.
- "Playlist name/song name" is only displayed by the "FLD" (Menu) button (4) when music is selected from Playlists.

Notes on iPod[®]

Supported iPod[®]

- iPod[®] nano:
- iPod[®] nano (7th generation) • iPod[®] touch:
- iPod[®] touch (6th generation) • i Pod[®] touch (5th generation)
- iPhone[®]:
- i Phone[®] 5
- i Phone[®] 5s
- i Phone[®] 5c
- i Phone[®] 6
 i Phone[®] 6 Plus
- i Phone[®] 6s
- i Phone[®] 6s Plus i Phone[®] SE

- i Phone[®] 7
 i Phone[®] 7 Plus
- i Phone[®] 8
- i Phone[®] 8 Plus
- i Phone[®] X

NOTE:

Some functions may not be available depending on the model of iPod[®].




"Made for iPod" and "Made for iPhone" means that an electronic accessory has been designed to connect specifically to iPod[®] or iPhone[®], respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this unit or its compliance with safety and regulatory standards.

- · Please note that the use of this accessory with iPod[®] or iPhone[®] may affect wireless performance.
- iPhone[®], iPod[®], iPod[®] classic, iPod[®] nano, and iPod[®] touch are trademarks of Apple Inc., registered in the U.S. and other countries.
- Lightning[®] is a trademark of Apple Inc.

5-24

AUX



(1) "MEDIA" button

Display



NOTICE

Before connection, mute the unit, and also keep the volume of the auxiliary audio source within a range that will not cause distortion.
When the audio source is turned off, noise may be emitted. Be sure to turn off the unit or switch to another mode before turning off the audio source.


AUX selection

- 1) Touch the "MEDIA" button (1).
- Each time the button is touched, the mode will change as follows: USB (iPod[®]) (if equipped) → Bluetooth[®] audio (if equipped) → AUX (if equipped)


NOTE:


 Please consult your place of purchase for details about whether a given auxiliary audio source can be connected and the proper auxiliary cord to use.

Setting of Bluetooth[®] devices



5-25





(1) "TUNE/TRACK" Up/Down button (2) "ENT" (enter) button

- (3) BACK button
- (4) "SETUP" button
 (5) Bluetooth[®] button (if equipped)
- (6) Off-hook button
- (7) Talk button (if equipped)

A CAUTION

Do not register or set the Bluetooth[®] device while driving. Stop your vehicle in a safe area before registering the device.

NOTE:

Talk button (7) can be used with a device having a voice recognition function. To use the function, it is necessary to perform a corresponding setting on your device. For operation of the audio system or the navigation system, refer to the supplementary manual provided along with it.

Registration of Bluetooth[®] devices

To use Bluetooth[®] devices (Bluetooth[®] audio or mobile phone) on the audio system, it is required to register the Bluetooth[®] devices to the audio system. Up to 5 Bluetooth[®] devices can be registered.

NOTE:

72RM05002

• Some Bluetooth[®] enabled phones may not be compatible fully and or partially with the audio unit.

OTHER CONTROLS AND EQUIPMENT

- Bluetooth[®] / Telephone setup mode can be entered only when the vehicle is stationarv.
- Certain functions cannot be used depending on the Bluetooth[®] device.
- Refer to the user manual included with your device regarding the operation method of Bluetooth[®] devices.
- If the pairing cannot be established, the connection operation is canceled. For the Bluetooth[®] device pairing

method, refer to the user manual included with your device or try pairing again.

- 1) The Bluetooth[®] setting screen will be displayed.
- From the panel button: Touch the "SETUP" button (4). Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth", and touch the "ENT" button (2).
- From the steering switch Press the Bluetooth[®] button (5).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Bluetooth", and touch the "ENT" button (2).
- 3) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Pairing", and touch the "ENT" button (2).
- · The passkey will be displayed.
- 4) Operate and register the Bluetooth® device.
 - Secure Simple Pairing (SSP) incompatible Bluetooth[®] device: Enter the passkev into the Bluetooth[®]

5-26

device.

Secure Simple Pairing (SSP) compatible Bluetooth[®] device: Select "Yes" to register the Bluetooth[®] device.

 It is possible to automatically register devices depending on the type of Bluetooth[®] device.

NOTE:

5-27

- If the Bluetooth[®] device contains music player and mobile phone function, both functions will be registered simultaneously. When deleting a Bluetooth[®] device, both functions will be deleted simultaneously.
- If a mobile phone is not registered and the off-hook button (6) is pressed and the telephone mode is selected, it will automatically switch to "Pairing".
- When pairing with a mobile phone is established, it is possible to automatically transfer the phonebook and call history. If you wish to conduct an automatic transfer press "YES" and if not, press "NO".

Set from the list of mobile phones

The list of paired mobile phones is displayed and the various settings can be changed.

- The Bluetooth[®] setting screen will be displayed.
- From the panel button: Touch the "SETUP" button (4). Touch or slide the "TUNE/TRACK" Up/

Down button (1), select "Bluetooth", and touch the "ENT" button (2).

- From the steering switch: Press the Bluetooth[®] button (5).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Bluetooth", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "List Phone", and touch the "ENT" button (2).

Connect a registered mobile phone

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "List Phone" screen, select the name of the desired mobile phone, and touch the "ENT" button (2).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Select", and touch the "ENT" button (2).

Disconnect a connected mobile phone

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "List Phone" screen, select the name of the desired mobile phone, and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Disconnect", and touch the "ENT" button (2).
- 3) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and touch the "ENT" button (2).

Delete a registered mobile phone

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "List Phone" screen, select the name of the desired mobile phone, and touch the "ENT" button (2).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Delete", and touch the "ENT" button (2).
- 3) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and touch the "ENT" button (2).

Set from the Bluetooth[®] audio list

The list of paired Bluetooth[®] audio is displayed and the various settings can be changed.

- 1) The Bluetooth[®] setting screen will be displayed.
- From the panel button: Touch the "SETUP" button (4). Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth", and touch the "ENT" button (2).
- From the steering switch: Press the Bluetooth[®] button (5).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Bluetooth", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "List Audio", and touch the "ENT" button (2).

Connect a registered Bluetooth[®] audio

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "List Audio" screen, select the name of the desired Bluetooth[®] audio, and touch the "ENT" button (2).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Select", and touch the "ENT" button (2).

Disconnect a registered Bluetooth[®] audio

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "List Audio" screen, select the name of the desired Bluetooth[®] audio, and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Disconnect", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and touch the "ENT" button (2).

Delete a registered Bluetooth[®] audio

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "List Audio" screen, select the name of the desired Bluetooth[®] audio, and touch the "ENT" button (2).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Delete", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and touch the "ENT" button (2).

- NOTE:
 - In case audio device does not re-connect after following above steps, delete your audio device from registered list of audio by following steps 1) to 3) of "Delete a registered Bluetooth[®] audio" mentioned above. Register the audio device again by referring to "Registration of Bluetooth[®] devices" and follow steps 1) to 4).
 - Some audio device may not re-connect automatically. For such cases, follow steps 1) to 2) of "Connect a registered Bluetooth[®] audio" mentioned in further pages of this section.

Select a connection method

It is possible to switch connection methods when the Bluetooth[®] audio is registered to the audio system and the audio system and Bluetooth[®] audio are not connected.

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "List Audio" screen, select the name of the desired Bluetooth[®] audio, and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Connect Method", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the connection method, and touch the "ENT" button (2).

OTHER CONTROLS AND EQUIPMENT

· From Car:

Operate from the audio system to connect to the Bluetooth[®] device.

- From Audio: Operate from the Bluetooth[®] device to
- connect to the audio system.

Change of Passkey

- 1) The Bluetooth[®] setting screen will be displayed.
- From the panel button: Touch the "SETUP" button (4).
 Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth", and touch the "ENT" button (2).
- From the steering switch Press the Bluetooth[®] button (5).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Bluetooth", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Passkey", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select a number between 0 and 9, and touch the "ENT" button (2).
 - Repeat this operation several times.
- Enter the passkey one digit by one digit.
- The passkey must be between 4 to 8 digits.

5-28

- In order to cancel the number that you entered and return to the previous digit, touch the BACK button (3).
- If you do not enter a number that is 4 or more digits and re-touch the "ENT" button (2), the passkey will be registered.

Automatic connection with the $\mathsf{Bluetooth}^{\mathbb{R}}$ device

If the "Bluetooth Power" is set to ON, turning the ignition switch to ACC will automatically connect the registered Bluetooth[®] device.

- With the automatic connection, the Bluetooth[®] device that was connected last will be prioritized.
- The Bluetooth[®] setting screen will be displayed.
- From the panel button:

Touch the "SETUP" button (4). Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth", and touch the "ENT" button (2).

- From the steering switch: Press the Bluetooth button (5).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Bluetooth", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth Power", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "On" or "Off", and touch the "ENT" button (2).

NOTE:

- When "Bluetooth Power" is set to "OFF", the audio system disconnects from the registered Bluetooth[®] device.
- If "Bluetooth Power" is set to "Off", the audio system will not automatically reconnect the next time the ignition is switched on.

The device status will be displayed

- The Bluetooth[®] setting screen will be displayed.
- From the panel button: Touch the "SETUP" button (4). Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth", and touch the "ENT" button (2).
- From the steering switch: Press the Bluetooth button (5).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Bluetooth", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Úp/ Down button (1), select "Bluetooth Info", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the desired status, and touch the "ENT" button (2).
- To display the device name, select "Device Name".
- To display the device address, select "Device Address".

Initialize

It is possible to initialize the audio system's Bluetooth $^{\ensuremath{\mathbb{R}}}$ settings or device information.

- Do not initialize the settings while driving. Stop your vehicle in a safe area before initializing the device.
- Initialize with caution. Initialized settings and history cannot be restored.
- The Bluetooth[®] setting screen will be displayed.
- From the panel button: Touch the "SETUP" button (4). Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth", and touch the "ENT" button (2).
- From the steering switch: Press the Bluetooth button (5).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Bluetooth", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Initialize", and touch the "ENT" button (2).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the item that you want to initialize item, and touch the "ENT" button (2).

- HF Sound Setting:
- Reception/ringtone volume
- Incoming call volume
- Vehicle Device Info:
- Passkey
- All Initialize:
- Reception/ringtone volume
- Incoming call volume
- Bluetooth audio volume
- Pairing registration
- Phonebook/history
- Speed dial
- Connect Method
- Bluetooth Power
- Auto Transfer
- 5) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and touch the "ENT" button (2).

Notes on Bluetooth[®]



 The Bluetooth[®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Denso Ten Limited is under license. Other trademarks and trade names are those of their respective owners.

This telecommunication equipment conforms to the requirements of the National Telecommunications Commission.

 Stop using this unit and a Bluetooth[®] ready device whenever requested. This unit shares the communication frequency with other private or public wireless communication equipment such as a wireless LAN and other wireless communication radios.

You should stop using this unit immediately whenever you are notified that your unit disturbs other wireless communication.

OTHER CONTROLS AND EQUIPMENT

Profile

73R0209


- SSP (Secure Simple Pairing)
- PBAP (Phone Book Access Profile)
- OPP (Object Push Profile)
- HFP (Hand-Free Profile)
- A2DP (Advanced Audio Distribution Profile)
- AVRCP (Audio/Video Remote Control Profile)

Disclaimer for Bluetooth[®] function

- Depending on the mobile phone models, some phones may not be compatible fully or partially (some function may be restricted).
- Media playback through third-party applications may have limited support.
- Playback, display contents, connectivity or voice quality etc. may get affected depending on circumstances.
- After the ignition switch is turned to the "ON" position, the audio system takes few seconds to detect and connect to the Bluetooth[®] device (if already paired).
- Make sure that you are aware of all applicable local laws and accordingly use Bluetooth[®] device.


5-30


Bluetooth[®] hands-free (if equipped) To use Bluetooth[®] devices (Bluetooth[®] audio or mobile phone) on the audio sys-tem, it is required to register the Blue-tooth[®] devices to the audio system by "Bluetooth Settings".



Phonebook All Calls

73R0151





- (5) BACK button
- (6) "ENT" (enter) button
 (7) Bluetooth[®] setting button (if equipped) (8) Off-hook button (9) On-hook button

- (10) Mute button
 (11) "VOL" (volume) button
 (12) Talk button (if equipped)

5-31

Display

EXAMPLE

Phone

NOTICE

- Do not leave your mobile phone inside your vehicle. If the temperature inside the vehicle increases, it may damage your mobile phone.
- When disposing your vehicle, make sure to delete all personal information saved to the audio system.
- The following hands-free data must be deleted from the audio system. - Speed dial
- Reception history/Incoming call historv
- Bluetooth[®] phonebook data

NOTE:

Talk button (12) can be used with a device having a voice recognition function. To use the function, it is necessary to perform a corresponding setting on your device. For operation of the audio system or the navigation system, refer to the supplementary manual provided along with it.

NOTE:

- · Please keep your phone volume low. The person's voice who you are talking to may be heard outside of the vehicle and increase the voice echo. When talking on the phone, speak clearly towards the microphone.
- In the following cases, your voice may not be heard clearly by the person on the other line:

- When driving on unpaved roads. (If Up to 1.000 phone numbers can be there is loud traffic noise.)
- When driving at high speeds.
- When driving with the window open.
- If the air conditioner is blowing directly towards the microphone.
- When the sound of the air conditioner fan is loud
- When there is an adverse effect to the sound quality of the phone or network that you are using.
- · The audio system may not function under the following conditions.
- When the phone power is not turned
- When the mobile phone is out of service.
- When the mobile phone is not connected.
- When the mobile phone battery is low
- The Bluetooth's hands-free operation is dependent upon the mobile phone's compatibility.
- The Bluetooth's hands-free performance is affected by the driving conditions of mobile phone networks, handsets and vehicles.
- The audio system's performance may be restricted due to the model of your mobile phone.

It is possible to register a mobile phone and register the phone number to the audio system as follows:

- saved for every registered mobile phone.
- Up to 30 phone numbers can be saved to the call history menu (missed calls/ incoming/outgoing calls.)
- When the call history exceeds 30 calls, they are deleted from the oldest one first, and the latest call history information is displayed in descending order.
- Up to 6 phone numbers can be saved to the speed dial list.

Answer the phone

- 1) Press the off-hook button (8).
- When you press the on-hook button (9) during an incoming call, you can block the call. (Only for compatible phone units)

NOTE:

- If you receive a call from a registered phone, the caller's name will appear on the screen.
- · If you receive a call from an unregistered phone, only the caller's phone number will appear on the screen.

Hang up the phone

1) When the call is finished, press the onhook button (9).

Make a call on call waiting

When the screen is displayed during a call, it is possible to hold the call and answer the other incoming call.

- 1) When an incoming call is received during a call, press the off-hook button (8).
- When the call is on hold, it will connect to the other incoming call.
- To end the call waiting, press the offhook button (8).
- When the call waiting is completed, the call on hold will connect.
- When switching the caller, press the offhook button (8) again while using the call waiting.

NOTE:

This function can only be used with phone units that are compatible with call waiting.

Mute the ringtone volume

1) Press the mute button (10).

• To deactivate the mute volume, press the mute button (10).

Adjust the volume

Adjust the reception volume

- 1) Touch or slide the "VOLUME" button (4) or press the "VOL" button (11) during a call.
- To increase the volume, touch **I** or slide upwards.
- To decrease the volume, touch a or slide downwards.

NOTE:

The volume and microphone sensitivity settings vary depending on the specifications of each mobile phone.

Adjust the ringtone volume

- Touch or slide the "VOLUME" button (4) or press the "VOL" button (11) during an incoming call.
- To increase the volume, touch I or slide upwards.
- To decrease the volume, touch or slide downwards.

Adjust the volume with the Bluetooth[®] settings

- 1) Display the Bluetooth[®] setup menu.
- From the panel button: Touch the "SETUP" button (3). Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth", and touch the "ENT" button (6).
- From the steering switch: Press the Bluetooth[®] button (7).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Telephone", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "HF Sound Setting", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the item that you want to adjust, and touch the "ENT" button (6).
- Call Volume: Reception/ringtone volume
- Ringtone Volume: Incoming call volume

5) Touch or slide the "VOLUME" button (4).

- To increase the volume, touch 🖬 or slide upwards.
- To decrease the volume, touch and or slide downwards.

Make a call

Press the off-hook button (8) to enter the telephone mode.

Use the phonebook

- 1) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Phonebook", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the desired initials, and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the contact number, and touch the "ENT" button (6).
- If there are multiple phone numbers for a single contact, touch or slide the "TUNE/ TRACK" Up/Down button (1), select the phone number, and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Yes", and touch the "ENT" button (6) or press the off-hook button (8).

Use the call history

- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "All Calls," "Missed Calls", "Incoming Calls" or "Outgoing Calls" and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the contact number, and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Yes", and touch the "ENT" button (6) or press the off-hook button (8).

Use the speed dial

- 1) Press the Off-hook button (8) for 1 second or longer.
- Touch the desired speed dial button (2) (1-6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and then touch the "ENT" button (6) or press the Off-hook button (8).

NOTE:

Speed dial numbers must be registered before this function can be used.

Transfer/delete the phonebook

1) Display the Bluetooth[®] setup menu.

- From the panel button: Touch the "SETUP" button (3). Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth", and touch the "ENT" button (6).
- From the steering switch: Press the Bluetooth[®] button (7).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Telephone", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Phonebook", and touch the "ENT" button (6).

Transfer all contacts from your mobile phone

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "Setup Phonebook" screen, select "Add Contacts", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Overwrite All", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and touch the "ENT" button (6).

OTHER CONTROLS AND EQUIPMENT

Transfer 1 contact from your mobile phone

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "Setup Phonebook" screen, select "Add Contacts", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Add One Contact", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and touch the "ENT" button (6).

Delete the registered phonebook

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "Setup Phonebook" screen, select "Delete Contacts", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the desired initials from the list or "All", and touch the "ENT" button (6).
- When you select "All", it will transition to step 4.
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the desired name from the list, and touch the "ENT" button (6).
- 4) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and touch the "ENT" button (6).
 - 5-34

Transfer/delete the call history

- Display the Bluetooth[®] setup menu.
 From the panel button: Touch the "SETUP" button (3). Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth", and touch the "ENT" button (6).
- From the steering switch: Press the Bluetooth[®] button (7).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Telephone", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Call History", and touch the "ENT" button (6).

Transfer the call history

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "Setup Call History" screen, select "Overwrite History", and touch the "ENT" button (6).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and touch the "ENT" button (6).

Delete the call history

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "Setup Call History" screen, select "Delete History", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "All Calls", "Missed Calls", "Incoming Calls" or "Outgoing Calls" and touch the "ENT" button (6).
- Touch or slide the TUNE/TRACK Up/ Down button (1), select the desired data from the history or select "All", and then touch the "ENT" button (6).
- Touch or slide the "TUNE/TRÁCK" Up/ Down button (1), select "YES", and touch the "ENT" button (6).

Registration / deletion of speed dial

- 1) Display the Bluetooth[®] setup menu.
- From the panel button: Touch the "SETUP" button (3). Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth", and touch the "ENT" button (6).
- From the steering switch: Press the Bluetooth[®] button (7).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Telephone", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Speed Dials", and touch the "ENT" button (6).

Registration in speed dial

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "Setup Speed Dials" screen, select "Add Speed Dial", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the phonebook or call history, and touch the "ENT" button (6).
- When you select the call history, it will transition to step 4.
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the desired initials from the list and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the contact number, and touch the "ENT" button (6).
- If there are multiple phone numbers for a single contact, touch or slide the "TUNE/ TRACK" Up/Down button (1), select the phone number, and touch the "ENT" button (6).
- 5) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the speed dial number that you want to register, and touch the "ENT" button (6).

Deletion of speed dial

- Touch or slide the "TUNE/TRACK" Up/ Down button (1) from the "Setup Speed Dials" screen, select "Delete Speed Dials", and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select the speed dial number that you want to delete, and touch the "ENT" button (6).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "YES", and touch the "ENT" button (6).

Automatic transfer of the phonebook/ call history

When registering the mobile phone, you can select to automatically transfer the phonebook and call history from your device. Select according to the following steps.


- 1) Display the Bluetooth[®] setup menu.
- From the panel button: Touch the "SETUP" button (3). Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Bluetooth", and
- touch the "ENT" button (6).
 From the steering switch: Press the Bluetooth[®] button (7).
- 2) Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Setup Tele-
- phone", and touch the "ENT" button (6). 3) Touch or slide the "TUNE/TRACK" Up/
- Down button (1), select "Auto Transfer", and touch the "ENT" button (6).

 Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "On" or "Off", and touch the "ENT" button (6).

Bluetooth[®] audio

To use Bluetooth[®] devices (Bluetooth[®] audio or mobile phone) on the audio system, it is required to register the Bluetooth[®] devices to the audio system by "Bluetooth[®] Settings".

EXAMPLE




(1) "TUNE/TRACK" Up/Down button(2) "DISP/ENT" (display/enter) button

(3) BACK button

- (4) "FLD" (group operation) button
- (5) "SETUP" (random/repeat) button

(6) "MEDIA" button

Display



(A) Playback time

(B) Text information display

NOTE:

Some functions may not be usable on some ${\sf Bluetooth}^{\mathbb{R}}$ devices.

Selecting the Bluetooth[®] audio

1) Press the "MEDIA" button (6) for 1 second or more for changing from radio mode, or

Touch the "MEDIA" button (6) if the audio is in other than radio mode.

 Touch the "MEDIA" button (6). Each time the button is touched, the mode will change as follows:

USB (iPod[®]) (if equipped) \rightarrow Bluetooth[®] audio (if equipped) \rightarrow AUX (if equipped)

Fast forwarding/Rewinding a track

- 1) Hold down the "TUNE/TRACK" Up/ Down button (1).
- M: Hold down the Up button for 1 second or longer to fast forward the track.
- Image: Hold down the Down button for 1 second or longer to fast rewind the track.

5-36

• Releasing the button can stop the fast forwarding/rewinding.

Selecting a track

- 1) Touch the "TUNE/TRACK" Up/Down button (1).
- A : Touch the Up button to listen to the next track.
- Wen the Down button is touched once, the track currently being played will start from the beginning again. Touch the Down button twice to listen to the previous track.

Selecting a group (only for supported models)

- 1) Touch the "FLD" (group operation) button (4).
- 2) Touch the "TUNE/TRACK" Up/Down button (1).
- Touch the Up button to go to the next group.
- ■ : Touch the Down button to go to the previous group.

Repeat playback

- 1) Touch the "SETUP" (random/repeat) button (5).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Repeat", and touch the "DISP/ENT" button (2).
- Each time the "DISP/ENT" button (2) is touched, display will change as follows: Off → One song repeat → Group repeat (if available) ...

Random playback

- Touch the "SETUP" (random/repeat) button (5).
- Touch or slide the "TUNE/TRACK" Up/ Down button (1), select "Random", and touch the "DISP/ENT" button (2)
- Each time the "DISP/ENT" button (2) is touched, display will change as follows: Off → Group random → All random ...

Display change

- 1) Touch the "DISP/ENT" button (2).
- Each time the button is touched, display will change as follows: Artist name/Track title → Album name/ Track title ...

NOTE:

- "NO TITLE" will be displayed when there is no text information in the USB device currently being played.
- "..." is displayed if all text data cannot be displayed. Touch and hold the "DISP/ ENT" button (2) for at least one second to automatically display the rest of the text data.


Anti-Theft Feature

The anti-theft function is intended to discourage thefts, such as that the audio system becomes inoperable when it is installed on other vehicles.

This function works by entering a Personal Identification Number (PIN).

When the unit is disconnected from its power source, such as when the audio system is removed or the lead-acid battery is disconnected, the unit will become inoperable until the PIN is reentered.





- (1) POWER button(2) List selection button(3) "ENT" (enter) button
- (4) BACK button
- (5) PIN entry button (1-4)

5-37

Display



Setting the Anti-Theft Function

- 1) Touch the POWER button (1) for 1 second or longer to power off the audio system.
- 2) Hold down the button numbered [1] of the PIN entry button (5) and the "ENT" button (3) and touch the POWER button (1).
- "SECURITY" will be displayed.
- 3) Hold down the Up button of the List selection button (2) \square and the button numbered [1] of the PIN entry button (5). • "----" will be displayed.
- 4) Enter a 4-digit number to be registered as PIN using the buttons numbered [1] -[4] of the PIN entry button (5).
- 5) Touch the "ENT" button (3) for 1 second or longer.
- "COMPLETE" will be displayed, and the power will turns off after 3 seconds.

NOTE:

Take a note of the registered PIN and keep it for the future use.

Canceling the anti-theft feature

To cancel the anti-theft function, delete the registered PIN.

- 1) Touch the POWER button (1) for 1 second or longer to power off the audio svstem.
- 2) Hold down the buttons numbered [1] of the PIN entry button (5) and the "ENT" button (3) and touch the POWER button (1).
- "PIN ENTRY" will be displayed.
- 3) Hold down the Up button of the List selection button (2) And the button numbered [1] of the PIN entry button (5).
- "----" will be displayed.
- 4) Enter a 4-digit number to be registered as PIN using the buttons numbered [1] -[4] of the PIN entry button (5).
- 5) Touch the "ENT" button (3) for 1 second or longer.
- If an incorrect PIN is entered, "ERROR* (ERR Number)" will be displayed for 3 seconds, then the audio system will go back to step 2.
- "----" is displayed on the screen, and the power will turns off after 3 seconds.

NOTE:

- · To change your PIN, first delete your current PIN. then set a new one.
- If an incorrect PIN is entered 10 times or more, "HELP" will be displayed and the audio system will become inoperable. In this case, contact a Maruti Suzuki authorised workshop.

Confirming the Personal Identification Number (PIN)


When the main power source is disconnected such as when the lead-acid battery is replaced, etc, it is required to enter the PIN to make the unit operable again.

- 1) Set the ignition switch to the ACC position
- "SECURITY" will be displayed.
- 2) Hold down the Up button of the List selection button (2) \square and the button numbered [1] of the PIN entry button (5).
- "----" will be displayed.
- 3) Enter the registered 4-digit PIN number using the buttons numbered [1] - [4] of the PIN entry button (5).
- 4) Touch the "ENT" button (3) for 1 second or longer.
- If an incorrect PIN is entered, "ERROR* (ERR Number)" will be displayed for 3 seconds, then the audio system will go back to step 2.
- After 3 seconds, the power of the audio system will be turned off automatically and it will become operable again.

5-38

Steering Switch (if equipped)

Use the steering wheel button to operate the basic functions of the audio system.



- (1) "MODE" button
- (2) Selection button
 - Selecting the radio station
 Selecting the track (USB (iPod[®]),
 - Bluetooth[®] audio mode)

73R0157

- (3) Mute button
- (4) "VOL" (volume) button

MODE button (1)

Each time the button is pressed, the mode will change as follows:
 AM → FM1 → FM2 → USB (iPod[®]) (if equipped) → Bluetooth[®] audio (if equipped) → AUX (if equipped)

Selection button (2)

- FM1, FM2, AM mode:
 - Press > to transfer to the next preset channel.
 - Press < to transfer to the previous preset channel.
 - Press > for 1 second or longer, it will search for receivable stations at a high frequency.
 - Press < for 1 second or longer, it will search for receivable stations at a low frequency.
- USB (iPod[®]), Bluetooth[®] audio mode:
- Press > to transfer to the next song.
 With the folder operation mode, it will transfer to the next folder.
- Press < to return to the beginning of the currently playing song. Pressing it twice consecutively will return to the previous song.
- With the folder operation mode, it will return to the previous folder.
- Press > for 1 second or longer to fastforward the song.
- When the button is released, it will stop fast-forwarding.
- Press < for 1 second or longer to rewind the song.
- Releasing the button can stop rewinding.

Mute button (3)

- Hands-free mode
- Each time you press the button the mute will switch from ON/OFF.
- USB (iPod[®]), Bluetooth[®] audio mode: Press the button during playback to temporarily stop the playback.

"VOL" button (4)

- · Hands-free mode:
- Press during an outgoing or ingoing call, the reception/ringtone sound will decrease.
- Press during an outgoing call, the ringtone sound will increase.
- Press during an outgoing call, the ringtone sound will decrease.
- Radio, USB (iPod[®]), Bluetooth[®] audio, AUX mode:

Press . , the volume will increase. Press . , the volume will decrease.

5-39

Remote Controller

Operational precautions regarding remote controller use:

- Because of its small size and light weight, use the remote controller with care. Dropping the remote controller or hitting it against hard surfaces may degrade the battery and cause malfunction.
- Do not expose the remote controller to humidity, dust, or moisture. Do not subject the remote controller to shock.
- Do not place the remote controller on the dashboard or other places that can be exposed to high temperatures, such as near heater vents. Exposing the remote controller to conditions in which it may overheat may cause the case to deform or other issues.
- Do not operate the remote controller while driving. Doing so may result in an accident.
- Direct the remote controller towards the remote controller receiver when using the remote controller.
- The receiver may not operate correctly when exposed to direct sunlight or other sources of bright light.

(Continued)

A CAUTION


(Continued)

• Remove the battery from the remote controller if the remote controller if the remote controller will not be used for extended periods of time.

A CAUTION

- Cleaning the remote controller:
- Use a dry cloth to clean the remote controller. If the remote controller becomes excessively soiled, use a cloth dampened lightly with a diluted liquid detergent.
- Never use organic solvents, such as benzene cleanser or thinner. Use of these substances will damage the case and finish.


Before using the remote controller



OTHER CONTROLS AND EQUIPMENT

 Pull out the battery insulated sheet tab from the remote controller in the direction indicated by the arrow.

Remote controller operation



5-40

No.	Button	Function
(1)	U	 POWER button: Turns the power to the audio system on / off (press and hold)
(2)	Y	Mute button: Sound mute on / off
(3)	MODE	 MODE button: Switches between audio sources The mode changes in the following order each time the button is pressed: AM → FM1 → FM2 → USB (iPod[®]) (if equipped) → Bluetooth[®] audio → AUX (if equipped) NOTE: "No Audio" will be displayed when there is no Bluetooth device connected.
(4)		 Volume buttons: Volume up / Continuous volume up (press and hold)
(5)	\checkmark	 Volume buttons: Volume down / Continuous volume down (press and hold)
(6)		 TUNE/TRACK up button: RADIO: Tune up / Seek up (press and hold) USB, iPod[®], and Bluetooth[®] audio: – Normal mode: Track (file) up / Fast up (press and hold) FLD mode (USB and Bluetooth[®] audio): Folder (Group) up / Fast up (press and hold) FLD mode (iPod[®]): List up / Continuous list up (press and hold) FUNCTION mode (various settings): Configures functions / Change values

5-41

No.	Button	Function	
(7)	(11)	 TUNE/TRACK down button: RADIO: Tune down / Seek down (press and hold) USB, iPod[®], and Bluetooth[®] audio: – Normal mode: Track (file) down / Fast down (press and hold) FLD mode (USB and Bluetooth[®] audio): Folder (Group) down / Fast down (press and hold) FLD mode (iPod[®]): List down / Continuous list down (press and hold) FUNCTION mode (various settings): Configures functions / Change values 	
(8)	SETUP	SETUP button: • Switch to the System setting mode	
(9)	AS	Auto Store button: RADIO: Switches between manual preset and AS mode / Auto Store (press and hold)	
(10)	DISP	DISP button: • Changes text displays / Changes automatic text display pages (press and hold)	
(11)	1	 Preset [1] button: RADIO: Calls preset channels / Stores channel as preset (press and hold) 	
(12)	2	 Preset [2] button: RADIO: Calls preset channels / Stores channel as preset (press and hold) 	
(13)	3	 Preset [3] button: RADIO: Calls preset channels / Stores channel as preset (press and hold) 	

No.	Button	Function
(14)	4 FLD	 Preset [4] / FLD button: RADIO: Calls preset channels / Stores channel as preset (press and hold) USB, iPod[®], and Bluetooth[®] audio: Switches between Folder operation / iPod[®] menus / Group operation mode
(15)	5 BACK	 Preset [5] / BACK button: RADIO: Calls preset channels / Stores channel as preset (press and hold) USB, iPod[®], Bluetooth[®] audio, and settings: Switches back to the previous screen
(16)	6 ENT	 Preset [6] / ENTER button: RADIO: Calls preset channels / Stores channel as preset (press and hold) USB, iPod[®], Bluetooth[®] audio, and settings: Sets the selected item


5-43

Battery replacement


- Store batteries in their original packaging out of reach of children until ready for use. Discard used batteries immediately. Seek medical attention immediately if swallowed.
- Do not place batteries in locations near fire or exposed to direct sunlight. Doing so may result in fire, explosion, or excessive heat.
- Do not place the remote controller on the dashboard or other places that can be exposed to high temperatures.
- Accidentally replacing batteries with lithium-ion batteries may result in explosion. Always replace batteries with the same type.

 Use a Phillips screwdriver (sold separately) of the proper size to remove the screw and pull out the battery slot cover in the direction indicated by the arrow.


EXAMPLE



2) Remove the old battery and place the new battery (CR2025) into the battery slot cover with the + mark facing upwards.



 Press the battery slot cover to the direction indicated by the arrow completely and then fully tighten the screw.



5-44

Troubleshooting When encountered a problem, check and follow the instructions as described below. If the described suggestions do not solve the problem, it is recommended to take the unit to a Maruti Suzuki authorised workshop.

Problem	Possible cause	Possible solution
---------	----------------	-------------------

Common

Unable to operate	The security function is on.	When "SECURITY" is displayed, enter the ID. When "HELP" is displayed, contact a Maruti Suzuki authorised workshop.
Unable to turn on the power (no sound). (No sound is produced)	Fuse is blown.	Contact a Maruti Suzuki authorised workshop.

Radio

Much noise	It may not be exactly tuned in to the station.	Tune it in exactly to the station.
Unable to receive by auto tuning	There may be no station emitting signals powerful enough.	Pick up a station by manual tuning.

USB

Playback does not start	There is no supported format file to play on this unit.	Check the file format.
when the USB device is connected.	The current consumption of the USB device exceeds 1.0 A.	Use an USB device with a current consumption lower than 1.0 A.
Sound skips or noise produced	Sound skipping may occur when playing VBR (Variable Bit Rate) files.	It is not recommended to play VBR files.

Problem	Possible cause	Possible solution
Bluetooth [®]		
Deiring failed	The distance between this unit and the Bluetooth [®] ready device is too far, or a metallic object may be located between the Bluetooth [®] ready device and this unit.	Change the location of the Bluetooth [®] ready device.
Pairing failed -	The Bluetooth [®] function of the Bluetooth [®] ready device is off.	Refer to the manual of the Bluetooth [®] ready device. (Some devices have the power saving function that automatically activates after a certain time.)
Unable to receive a call	Your current location may be out of service area.	Drive your vehicle to the service area of the phone.
The voice quality of hands-free is low (Distortion, noise etc.)	Another wireless device may be located near the unit.	Switch off the wireless device or keep it away from the unit.

5-46


Error Display Messages The following messages (flashing) will be displayed onto the screen depending on the condition of the audio system.

Message	Description	
Reading	When the USB device or iPod [®] file format is being read,, this message will be displayed.	
ERROR 1 When the USB device or iPod [®] reading error occurs, this message will be displayed Reconnect the USB device or iPod [®] connection cable. When the Bluetooth [®] audio playback malfunction occurs, this message will be disp Check the Bluetooth [®] audio body.		
ERROR 2	When the USB device or iPod [®] communication error occurs, this message will be displayed. Reconnect the USB device or iPod [®] connection cable.	
ERROR 3	When the USB device or iPod [®] issues are detected, this message will be displayed. Remove the USB device or iPod [®] , and check the USB device or the iPod [®] .	
ERROR 4	If the USB device or iPod [®] does not operate due to an over current, this message will be displayed. Remove the USB device or iPod [®] , and check the USB device or the iPod [®] .	
ERROR 5When the data playback fails with the USB device or iPod [®] connected, or there are dat to be transferred, this message will be displayed. Remove the USB device or iPod [®] , and check the USB device or the iPod [®] .		
ERROR 6 When the USB HUB is connected, this message will be displayed. Disconnect the USB HUB.		
UNSUPPORTED When an unsupported USB device or iPod [®] is connected, this message will be di Connect the supported USB device or iPod [®] .		
When an empty USB device or a USB device containing files with the extension unable played is connected, this message will be displayed. Connect the USB device containing files with the playable extension.		
No Songs	When an iPod [®] is connected, this message will be displayed.	


5-47

Fuel Filler Cap

EXAMPLE



The fuel filler cap is located on the left rear side of the vehicle. The fuel filler door can be unlocked by pulling up the opener lever located on the outboard lower side of the driver's seat and locked by simply closing the door.



To remove the fuel filler cap:

1) Stop the engine and close all the doors and windows while refueling.


2) Open the fuel filler door.

73R0084

3) Remove the cap by turning it counterclockwise.

A CAUTION

Remove the fuel filler cap slowly. The fuel may be under pressure and may spray out, causing injury.



NOTE:

The cap holder (1) holds the fuel filler cap (2) by hooking the groove (3) when refueling.

- To reinstall the fuel filler cap: 1) Turn the cap clockwise until you hear several clicks.
- 2) Close the fuel filler door.

WARNING

Fuel is extremely flammable. Do not smoke when refueling, and make sure there are no open flames or sparks in the area.

5-48


A WARNING

If you need to replace the fuel cap, use a MARUTI SUZUKI genuine cap. Use of an improper cap can result in a malfunction of the fuel system or emission control system. It may also result in fuel leakage while driving and in the event of an accident.

Engine Hood


A WARNING

- Never allow children to open or close the hood. Children may injure themselves because the hood is heavy. Contact with the engine compartment and related parts may cause burns when this area/these parts are hot.
- Do not allow children to be near the vehicle when opening the hood.
- Do not leave tools, cloths, and other objects, which were used to clean or perform maintenance and inspections, in the engine compartment. Doing so may cause operational failures or even the vehicle to catch fire when the engine compartment becomes hot.



To open the engine hood:

 Pull the hood release handle located under the driver's side instrument panel in the outboard position. This will disengage the engine hood lock halfway.



 Push the under-hood release lever leftward with your finger, as shown in the illustration. While pushing the lever, lift up the engine hood.

A CAUTION


The release lever and its peripheral, or engine hood can be hot enough to burn your finger right after driving. Touch after those becomes cool enough.

73R0086

5-49

NOTICE

Check that the wiper arms are not raised before you lift up the engine hood to avoid damaging the wiper arms and the engine hood.



3) While holding the hood, pull the prop rod out from the holding clip by protector (1), and then insert the end of the


rod into the designated hole.

A CAUTION

- The prop rod can be hot enough to burn your finger right after driving. Hold the prop rod by protector (1)
- Insert the end of the rod into the hole securely. If the rod slips out, you may get caught in the closing hood.
- The rod may slip out when the hood is blown by wind. Be careful on windy days.

To close the engine hood:

1) Lift the hood up slightly and remove the prop rod from the hole. Put the prop rod back to the holding clip.



2) Lower the hood to about 20 cm above the hood latch, and then let it drop down. Make sure the hood is securely latched after closing.



Make sure the hood is fully closed and latched before driving. If it is not, it can fly up unexpectedly during driving, obstructing your view and resulting in an accident.


A CAUTION

To avoid injury, check that no part of the occupant's body such as hands or head is in the path of the hood when closing it.

NOTICE

Pushing on the hood from the top may damage it.

Sun Visor



The sun visors can be pulled down to block glare coming through the windshield, or they can be unhooked and turned to the side to block glare coming through the side window.

NOTICE

When unhooking and hooking a sun visor, handle it by the hard plastic parts or the sun visor can be damaged. Card holder EXAMPLE (1) 74LHT0516


(1) Card holder

You can put a card in the card holder (1) on the back of the sun visor.

NOTICE

When you park your vehicle outdoors in direct sunlight or in hot weather, do not leave plastic cards in the holder. The heat may distort them.


5-51




(1) Vanity mirror

A WARNING

- Do not use the vanity mirror while driving. Doing so may result in an accident due to failure to pay attention to the road in front of you.
- Do not place any object on the location where an airbag is stored or come close to the location where airbag is stored, when using a vanity mirror. Doing so may cause the airbag to deploy and cause serious injury due to the impact of airbag.



Front (Type B)



Interior light switch has three positions which function as described below:

ON (1)

The light comes on and stays on regardless of whether the door is open or closed.

NOTE:

The light will automatically be turned off to prevent the lead-acid battery from discharging when the following conditions are simultaneously met:

- The ignition switch is in "LOCK" position, or the ignition mode is "LOCK" (OFF).
- The hazard warning lights, the position lights and the headlights are off.

• After 15 minutes from the light on.


5-52

DOOR (2)

- The light comes on when the door is opened. After closing all doors, the light will remain on for 15 seconds and then fade out. If you insert the key, or press the engine switch to change the ignition mode to "ACC" or "ON" during this time, the light will start to fade out immediately. After removing the key from the ignition switch or press the engine switch to change the ignition mode to "LOCK" (OFF), the light will turn on for 15 seconds and then fade out.
- When the ignition switch is in LOCK position, or the ignition mode is "LOCK" (OFF), to prevent the lead-acid battery from discharging, the light will automatically be turned off when a period of 15 minutes has elapsed after any of the doors (including the tailgate) is opened and other operations are not done.

OFF (3)


The light remains off even when the door is opened.



NOTE:


The number of doors involved in the lighting operation of the interior light depends on the vehicle specification. If there is a switch (rubber projection) at the door opening as shown, the door is involved in the lighting operation. The tailgate is also involved in this operation even without the rubber projection depending on the vehicle specification.

Accessory Socket



Floor Console (if equipped)


Type A



73R0093

The accessory socket will work when the ignition switch is in ACC or ON position, or the ignition mode is "ACC" or "ON". Each socket can be used to provide 12 volt/120 watt/10 ampere power for electrical accessories when used alone.


Type B



72R0047

3rd Row Seats (if equipped)

EXAMPLE



If you pay too much attention to operating the Accessory socket while driving, an accident can occur.

A CAUTION

All accessory sockets together have a power rating of 120 watt/10 ampere combined. Total load at one time on all ACC sockets should not be more than 120 watt.

NOTICE

- Use of inappropriate electrical accessories can cause damage to your vehicle's electrical system. Check that any electrical accessories you use are designed to plug into this type of socket.
- Always close the cap on the socket when the socket is not in use.
- When the ignition switch is in "LOCK" position or the ignition mode is LOCK (OFF) while using the accessory socket, the following may occur;
- the audio or navigation system does not turn off.
- the keyless entry system does not work, etc.

If they occur, disconnect the item from the accessory socket and check whether the electrical equipments work properly.

If the problem persists, ask a Maruti Suzuki authorised workshop to have the system inspected.




Assist Grips

3rd Row Seat

Front Passenger's Seat / 2rd Row Seat

EXAMPLE



54G249

EXAMPLE

Assist grips are provided for convenience.

NOTICE

To avoid damaging the assist grip and the molded headlining, do not hang down the assist grip. **Glove Box**

EXAMPLE



73R0095

To open the glove box, pull the latch lever. To close it, push the lid until it latches securely.

WARNING

Never drive with the glove box lid open. It could cause injury if an accident occurs.

5-55


Do not leave cigarette lighters or spray cans in the glove box. If a cigarette lighter or spray can is in a place such as the glove box, it may light accidentally when luggage is loaded, causing a fire.

WARNING

Do not drive the vehicle with the lid of glove box open.

AUX/USB Socket (if equipped)

EXAMPLE



Do not put items in the vehicle that may fall or roll around in the vehicle while driving. Objects getting caught in the brake pedal or accelerator pedal may prevent proper operation of the pedals, which may result in an accident.

Connect your portable digital music player, etc. to this socket to enjoy music through the vehicle's audio system. Refer to "Audio system (if equipped)" in this section.

NOTICE

Always close the cap when not in use, since entry of foreign material, dust, water, conductive liquids may damage the audio system or USB device.

WARNING


If you pay too much attention to operating the AUX/USB socket while driving, an accident may occur.

5-56


Cup Holder and Storage Area

3rd Row Seats

Front



EXAMPLE



A WARNING

Failure to take the precautions listed below could cause personal injury or vehicle damage.

• Be careful when you are using the cup holders to hold a cup containing hot liquid. Spilling out hot liquid can cause burn injury.

In addition, liquids spilling on the lithium-ion battery in models equipped with ENG A-STOP system or Smart Hybrid may cause a fire or electric shock or damage to the battery.

- Do not use the cup holders to hold sharp-edged, hard, or breakable objects. Objects in the cup holders may be thrown about during a sudden stop or impact, and could cause personal injury.
- Be careful not to spill liquid or insert any foreign materials into the moving part of the gearshift lever, or any electrical components. Liquid or foreign materials may damage these parts.
- If you spill, or drop liquid accidentally, have your vehicle inspected by a Maruti Suzuki authorised workshop.

Ventilated cup holder

If you turn on the air conditioning system, air flow comes out of the cup holder outlet. Air flow prevent the temperature of the drink from increasing.


Turn the dial wheel (1) clockwise, the cup holder outlet will open.

Turn the dial wheel(1) counterclockwise, the cup holder outlet will close.

NOTE:

- The temperature of air flow in cup holder is about the same with the center outlet.
- There is no effect to cool the drink in the cup holder.

5-57




You should hold a bottle with a cap in the holder.

5-58

72R0045


Rear Armrest (if equipped)



The rear armrest is stowed in the center of the seatback. Tilt it down forward to use.

WARNING

If the seat belt is obstructed by any part of the armrest when fastened, it cannot provide the intended protection. After fastening the seat belt, always check that the armrest is not interfering with the belt.



Pull the upper portion of the holder, downward to open the cover.


It is recommended to separate coins (2) and bills (3) with partition.

The holder can also be used after sliding out and removing the partition plate (1). Push the upper portion of the holder, upward to close the cover.

A WARNING

Never drive with the bill/coin holder lid open. It could cause injury if an accident occurs.


Footrest (if equipped)



Use the footrest (1) (only for driver side) as a support for your left foot (only).

5-59

Front Seat Back Pocket (if equipped)




This pocket is provided for holding light and soft things such as gloves, newspapers or magazines.

A CAUTION

Do not put hard or breakable objects in the pocket. If an accident occurs, objects such as bottles, cans, etc. can injure the occupants in the rear seat.

Luggage Box (if equipped)



Insert your hands into the notches and lift up the luggage box cover to use the box.

NOTICE

Do not allow items in the box to extend above the top of the box. Otherwise, the box or cover may be damaged.

NOTICE

Observe the following instructions, not to break the luggage box cover.

- Do not hold open the cover while driving.
- Do not apply any load to the cover while holding it open.

OTHER CONTROLS AND EQUIPMENT

Frame Hooks

It is not recommended that you use the frame hooks for towing another vehicle. They were originally designed to tow your vehicle in emergency situation.

If your vehicle needs to be towed in an emergency, refer to "Towing your vehicle" in "EMERGENCY SERVICE" section.

WARNING


Observe the following instructions when using frame hooks. The towing eye or vehicle body may break and cause serious injury or damage:

- Do not use the frame hooks for towing another vehicle.
- Avoid pulling the vehicle to get out of severe snowy, muddy or sandy conditions, sudden starts or erratic driving maneuvers which could cause excessive stress on the towing eye.

In such case, we recommend that you contact a professional service.

5-60


Front




The towing eye (1) is provided on the front of the vehicle for use in emergency situations and sea shipping purpose only.

NOTICE

To prevent damage to the vehicle, never use the towing eye (1) for trailer / train shipping. To install the hook (1), follow the procedure below.




 Pick up the towing eye (1), jack handle (A) and wheel wrench (B) in the luggage compartment.



2) Remove the cover (C) by using a jack handle (A) covered with a soft cloth as shown in the illustration.

NOTE:


Do not use excessive force as it may damage the cover strap.



3) Install the towing eye (1) by hand.

NOTE:

It is recommended to secure the cover with tape to prevent damage during towing.




 To tighten the towing eye (1), turn it clockwise by using a wheel wrench (B) until the towing eye (1) is securely installed.

To remove the towing eye (1), reverse the installation procedure.

Rear

EXAMPLE




The frame hook (2) is provided on the rear of the vehicle for use in emergency situations and sea shipping purposes only.

NOTICE

To prevent damage to the vehicle, never use the frame hook (2) for trailer / train shipping.

5-62

Other Holes



The frame holes (3) are provided only for transporting by a car carrier trailer.

NOTICE

Do not use the frame holes (3) for towing purpose. These holes may break and cause serious injury or damage.

5-63



72RM06000

INSPECTION AND MAINTENANCE

INSPECTION AND MAINTENANCE

Maintenance Schedule	6-2
Periodic Maintenance Schedule	6-2
Drive Belt	6-6
Engine Oil and Filter	6-7
Engine Coolant	6-10
Air Cleaner	6-12
Spark Plugs	6-12
Gear Oil	6-14
Clutch Pedal	6-15
Fuel Filter	
Automatic Transmission (AT) Fluid	6-15
Brakes	6-17
Steering Wheel	6-19
Tires	6-19
Lead-acid Battery	6-22
Fuses	6-24
Headlight Aiming	6-28
Bulb Replacement	6-28
Wiper Blades	6-34
Windshield Washer Fluid	6-36
Air Conditioning System	6-37

EXAMPLE



WARNING

Take extreme care when working on your vehicle to prevent accidental injury. Carefully observe the following precautions:

 To prevent damage or unintended activation of the airbag system or seat belt pretensioner system, be sure that the lead-acid battery is disconnected and the ignition switch has been in LOCK position or the ignition mode has been "LOCK" (OFF) for at least 90 seconds before performing any electrical service work on your MARUTI SUZUKI vehicle. Do not touch airbag system components, seat belt pretensioner system components or wires. The wires are wrapped with yellow

tape or yellow tubing, and the couplers are yellow for easy identification. (Continued) A WARNING

(Continued)

- Do not leave the engine running in garages or other confined areas.
- When the engine is running, keep hands, clothing, tools, and other objects away from the fan and drive belt. Even though the fan may not be moving, it can automatically turn on without warning.
- When it is necessary to perform service work with the engine running, make sure that the parking brake is set fully and the transmission is in Neutral (for manual transmission vehicles) or Park (for automatic transmission vehicles).
- Do not touch ignition wires or other ignition system parts when starting the engine or when the engine is running, or you could receive an electric shock.
- Be careful not to touch a hot engine, exhaust manifold and pipes, muffler, radiator and water hoses.
- Do not allow smoking, sparks, or flames around fuel or the lead-acid battery. Flammable fumes are present.

(Continued)

(Continued)

- Do not get under your vehicle if it is supported only with the portable jack provided in your vehicle.
- Be careful not to cause accidental short circuits between the positive and negative lead-acid battery terminals.
- Keep used oil, coolant, and other fluids away from children and pets. Dispose of used fluids properly; never pour them on the ground, into sewers, etc.

Maintenance Schedule

The following table shows the times when you should perform regular maintenance on your vehicle. This table shows in kilometers and months when you should perform inspections, adjustments, lubrication and other services.

A WARNING

MARUTI SUZUKI recommends that maintenance on your Maruti Suzuki vehicle should be performed by a Maruti Suzuki authorised workshop.

NOTICE

Whenever it becomes necessary to replace parts on your vehicle, it is recommended that you use MARUTI SUZUKI genuine replacement parts or their equivalent.

INSPECTION AND MAINTENANCE

Periodic Maintenance

Schedule

"C": Clean

- "R": Replace or Change
- "I": Inspect, clean, adjust, lubricate or replace as necessary
- "L": Lubricate
- "T": Tighten to Specified Torque

"O": Rotate

NOTE:

This table includes services as scheduled up to 80,000 km mileage. Beyond 80,000 km, carry out the same services at the same intervals respectively.

6-2

	nterval: This interval should be judged by odom- ter reading or months, whichever comes first.		FRE	E INSPE	CTION	PERIODIC MAINTENANCE AT COST							
Interv eter re			1	5	10	20	30	40	50	60	70	80	
010.11		months	1	6	12	24	36	48	60	72	84	96	
ENGI	NE			•			•		•	•	•		
1-1	Water pump drive belt (Tension, Wear)	Non-ISG model	-	-	I	I	I	I	I	I	I	R	
• •		ISG model	-	-	I	I	R	I	I	R	I	I	
1-2	Engine Coolant (Level, Leakage)		1	I	I	R	I	R	I	R	I	R	
1-3	Engine oil, engine oil filter and drain plu	ig gasket (Level, Leakage)	I	I	R	R	R	R	R	R	R	R	
1-4	Cooling system hoses and connections	(Leakage and Damage)	I	I	I	I	I	I	I	I	I	I	
1-5	Engine Mounting & manifold fixing (Loo	ose, Damage)	-	-	I	-	I	-	I	-	I	-	
1-6	Valve Clearance	CNG	-	-	-	I	-	I	-	I	-	I	
. 0		Petrol	-	-	-	-	I	-	-	I	-	-	
1-7	Exhaust System (Noise, Leakage etc.)	-	-	I	-	I	-	I	-	I	-	I	
1-8	Positive Crank Case Ventilation System (Hoses, Connections and Valve)	n	-	I	-	I	-	I	-	I	-	I	
IGNIT	TION												
2-1	Ignition wire (Damage, Deterioration)		-	-	-	1	-	I	-	I	-	I	
2-2	Spark Plug		-	-	-	- 1	-	R	-	-	-	R	
FUEL											•		
3-1	Air cleaner filter element Paved-road		Clean after every 5,000 KM. Replace after every 40,000 KM.										
5-1	Dusty		Clean a	Clean after every 2,500 KM or as required. Replace after every 40,000 KM.									
3-2	Fuel tank cap, fuel lines and connection	ns (Leakage and Damage)	-	I	-	-	-	I	-	-	-	I	
3-3	Fuel Filter (Leakage)		-	-	-	-	-	R	-	-	-	R	
CLUT	CH AND TRANSMISSION		÷										
4-1.	Clutch fluid (Level, Leakage)	Clutch fluid (Level, Leakage)		I	I	R	I	R	I	R	I	R	
4-2.	Clutch slipping (Dragging or Excess Damage)		I	I	I	I	I	I	I	I	I	I	
4-3.	Manual Transaxle Oil (Level, Leakage)			I	I		I	I	I	I	I	I	
4-4.	Automatic Transaxle Fluid (Level, Leak	age)	Replac	e at 1,65,	000 km o	or 11 years	s whichev	er come	s first				
4-5.	Hose, Automatic Transaxle Fluid		I	I	I	I	I	I	I	I	I	I	
4-6.	Gear shifter (Operation)						I	I	I	I		I	

			FRE	E INSPEC	CTION		PER	IODIC M/	AINTENA	NCE AT	COST	
Interval: This interval should be judged by odom- eter reading or months, whichever comes first.		km (x1000)	1	5	10	20	30	40	50	60	70	80
		months	1	6	12	24	36	48	60	72	84	96
DRIVE	SHAFT				•	•	•			•	•	
5-1. I	Drive shaft noise		I	I	I	I	I	I	I	I	I	I
5-2. I	Drive shaft boot (boot damage)		-	I	I	I	I	I	I	I	I	I
BRAK	E											
6-1. I	Brake Fluid (Level, Leakage)		I	I	I	R	I	R	I	R	I	R
6-2. I	Brake pedal (Pedal - wall clearance)		I	I	I	I	I	I	I	I	I	I
6-3. I	Parking brake lever and cable (Play, Dama	ige)	I	I	I	I	I	I	I	I	I	I
6-4. I	Brake disc and pad (Wear)		-	I	I	I	I	I	I	I	I	I
6-5. I	Brake drum and shoes (Wear)		-	-	I	I	I	1	I	I	I	I
6-6. I	Brake hoses and pipes (Fluid leakage, Da	mage)	I	I	I	I	I	I	I	I	I	I
6-7.	Master cylinder, wheel cylinder and caliper piston (Fluid leakage, Boot/Seal damage)			I	I	I	I	I	I	I	I	I
WHEE	L											
7-1.	Tires (Air pressure, Abnormal wear, Crack	and Rotation)	1	I&O	I&O	I&O	1&O	1&0	I&O	1&O	1&O	1&0
7-2.	Wheels (Damage)		1	I	1	1	I	1	1	1	I	1
7-3. I	Front/Rear wheel bearing (Loose, Damage	:)	1	I	1	1	I	I	I	1	I	I
FRON	Γ / REAR SUSPENSION											
8-1.	Suspension strut (Oil leakage, Damage)		I	I	1	1	I		I	1	I	I
8-2.	Suspension arms / Knuckle support and To	orsion rods (Loose, Damage)	- 1	I	I	I	I	I	I	I	I	I
8-3. I	Rear spring (Damage)		1	I	1	I	I	1	I	I	I	I
8-4.	Shock absorbers (Oil leakage, Damage)		I	I	I	I	I	I	I	I	I	I
8-5. /	5. All bolts and nuts (Loose)			Т	Т	Т	Т	Т	Т	Т	Т	Т
STEER	RING											
9-1.	Steering wheel (Play, Loose)		I	I	I	I	I	I	I	I	I	I
9-2.	All rods and arms (Loose, Damage, Wear)		Ι	I	I	I	I	I	I	I	I	I
9-3.	Tilt Steering (Operation)		I	I	I	I	I	Ι	I	I	I	I

6-4

· · · · - · · · · · · · · · · · · · · · ·		FREE	E INSPEC	CTION	PERIODIC MAINTENANCE AT COST						
Interval: This interval should be judged by odom- eter reading or months, whichever comes first.	km (x1000)	1	5	10	20	30	40	50	60	70	80
	months	1	6	12	24	36	48	60	72	84	96
ELECTRICAL	•	•									
10-1. Battery - electrolyte (Level, leakage) and v	oltage	I	I	I		I	I	I	I	I	I
10-2. Wiring harness connection (Loose, Damag	e)	-	I	I	I	I	I	I	I	I	Ι
10-3. Lighting system (Operation, Stains, Damag	le)	I	I	I	I	I	I	I	I	I	-
10-4. Wiper (Operation, Stains, Damage)		I	I	I	1	I	I	I	I	I	I
10-5. Horn (Operation)		I	I	I	I	I	I	I	I	I	I
10-6. AUX, USB and accessory socket (Operation	on)	-	I	I	I	I	I	I	I	I	-
BODY				•				•			
11-1. All chassis bolts and nuts (Tighten)		-	Т	Т	Т	Т	Т	Т	Т	Т	Т
11-2. All latches, hinges and locks (Function)	. All latches, hinges and locks (Function)			I&L	I&L	I&L	I&L	I&L	I&L	I&L	I&L
ROAD TEST											
12-1. Operation of Brakes, gear shifting and spe	edometer	I	I	I	I	I	I	I	I	I	I
12-2. Body and chassis noise		1	I	I	1	I	I	I	I	I	
AIR CONDITIONER											
13-1. Check belt tension		I	I	I	I	I	I	I	I	I	I
13-2. Tighten compressor mounting bolt		-	Т	Т	Т	Т	Т	Т	Т	Т	Т
13-3. All hose joint (Check, Tighten)		I	I	I	I	I	I	I	I	I	I
13-4. Check functioning of Recirculating flap	Check functioning of Recirculating flap		I	I	I	I	I	I	I	I	I
13-5. Clean condenser with low pressure water	Clean condenser with low pressure water		С	С	С	С	С	С	С	С	С
13-6. Check belt for frayed edges		I	I	I	I	I	I	I	I	I	I
13-7. Check all mounting bolts		I	I	I	I	I	I	I	I	I	I
13-8. Air conditioner filter element		1	I	I	I	R	I	1	R	I	I


Drive Belt

When the engine is running, keep hands, hair, clothing, tools, etc. away from the moving fan and drive belts.

Check that the drive belt tension is correct while the engine is stopped. If the belt is too loose, insufficient lead-acid battery charging, engine overheating, poor air conditioning, or excessive belt wear can result. When you push the belt with your thumb midpoint between the pulleys, there should be a deflection according to the following chart.

The belts should also be examined to ensure that they are not damaged.

If you need to replace or adjust the belt have it done by a Maruti Suzuki authorised workshop.



1) Vehicle front

2) Vehicle rear

3) Generator

4) Water pump

5) Tensioner pulley

6) Air conditioner compressor

Drive belt deflection

(100 N (10 kg, 22 lbs) press)

(a) New:

4.8 - 5.9 mm (0.19 - 0.23 in.) Readjustment: 7.2 - 8.2 mm (0.28 - 0.32 in.)

(b) New:

3.2 - 3.9 mm (0.12 - 0.15 in.) Readjustment: 4.8 - 5.6 mm (0.19 - 0.22 in.)

(With ISG model)


The drive belts tension is adjusted automatically.


6-6

Engine Oil and Filter

Oil Level Check

Specified Oil








Check that the engine oil you use comes under the quality classification of SN. Select the appropriate oil viscosity according to the above chart.

SAE 0W-16 (1) is the best choice for good fuel economy and good startability in cold weather.

NOTE:

We recommend that you use MARUTI SUZUKI genuine oil. To purchase it, visit a Maruti Suzuki authorised workshop.



It is important to keep the engine oil at the correct level for proper lubrication of your vehicle's engine. Check the oil level with the vehicle on a level surface. The oil level indication may be inaccurate if the vehicle is on a slope. The oil level should be checked either before starting the engine or at least 5 minutes after stopping the engine.


The handle of the engine oil dipstick is colored with yellow for easy identification.

Pull out the oil dipstick, wipe oil off with a clean cloth, insert the dipstick all the way into the engine, then remove it again. The oil on the stick should be between the upper and lower limits shown on the stick. If the oil level indication is near the lower limit, add enough oil to raise the level to the upper limit.

NOTICE


Failure to check the oil level regularly could lead to serious engine trouble due to insufficient oil.

Refilling



Remove the oil filler cap and pour oil slowly through the filler hole to bring the oil level to the upper limit on the dipstick. Be careful not to overfill the oil. Too much oil is almost as bad as too little oil. After refilling, start the engine and allow it to idle for about a minute. Stop the engine, wait about 5 minutes and check the oil level again. **Changing Engine Oil and Filter**

Drain the engine oil while the engine is still warm.



- 1) Remove the oil filler cap.
- 2) Place a drain pan under the drain plug.
- 3) Using a wrench, remove the drain plug and drain the engine oil.

The engine oil temperature may be high enough to burn your fingers when the drain plug is loosened. Wait until the drain plug is cool enough to touch with your bare hands. EXAMPLE The second sec

Tightening torque for drain plug: 35 Nm (3.6 kg-m, 25.8 lb-ft)

WARNING

- Engine oil can be hazardous. Children and pets may be harmed by swallowing new or used oil. Keep new and used oil and used oil filters away from children and pets.
- Repeated, prolonged contact with used engine oil may cause skin cancer.
- Brief contact with used oil may irritate skin.


(Continued)

(Continued)

- To minimize your exposure to used oil, wear a long-sleeve shirt and moisture-proof gloves (such as dishwashing gloves) when changing oil. If oil contacts your skin, wash thoroughly with soap and water.
- Launder any clothing or rags if it is with oil.
- Recycle or properly dispose of used oil and filters.
- Reinstall the drain plug with new gasket. Tighten the plug with a wrench to the specified torque.


Oil Filter Replacement

- 1) Using an oil filter wrench, turn the oil filter counterclockwise and remove it.
- 2) Using a clean rag, wipe off the mounting surface on the engine where the new filter will be seated.
- Smear a small amount of engine oil around the rubber gasket of the new oil filter.
- Screw the new filter by hand until the filter gasket contacts the mounting surface.



(1) Loosen (2) Tighten

Tightening (viewed from filter top)



(1) Oil filter (2) 3/4 turn

NOTICE

To tighten the oil filter properly, it is important to accurately identify the position at which the filter gasket first contacts the mounting surface.

5) Tighten the filter as specified below from the point of contact with the mounting surface (or to the specified torque) using an oil filter wrench.

Tightening torque for oil filter

3/4 turn or 14 Nm (1.4 kg-m, 10.3 lb-ft)

NOTICE

To prevent oil leakage, make sure that the oil filter is tight, but do not over-tighten it.

Refill with Oil and Oil Leakage Check

- 1) Pour oil through the filler hole and install the filler cap.
- For the approximate capacity of the oil, refer to "Capacities" in "SPECIFICA-TIONS" section.
- Start the engine and carefully check the oil filter and the drain plug for leakage. Run the engine at various speeds for at least 5 minutes.
- Stop the engine and wait about 5 minutes. Check the oil level again and add oil if necessary. Check for leakage again.

NOTICE

- When replacing the oil filter, it is recommended that you use a MARUTI SUZUKI genuine replacement filter. If you use an aftermarket filter, make sure it is of equivalent quality and follow the manufacturer's instructions.
- Oil leakage from the periphery of the oil filter or drain plug indicate incorrect installation or gasket damage. If you find any leakage or are not sure that the filter has been properly tightened, have the vehicle inspected by a Maruti Suzuki authorised workshop.

Engine Coolant

Selection of Coolant

To maintain optimum performance and durability of your engine, use MARUTI SUZUKI genuine coolant or equivalent.

This type of coolant is the best for cooling system for the following reasons:

- The coolant helps maintain proper engine temperature.
- It gives proper protection against freezing and boiling.
- It gives proper protection against corrosion and rust.

Failure to use the proper coolant can damage your cooling system, Maruti Suzuki authorised workshop can help you select the proper coolant.

6-10

NOTICE

To avoid damaging your cooling system:

- Always use a high quality ethylene glycol base non-silicate type coolant diluted with distilled water at the correct mixture concentration.
- Check that the proper mix is 30/70 and in no case higher than 70/30. Concentrations greater than 70/30 coolant to distilled water will cause overheating conditions.
- Do not use straight coolant nor plain water.
- Do not add extra inhibitors or additives. They may not be compatible with your cooling system.
- Do not mix different types of base coolants. Doing so may result in accelerated seal wear and/or the possibility of severe overheating and extensive engine or automatic transmission damage.

Coolant Level Check

Check the coolant level at the reservoir tank, not at the radiator. With the engine cool, the coolant level should be between "FULL" and "LOW" marks.

Adding Coolant


WARNING

Swallowing engine coolant can cause severe injury or death. Inhaling coolant mist or vapors or getting coolant in your eyes could result in severe injury.

- Do not drink antifreeze or coolant solution. If swallowed, do not induce vomiting. Immediately contact a poison control center or a physician.
- Avoid inhaling coolant mist or hot vapors. If inhaled, remove to a fresh air area.
- If coolant gets in the eyes, flush with water and seek medical attention.
- Wash thoroughly after handling coolant.
- Keep engine coolant out of the reach of children and pets.

NOTICE

- The mixture you use should contain 50% concentration of antifreeze.
- If the lowest ambient temperature in your area is expected to be – 35°C (-31°F) or below, use higher concentrations up to 60% following the instructions on the antifreeze container.



73R0110

If the coolant level is below "LOW" mark, coolant should be added. While the engine is cool, remove the reservoir tank cap and add coolant until the reservoir tank level reaches "FULL" mark. Never fill the reservoir tank above "FULL" mark.

NOTICE

When putting the cap on the reservoir tank, line up the mark on the cap and the mark on the tank. Failure to follow this can result in coolant leakage.

Coolant Replacement

Since special procedures are required, ask a Maruti Suzuki authorised workshop for this job.

Air Cleaner

EXAMPLE


If the air cleaner is clogged with dust, there will be greater intake resistance, resulting in decreased power output and increased fuel consumption.

78P112

- Unclamp the side clamps and remove the element from the air cleaner case. If it appears to be dirty, replace it with a new one.
- 2) Clamp the side clamps securely.

Spark Plugs

For nickel spark plugs (traditional type): You should inspect spark plugs periodically for carbon deposits. When carbon accumulates on a spark plug, a strong spark may not be produced. Remove carbon deposits with a wire or pin and adjust the spark plug gap.




- To access the spark plug:
- If necessary, disconnect the coupler (1) while pushing the release lever.
- 2) Remove the ignitor bolts.
- 3) Pull the spark plug boots out.


NOTE:


During installation, make sure that the wires, couplers, sealing rubber of air cleaner assy and washers, are correctly returned in place.





78K179





NOTICE

- When pulling out the ignition coils, do not pull on the cable. Pulling on the cable can damage it.
- When servicing the iridium/plati-num spark plugs (slender center electrode type plugs), do not touch the center electrode, as it is easy to damage.

When installing the spark plugs, screw them in with your fingers to avoid stripping the threads. Tighten the spark plugs with a torque wrench to 17.5 Nm (1.8 kg- m, 13.0 lb-ft). Do not allow contami- nants to enter the engine through
nants to enter the engine through
the spark plug holes when the
plugs are removed.

NOTICE

Never use spark plugs with the wrong thread size.

When replacing spark plugs, you should use the brand and type specified for your vehicle. For the specified plugs, refer to "SPECIFICATIONS" section in the end of this book. If you wish to use a brand of spark plug other than the specified plugs, consult a Maruti Suzuki authorised workshop.

NOTICE

6-13

Gear Oil

Specified Gear Oil

When adding gear oil, use gear oil with the appropriate viscosity and grade as shown in the chart below.

We highly recommend you use: "MARUTI GEAR OIL 75W" for manual transmission gear oil.


Manual Transmission oil

\leq			75	W			
°C -30	-20	-10	Q	10	20	30	40
°F -22	-4	14	32	50	68	86	104

54P120706

Gear Oil Level Check

Manual Transmission



(1) Oil filler and level plug

To check the gear oil level, use the following procedure:

- 1) Park the vehicle on a level surface with the parking brake applied. Then, stop the engine.
- 2) Remove the oil filler and level plug (1).3) If gear oil flows from the plug hole, the oil level is correct. Reinstall the plug. If gear oil does not flow from the plug hole, add oil through the filler plug hole until oil flows a little from the plug hole.
- 4) If the oil level is low, add gear oil through the oil filler and level plug hole (1) until the oil level reaches the bottom of the filler hole, then reinstall the plug.

INSPECTION AND MAINTENANCE

Tightening torque for oil filler and level plug (1) Manual Transmission: 21 Nm (2.1 kg-m, 15.5 lb-ft)

After driving the vehicle, the gear oil temperature may be high enough to burn you. Wait until the oil filler and level plug is cool enough to touch with your bare hands before inspecting gear oil level.

NOTICE

When tightening the plug, apply the following sealing compound or equivalent to the plug threads to prevent oil leakage.

MARUTI SUZUKI Bond No. "1216E" or "1217G"

Gear Oil Change


Since special procedures, materials and tools are required, ask a Maruti Suzuki authorised workshop for this job.

6-14

Clutch Pedal

Fluid Control Clutch


EXAMPLE



Check the clutch pedal for smooth operation and clutch fluid level from time to time. If clutch dragging is felt with the pedal fully depressed, have the clutch inspected by your Maruti Suzuki authorised workshop. If the clutch fluid level is near the "MIN" line, fill it up to the "MAX" line with Maruti Genuine Brake Fluid (MGBF) or DOT 3. We highly recommend to use "Maruti Genuine Brake Fluid" (MGBF).

Fuel Filter

The fuel filter is located on the way of the fuel hose line under the vehicle body.



(1) Fuel filter(2) Fuel inlet hose(3) Fuel outlet hose

Replace the fuel filter

Since special procedure are required, we recommend you take your vehicle to a Maruti Suzuki authorised workshop for fuel filter replacement.

Automatic Transmission (AT) Fluid

Specified Fluid

Use an automatic transmission fluid SUZUKI AT OIL AW-1.

Fluid Level Check

NOTICE

Driving with too much or too little fluid can damage the transmission.

You must check the fluid level with the automatic transmission fluid at normal operating temperature.


- To check the fluid level:
- To warm up the transmission fluid, drive the vehicle or idle the engine until the engine coolant temperature light (blue color) goes off.
- 2) Then drive for ten more minutes.

NOTICE

Be sure to use the specified automatic transmission fluid. Using automatic transmission fluid other than SUZUKI AT OIL AW-1 may damage the automatic transmission of your vehicle.

NOTE:


Do not check the fluid level if you have just driven the vehicle for a long time at high speed, if you have driven in city traffic in hot weather. Wait until the fluid cools down (about 30 minutes), or the fluid level indication will not be correct.



- 3) Park your vehicle on level ground.
- 4) Apply the parking brake and then start the engine in "P" (Park). Let it idle for two minutes and keep it running during the fluid level check.
- 5) With your foot on the brake pedal, move the gearshift lever through each gear position, pausing for about three seconds in each position. Then move it back to "P" (Park) position.

A WARNING


Be sure to depress the brake pedal when moving the gearshift lever, or the vehicle can move suddenly.



6) The handle of the A/T fluid dipstick is colored red for easy identification. Remove the dipstick, wipe the oil off with a clean cloth and push it back in until the cap seats. Then pull out the dipstick.

INSPECTION AND MAINTENANCE

 Check both sides of the dipstick, and read the lowest level. The fluid level should be between the two marks in hot range on the dipstick.



(1) FULL HOT(2) LOW HOT(3) The lowest point = Fluid level

8) Add just enough specified fluid through the dipstick hole to fill the transmission oil to the proper level.

NOTICE


After checking or adding oil, be sure to insert the dipstick securely.

Changing Oil

Since special procedures, materials, and tools are required to change the automatic transmission oil, ask a Maruti Suzuki authorised workshop for this job.

Brakes

Brake Fluid



Check the brake fluid level by looking at the reservoir in the engine compartment. Check that the fluid level is between "MAX" and "MIN" lines.

NOTICE

If your brake fluid level is near "MIN" line, there is a possibility of brake pad and/or shoe wear and brake fluid leakage. Consult with a Maruti Suzuki authorised workshop regarding this possibility before filling the reservoir.

A WARNING

Failure to follow the guidelines below can result in personal injury or serious damage to the brake system.

- If the brake fluid in the reservoir drops below a certain level, the brake warning light on the instrument panel will come on (the engine must be running with the parking brake fully disengaged). Should the light come on, immediately ask a Maruti Suzuki authorised workshop to inspect the brake system.
- A rapid fluid loss indicates a leakage in the brake system which should be inspected by a Maruti Suzuki authorised workshop immediately.
- Do not use any fluid other than Maruti Genuine Brake Fluid (MGBF) or DOT3 brake fluid. Do not use reclaimed fluid or fluid that has been stored in old or open containers. It is essential that foreign particles and other liquids are kept out of the brake fluid reservoir.

A CAUTION

Brake fluid can harm your eyes and damage painted surfaces. Use caution when refilling the reservoir.

WARNING

Brake fluid is harmful or fatal if swallowed, and harmful if it comes in contact with skin or eyes. If swallowed, do not induce vomiting. Immediately contact a poison control center or a physician. If brake fluid gets in eyes, flush eyes with water and seek medical attention. Wash thoroughly after handling. Solution can be poisonous to animals. Keep out of reach of children and animals.

NOTE:

- The fluid level can be expected to gradually fall as the brake pad and/or shoe wear.
- Brake fluid absorbs water over time and brake fluid with high water content may cause vapor lock or brake system malfunction.


Replace your brake fluid in accordance with the maintenance schedule in your Owner's Manual.

Brake Pedal

tance "a":

51 mm (2.0 in.)

Check if the brake pedal stops at the regular height without "spongy" feeling when you depress it. If not, have the brake system inspected by a Maruti Suzuki authorised workshop. If you doubt the brake pedal for the regular height, check it as follows:



Pedal to floor carpet minimum dis-


With the engine running, measure the distance between the brake pedal and floor carpet when the pedal is depressed with approximately 30 kg (66 lbs) of force. The minimum distance required is as specified. Since your vehicle's brake system is selfadjusting, there is no need for pedal adjustment.

If the pedal to floor carpet distance as measured above is less than the minimum distance required, have your vehicle inspected by a Maruti Suzuki authorised workshop.


NOTE:

When measuring the distance between the brake pedal and floor wall, be sure not to include the floor mat or rubber on the floor wall in your measurement.

INSPECTION AND MAINTENANCE




Parking Brake



Ratchet tooth specification "b": 4th – 9th Lever pull force (1): 200 N (20 kg, 45 lbs)


Check the parking brake for proper adjustment by counting the number of clicks made by the ratchet teeth as you slowly pull up on the parking brake lever to the point of full engagement. The parking brake lever should stop between the specified ratchet teeth and the rear wheels should be securely locked. If the parking brake is not properly adjusted or the brakes drag is suspected even after the lever has been fully released, have the parking brake inspected and/or adjusted by a Maruti Suzuki authorised workshop.



Steering wheel play "c": 0 - 30 mm (0.0 - 1.2 in.)

Check the play of the steering wheel by gently turning it from left to right and measuring the distance that it moves before you feel slight resistance. The play should be between the specified values.

Check that the steering wheel turns easily and smoothly without rattling by turning it all the way to the right and to the left while driving very slowly in an open area. If the amount of free play is outside the specification or you find anything else to be wrong, an inspection must be performed by a Maruti Suzuki authorised workshop.



The front and rear tire pressure specifications for your vehicle are listed in the tire information label. Both front and rear tires should have the specified tire pressure.


Tire Inspection

Inspect your vehicle's tires at least once a month or before long trip by performing the following checks:

1) Measure the air pressure with a tire gauge. Adjust the pressure if necessary. Remember to check the spare tire, too.

- Air pressures should be checked when the tires are cold or you may get inaccurate readings.
- Check the inflation pressure from time to time while inflating the tire gradually, until the specified pressure is obtained.
- Never underinflate or over-inflate the tires.
- Underinflation can cause unusual handling characteristics or can cause the rim to slip on the tire bead, resulting in an accident or damage to the tire or rim. Overinflation can cause the tire to burst, resulting in personal injury.

Overinflation can also cause unusual handling characteristics which may result in an accident.



(1) Tread wear indicator(2) Indicator location mark

- 2) Check that the depth of the tread groove is more than 1.6 mm (0.06 in.). To help you check this, the tires have molded-in tread wear indicators in the grooves. When the indicators appear on the tread surface, the remaining depth of the tread is 1.6 mm (0.06 in.) or less and the tire should be replaced.
- 3) Check for abnormal wear, cracks and damage. Any tires with cracks or other damage should be replaced. If any tires show abnormal wear, have them inspected by a Maruti Suzuki authorised workshop.

A CAUTION

Hitting curbs and running over rocks can damage tires and affect wheel alignment. Have tires and wheel alignment checked periodically by a Maruti Suzuki authorised workshop.

- 4) Check for loose wheel nuts.
- 5) Check that there are no nails, stones or other objects sticking into the tires.

- Your MARUTI SUZUKI vehicle is equipped with tires which are all the same type and size. This is important to ensure proper steering and handling of the vehicle. Never mix tires of different size or type on the four wheels of your vehicle. The size and type of tires used should be only those approved by MARUTI SUZUKI as standard or optional equipment for your vehicle.
- Replacing the wheels and tires equipped on your vehicle with certain combinations of aftermarket wheels and tires can significantly change the steering and handling characteristics of your vehicle.
- Therefore, use only those wheel and tire combinations approved by MARUTI SUZUKI as standard or optional equipment for your vehicle.


NOTICE


Replacing the original tires with tires of a different size may result in false speedometer or odometer readings. Check with a Maruti Suzuki authorised workshop before purchasing replacement tires that differ in size from the original tires.

6-20

Tire Rotation

5-tire rotation





To avoid uneven wear of your tires and to prolong their life, rotate the tires as illustrated. Tires should be rotated every 10000 km. After rotation, adjust front and rear tire pressures to the specification listed in your vehicle's Tire Information Label.

Wheel Balancing

If the vehicle vibrates abnormally on smooth road, have the wheel balanced at Maruti Suzuki authorised workshop.

Wheel Alignment

In case of abnormal tire wear or pulling towards one side, have the wheel aligned at Maruti Suzuki authorised workshop.

Tubeless Tires (If equipped)

The vehicle is equipped with Tubeless Tires. In tubeless tire, a thin layer of butyl rubber is used for lining the inside of the tubeless tire. This layer is to prevent air loss and fulfilling the purpose of tube. The air pressure is maintained by the sealing between tire bead and wheel rim. Tubeless tires are having advantage of slow air loss and preventing sudden deflation while driving.

Care and maintenance tips for tubeless tires


- Always maintain recommended inflation pressure. Driving continuously at low inflation pressure can lead to tire damage.
- In case any leakage is found, check for any nail penetration/valve core damage or rim bent. Damaged wheel must not be used.
- In case tire has run at low pressure, it must be inspected for any defect.
- 4) Whenever new tire is fitted, replace the valve.

- If continuous high speed driving is required, increase pressure of tires by 5 psi over recommended inflation pressure.
- 6) Never run the tire beyond TWI (Tread wear indicator). The tire is recommended to be replaced when the remaining tread has worn to this point. The indicators are spaced across the tread around the tire marked by a triangular symbol (TWI).
- Always prefer tubeless tire mounting machine. In case of manual mounting tire/ wheel rim damage may occur.
- In case of any problem, please get in touch with a Maruti Suzuki authorised workshop.

Lead-acid Battery

A WARNING

- Batteries produce flammable hydrogen gas. Keep flames and sparks away from the lead-acid battery or an explosion may occur. Never smoke when working in the vicinity of the lead-acid battery.
- When checking or servicing the lead-acid battery, disconnect the negative cable. Be careful not to cause a short circuit by allowing metal objects to contact the leadacid battery posts and the vehicle at the same time.
- To avoid harm to yourself or damage to your vehicle or lead-acid battery, follow the jump starting instructions in "EMERGENCY SER-VICE" section of this manual if it is necessary to jump-start your vehicle.
- Diluted sulfuric acid spilled from lead-acid battery can cause blindness or severe burns. Use proper eye protection and gloves. Flush eyes or body with ample water and get medical care immediately if suffered. Keep batteries out of reach of children.



For maintenance-free battery (cap-less type), you need not add water. For traditional type battery, which has water filler caps, the level of the battery fluid must be kept between the "MAX" and the "MIN" level lines at all times. You should periodically check the battery, battery terminals, and battery hold-down bracket for corrosion. Remove corrosion using a stiff brush and ammonia mixed with water, or baking soda mixed with water. After removing corrosion, rinse with clean water.

If your vehicle is not going to be driven for a month or longer, disconnect the cable from the negative terminal of the battery to help prevent discharge.

INSPECTION AND MAINTENANCE

A WARNING

If the battery is used with battery level being less than the lower level line "MIN", it may cause reduced battery life, an exothermic heat, or an explosion by hydrogen gas occurring from the battery. Do not use the battery with battery level being less than the lower level line "MIN".

NOTICE


If the battery liquid is added more than the upper level line "MAX", liquid may leak by vibrations during driving or liquid may spray out in some case depending on the condition of battery charging. These may cause damage to the parts near the battery. If the battery liquid overspills, immediately wash away with water. Do not add the

battery liquid more than the upper level line "MAX".

NOTE:

The battery liquid is consumed when the battery is used. If the level is found to be less than the center of upper level "MAX" and lower level "MIN", add distilled water till it reaches the upper level line "MAX".

Replacement of the battery



To remove the battery:

- 1) Disconnect the negative cable (1).
- 2) Disconnect the positive cable (2).
- 3) Remove the retainer nuts (3) and remove the retainer (4).
- 4) Remove the battery.

To install the battery:

- 1) Install the battery in the reverse order of removal.
- 2) Tighten the bracket bolt and battery cables securely.

NOTE:


• When the battery is disconnected, some of the vehicle's functions will be initialized and/or deactivated. These functions are required to be reset after the battery is reconnected.

 Do not disconnect the battery terminals for at least one minute after the ignition switch is turned off, or the engine switch is pressed to change the ignition mode to "LOCK" (OFF).

Batteries contain toxic substances including sulfuric acid and lead. They could have potential negative consequences for the environment and human health. Used batteries must be disposed of or recycled according to applicable rules or regulations and must not be disposed of with ordinary household trash. Make sure not to tip over the battery when you remove it from the vehicle. Otherwise, sulfuric acid could run out and you might get injured.

NOTICE

Do not use regular battery in ISG Vehicle. Use only Exide Conservo N55 battery, else it may deteriorate Smart Hybrid performance.



You may find this label on the inside of hood.

Fuses

Your vehicle has three types of fuses, as described below:

Main fuse

The main fuse takes current directly from the lead-acid battery.

Primary fuses

These fuses are between the main fuse and individual fuses, and are for electrical load groups.


Individual fuses

These fuses are for individual electrical circuits.

NOTE:


- "Blank" indicates that fuse is not applicable in the variant, even though name of fuse might be available on cover of fuse box of your vehicle.
- Some fuse may not be applicable to your vehicle according to the variant of vehicle, even though it is not mentioned as blank.

To remove a fuse, use the fuse puller (1) provided in the relay box cover.



EXAMPLE


Fuses in Engine Compartment



(1) Main fuse box(2) Relay box


63J095

Main fuse box (as applicable)





Relay box




MAIN FUSE / PRIMARY FUSE						
(1)	120 A	FL1 (K15B)				
(1)	-	FL1 (K15B ISG)				
(2)	100 A	FL2				
(3)	80 A	FL3				
(4)	100 A	FL4				
(5)	50 A	FL5				
(6)	200 A	FL6				
(7)	30 A	Starting motor				
(8)	30 A	Blower fan				
(9)	-	Battery				
(10)	40 A	ABS motor				
(11)	40 A	Ignition switch				
(12)	30 A	Back up light				
(13)	30 A	Sub battery				
(14)	20 A	Front fog light				
(15)	-	Blank				
(16)	25 A	ABS solenoid				
(17)	-	Blank				
(18)	10 A	A/C Compressor				
(19)	-	Blank				
(20)	30 A	Radiator fan				

(21)	-	Blank
(22)	-	Blank
(23)	25 A	Headlight HI
(24)	15 A	Headlight (Left)
(25)	15 A	Headlight (Right)
(26)	-	Blank
(27)	50 A	Ignition switch -2
(28)	15 A	Auto Transmission
(29)	15 A	Fuel Injection
(30)	7.5 A	CNG valve
(31)	15 A	Headlight HI (Left)
(32)	15 A	Headlight HI (Right)
(33)	5 A	Starting Signal
(34)	7.5 A	CNG

The main fuse, primary fuses and some of the individual fuses are located in the engine compartment. If the main fuse blows, no electrical component will function. If a primary fuse blows, no electrical component in the corresponding load group will function. When replacing the main fuse, a primary fuse or an individual fuse, use a MARUTI SUZUKI genuine replacement parts or equivalent for individual fuses.


To remove a fuse, use the fuse puller provided in the fuse box. The amperage of each fuse is shown in the back of the fuse box cover and in the relay box.

If the main fuse or a primary fuse blows, have your vehicle inspected by a Maruti Suzuki authorised workshop. Always use a MARUTI SUZUKI genuine replacement. Never use a substitute such as a wire even for a temporary repair, or extensive electrical damage and a fire can result.



NOTE:

Make sure that the fuse box always carries spare fuses.



Fuses under Dashboard




PRIM	PRIMARY FUSE							
(1)	30 A	Power window						
(2)	10 A	Meter						
(3)	15 A	Ignition coil						
(4)	5 A	Ignition-1 signal 2						
(5)	20 A	Auto Gear Shift lever						
(6)	20 A	Sunroof motor						
(7)	-	Blank						
(8)	20 A	Door lock						
(9)	15 A	Steering lock						
(10)	10 A	Hazard light						
(11)	5 A	AUTO-STOP						
(12)	10 A	Rear fog light						

6-26

(13)	5 A	ABS control module
(14)	15 A	Rear air conditioner
(15)	5 A	Ignition-1 signal 3
(13)	5 A	CNG ignition-1
(16)	10 A	Dome light-2
(17)	5 A	Dome light
(18)	15 A	Radio
(19)	5 A	Controller
(20)	5 A	Key2
(21)	20 A	Power window timer
(22)	5 A	Кеу
(23)	15 A	Horn
(24)	5 A	Tail light (Left)
(25)	10 A	Tail light
(26)	10 A	Airbag
(27)	10 A	Ignition-1 signal
(28)	10 A	Back up light
(29)	5 A	Accessory 3
(30)	20 A	Rear defogger
(31)	10 A	Mirror heater
(32)	15 A	Accessory 2
(33)	5 A	Accessory

(34)	10 A	Rear wiper
(35)	5 A	Ignition-2 signal
(36)	15 A	Washer
(37)	25 A	Front wiper
(38)	10 A	Stop light
(00)	1071	etop light

EXAMPLE



WARNING

Always replace a blown fuse with a fuse of the correct amperage. Never use a substitute such as aluminum foil or wire to replace a blown fuse. If you replace a fuse and the new one blows in a short period of time, you may have a major electrical problem. Have your vehicle inspected immediately by a Maruti Suzuki authorised workshop.

NOTE:

81A283

According to the vehicle specifications, fuse setting may be different from the specifications which are shown in the above tables.

6-27

Headlight Aiming

Since special procedures are required, ask a Maruti Suzuki authorised workshop for this job.

Bulb Replacement

A CAUTION

- Light bulbs can be hot enough to burn your finger right after turning off lights. This is true especially for halogen headlight bulbs. Replace the bulbs after they become cool enough.
- The headlight bulbs are filled with pressurized halogen gas. They can burst and injure you if they are hit or dropped. Handle them carefully.
 To avoid injury by sharp-edged
- parts of the body, wear gloves and a long-sleeved shirt when replacing light bulbs.

NOTICE

The oils from your skin may cause a halogen bulb to overheat and burst when the lights are on. Grasp a new bulb with a clean cloth.

NOTICE


- Frequent bulb replacement indicates the need for an inspection of the electrical system. This should be carried out by a Maruti Suzuki authorised workshop.
- During bulb replacement always use same bulb number as used in vehicle which is imprinted on the said bulb/unit and/or mentioned in SPECIFICATIONS.

NOTE:

Mist may form on the lenses of exterior lights (Headlight, Rear combination light etc.) during or after driving in the rain or after car washing. This is a natural phenomenon which occurs due to temperature difference between lamp inside and outside. Temporary mist on the lens is not a malfunction and will not cause any discomfort during vehicle driving.

The mist would get cleared when the environmental condition change to sunny or when headlamp is kept on. However if there is water leakage inside the lamp, contact your Maruti Suzuki authorised workshop.

Headlight




INSPECTION AND MAINTENANCE

Open the engine hood while the engine is stopped.

Push the lock release (1) and disconnect the coupler (2). Turn the bulb holder counterclockwise and remove it (3). Install a new bulb in the reverse order of removal. Ensure bulb rotation upto lock.

6-28

High beam




Open the engine food while the engine is stopped.

Turn the cover (1) counterclockwise and remove it.


Turn the bulb (2) holder counterclockwise and remove it. Disconnect the coupler with pushing the lock release.

Front turn signal light Front position light




(1) Front turn signal light (2) Front position light

EXAMPLE



1) Open the engine hood while the engine is stopped. To remove the bulb holder of the front turn signal light or the front position light from the light housing, turn the holder counterclockwise and pull it out.



68PM00721

(3) Removal (4) Installation

2) To remove the bulb of the front turn signal light (1) from the bulb holder, push in the bulb and turn it counterclockwise. To install a new bulb, push it in and turn it clockwise.

To remove and install the bulb of the front position light (2), simply pull out or push in the bulb.

NOTE:


For turn signal / position light, it is recommended that you take your vehicle to a Maruti Suzuki authorised workshop for bulb replacement since special procedures are required.

Side Turn Signal Light


Outside rearview mirror type

LED is used. It is recommended that you take your vehicle to a Maruti Suzuki authorised workshop for bulb replacement since special procedures are required.

Fender type




1) Remove the side turn signal light assembly (1) by sliding light housing to left with your finger.



2) Turn the bulb holder (2) clockwise and pull it out from the light housing.


Front fog light (if equipped) 1) Start the engine. Turn the steering wheel to the opposite side of the fog light to be replaced to replace the bulb easily. Then turn off the engine.



73R0125

2) Insert a flat-bladed screwdriver into the hole (2) and remove the clips (1) by twist the driver as shown in the illustration.






 Open the fender cover. Disconnect the coupler with pushing the lock release. Turn the bulb holder counterclockwise and remove it.

Rear combination light

(tail, stop, turn signal, etc.) For LED tail / brake light, it is recommended that you take your vehicle to a Maruti Suzuki authorised workshop for bulb replacement since special procedures are required.




With the tailgate opened, remove the bolts (1) and tail light (2), and then pull the rear combination light (3) firmly to the rearward.

NOTE:

When it is difficult to remove the rear combination lamp from the body at a low temperature (10 deg. C or less), pour water between the body and the rear combination lamp to make the removal smooth.


NOTE:

Brake light and tail light in rear combination lamp are LED type and are non replaceable. It is recommended that you take your vehicle to a Maruti Suzuki authorised workshop for replacing brake light / tail light



 To remove the bulb holder of the rear turn signal light (4) or the reversing light (5) from the light housing, turn the holder counterclockwise and pull it out.

6-31



When reinstalling the light housing, check that the clips are properly attached.

73R0192


To remove and install the bulb of the license plate light (2), simply pull out or push in the bulb.

6-32


High-mount stop light LED is used. It is recommended that you take your vehicle to a Maruti Suzuki autho-rised workshop for bulb replacement since special procedures are required.

Interior Light

Front (Type A)




Front (Type B)



Rear

73R0193



Remove the lens by using a flat-bladed screwdriver covered with a soft cloth as shown. To install it, simply push it back in.

6-33

The bulb can be removed by simply pulling it out. When replacing the bulb, make sure that the contact springs are holding the bulb securely.

Wiper Blades

If the wiper blades become brittle or damaged, or make streaks when wiping, replace the wiper blades.

To install new wiper blades, follow the procedures below.

NOTICE

To avoid scratching or breaking the window, do not let the wiper arm strike the window while replacing the wiper blade.

NOTE:

Some wiper blades may be different from the ones described here depending on vehicle specifications. If so, consult a Maruti Suzuki authorised workshop for proper replacement method.



EXAMPLE


For windshield wipers:

1) Hold the wiper arm away from the window.

NOTE:

54G129

When raising both of the front wiper arms, pull the driver's side wiper arm up first. When returning the wiper arms, lower the passenger's side wiper arm first. Otherwise, the wiper arms may interfere with each other.






- Squeeze lock (1) towards wiper arm (2) and remove the wiper frame from the arm as shown.
- 3) Unlock the lock end of the wiper blade and slide the blade out as shown.




INSPECTION AND MAINTENANCE




(A) Up (B) Down

6-35




2) Remove the wiper frame from the wiper arm as shown.



3) Slide the blade out as shown.

NOTE:

Do not flex the wiper blade frame end more than necessary. If you do, it can break off.



(1) Retainer

- 4) If the new blade is provided without the two metal retainers, move them from the old blade to the new one.
- 5) Install the new blade in the reverse order of removal.
 - Make sure the blade is properly retained by all the hooks.
- 6) Reinstall wiper frame to arm in the reverse order of removal.

Check that there is washer fluid in the tank. Refill it if necessary. Use a good quality windshield washer fluid, diluted with water as necessary.

WARNING

Do not use radiator antifreeze solution in the windshield washer reservoir. This can severely impair visibility when sprayed on the windshield, and also can damage your vehicle's paint.


NOTICE

Damage may result if the washer motor is operated with no fluid in the washer tank.

6-36

Windshield Washer Fluid

INSPECTION AND MAINTENANCE




INSPECTION AND MAINTENANCE

Air Conditioning System


If you do not use the air conditioner for a long period, such as during winter, it may not give the best performance when you start using it again. To help maintain optimum performance and durability of your air conditioner, it needs to be run periodically. Operate the air conditioner at least once a month for one minute with the engine idling. This circulates the refrigerant and oil and helps protect the internal components.

Air conditioner filter replacement

Since special procedures are required, ask a Maruti Suzuki authorised workshop for this job.



 To approach the air conditioner filter, remove the glove box by pressing both sides of the glove box inward and pull-




2) Remove the cover (1) and pull out the air conditioner filter (2).

NOTE:

When you install a new filter, check that the UP mark (3) faces upward.

6-37

ing it out.




EMERGENCY SERVICE

Tire Changing Tool	7-1
Jacking Instructions	7-3
Jump-Starting Instructions	7-8
Towing your vehicle	7-9
Engine trouble: Starter does not operate	7-10
Engine trouble: Does not start	7-10
Engine trouble: Overheating	7-11
Warning Triangle	7-12
warning manyle	/-12

7

60G411A


Tire Changing Tool




(1) Jack

- (2) Wheel wrench(3) Jack handle

The tire changing tools are stowed in the side of the luggage compartment. Remove the cover to access the tools.




To remove the jack (1), turn its shaft counterclockwise by using jack handle (3) and pull the jack out of the storage bracket.




NOTE:

If you are difficult to use the jack handle (3), use jack handle and wheel wrench (2) as shown in the illustration.



73R0205

To stow the jack, place it in the storage bracket and turn the shaft clockwise with hand.





After temporarily holding the jack (1) until it contacts the storage bracket, turn the shaft (4) approximately 90° to 180° by using jack handle (3) to securely hold the jack in place.

A WARNING

After using the tire changing tools, stow them securely or they can cause injury if an accident occurs.

The jack should be used only to change wheels. It is important to read the jacking instructions in this section before attempting to use the jack. The spare tire is stowed under the rear floor.






 Remove the cap and use a wheel wrench to loosen the hook bolt of the spare tire holder. Then, rotate using the end of the jack handle.

NOTICE

Loose the spare tire holder hook bolt until you can remove the hook by yourself. If the bolt is loosen too much, the hook might off and the spare tire might drop off to the ground.



- Unhook the spare tire holder and lower it slowly.
- 3) Remove the tire.
- To install the spare tire:
- Install the spare tire facing up the outside of the wheel in the reverse order of removal.
- 2) Tighten the spare tire holder hook bolt securely.

WARNING

Do not drive your vehicle with the loose spare tire holder hook bolt, otherwise it may come loose or the spare tire may drop off, which can result in an accident.

NOTICE


Make sure that the spare tire is fixed securely. Loosely fixed tire may cause noise during driving. However, do not overtighten the bolt, it may be warped or broken.

NOTICE

Tighten the spare tire holder hook bolt securely. However, do not overtighten the bolt, it may be warped or broken.

Tightening torque for the spare tire holder hook bolt 30 Nm (3.0 kg-m, 22.1 lb-ft)


Jacking Instructions




1) Place the vehicle on level, hard ground.

 Set the parking brake firmly and shift into "P" (Park) if your vehicle has an automatic transmission, or shift into "R" (Reverse) if your vehicle has a manual

- 3) Turn on the hazard warning switch if your vehicle is near traffic.
- Block the front and rear of the wheel diagonally opposite of the wheel being lifted.
- 5) Place the spare tire near the wheel being lifted as shown in the illustration in case the jack slips.



66RM08006




A WARNING

transmission.

- Shift into "P" (Park) for an automatic transmission, or into "R" (Reverse) for a manual transmission vehicle when you jack up the vehicle.
- Never jack up the vehicle with the transmission in "N" (Neutral). Otherwise, unstable jack may cause an accident.

7-3

EXAMPLE



- 6) Position the jack at an angle as shown in the illustration and raise the jack by turning the jack handle clockwise until the jack-head groove fits around the jacking bar beneath the vehicle body.
- Continue to raise the jack slowly and smoothly until the tire clears the ground. Do not raise the vehicle more than necessary.

A WARNING

- Use the jack only to change wheels on level, hard ground.
- Never jack up the vehicle on an inclined surface.
- Never raise the vehicle with the jack in a location other than the specified jacking point (shown in the illustration) near the wheel to be changed.


Especially, do not raise the vehicle with a jack at a part of the torsion beam which is located under the vehicle body, between rear wheels.

- Make sure that the jack is raised at least 51 mm (2 inches) before it contacts the flange. Use of the jack when it is within 51 mm (2 inches) of being fully collapsed may result in failure of the jack.
- Do not use wooden blocks or similar objects as a jack underlay
- Never get under the vehicle when it is supported by the jack. Never place your hands and feet under the raised vehicle when it is supported by a jack
- Never run the engine when the vehicle is supported by the jack and never allow passengers to remain in the vehicle.

Raising vehicle with garage jack

- Apply the garage jack to one of the points indicated below.
- Always support the raised vehicle with jack stands (commercially available) at the points indicated below.

7-4





Changing Wheels

A WARNING

Never change a wheel in traffic lane. Always move the vehicle off the road on level, hard ground away from traffic for changing a wheel. For any further assistance contact your nearest Maruti Suzuki authorised workshop.

To change a wheel, use the following procedure:

- 1) Remove the jack, tools and spare wheel from the vehicle.
- 2) Loosen, but do not remove the wheel nuts.
- 3) Jack up the vehicle (follow the jacking instructions in this section).

WARNING


- Shift into "P" (Park) for an automatic transmission, or into "R" (Reverse) for a manual transmission vehicle when you jack up the vehicle.
- Never jack up the vehicle with the transmission in "N" (Neutral). Otherwise, unstable jack may cause an accident.

A CAUTION

Immediately after the vehicle has been driven, the wheels, the wheel nuts and the area around the brakes might be extremely hot. Touching these areas may cause


burn injury. Do not touch these areas, immediately after the vehicle has been driven.

4) Remove the wheel nuts and wheel.



65J4033

- Clean any mud or dirt off from the surface of the wheel (1), hub (2), thread part (3) and surface of the wheel nuts (4) with a clean cloth. Clean the hub carefully; it may be hot from driving.
- 6) Install the new wheel and replace the wheel nuts with their cone shaped end facing the wheel. Tighten each nut snugly by hand until the wheel is securely seated on the hub.




Tightening torque for wheel nuts 100 Nm (10.2 kg-m, 74.0 lb-ft)

 Lower the jack and fully tighten the nuts with a wheel wrench in numerical order as shown in the illustration.

Use genuine wheel nuts and tighten them to the specified torque as soon as possible after changing wheels. Incorrect wheel nuts or improperly tightened wheel nuts may come loose or fall off, which can result in an accident. If you do not have a torque wrench, have the wheel nut torque checked by a Maruti Suzuki authorised workshop.

Full Wheel Cover (if equipped)



After Changing Wheels

Stow the tire changing tools (jack, jack handle and lug wrench) in place. Also, stow the flat tire in the spare tire stowed position. Refer to "Tire Changing Tool" in this section.


NOTICE

Repair or replace the flat tire immediately. If the flat tire is placed in the spare tire stowed position for long time, it can cause vehicle shakiness, noise, or scratches.

(1) or (2) Flat end tool

Your vehicle includes two tools, a lug wrench and a jack crank, one of which has a flat end.

Use the tool with the flat end with a soft cloth to remove the full wheel cover, as shown in the illustration.



60MH074

When installing the cover, make sure that it is positioned so that it does not cover or foul the air valve.

7-7

Jump-Starting Instructions

WARNING

- Never attempt to jump-start your vehicle if the lead-acid battery appears to be frozen. Lead-acid batteries in this condition may explode.
- When making jump lead connections, be certain that your hands and the jump leads remain clear from pulleys, belts or fans.
- Batteries produce flammable hydrogen gas. Keep flames and sparks away from the lead-acid battery or an explosion may occur. Never smoke when working near the lead-acid battery.
- If the booster lead-acid battery you use for jump-starting is installed in another vehicle, make sure the two vehicles are not touching each other.
- If your lead-acid battery discharges repeatedly, for no apparent reason, have your vehicle inspected by a Maruti Suzuki authorised workshop.
- To avoid harm to yourself or damage to your vehicle or lead-acid battery, follow the jump-starting instructions below.
 If you are in doubt, call for qualified


road service.

NOTICE

Your vehicle should not be started by pushing or towing. This starting method could result in permanent damage to the catalytic converter. Use jump leads to start a vehicle with a weak or discharged battery.

Jump-Starting

- Use only a 12-volt battery to jump-start your vehicle. Position the good 12-volt battery close to your vehicle so that the jump leads will reach both batteries. When using a battery installed on another vehicle, check that two vehicles do not touch each other. Set the parking brakes fully on both vehicles.
- Turn off all vehicle accessories, except those necessary for safety reasons (for example, headlights or hazard lights).



- 3) Connect jump leads as follows:
 - 1. Connect one end of the first jump lead to the positive (+) terminal of the discharged battery (1).
 - Connect the other end to the positive (+) terminal of the booster battery (2).

- 3. Connect one end of the second jump lead to the negative (–) terminal of the booster battery (2).
- Make the final connection to an unpainted, heavy metal part (i.e.engine mount bolt (3)) of the engine of the vehicle with the discharged battery (1).

Never connect the jump lead directly to the negative (–) terminal of the discharged lead-acid battery, or an explosion may occur.

A CAUTION

Connect the jump lead to the engine mount bolt securely. If the jump lead disconnects from the engine mount bolt because of vibration at the start of the engine, the jump lead could be caught in the drive belts.

- 4) If the booster battery you are using is fitted to another vehicle, start the engine of the vehicle with the booster battery. Run the engine at moderate speed.
- 5) Start the engine of the vehicle with the discharged lead-acid battery.
- 6) Remove the jump leads in the exact reverse order in which you connected them.

Towing your vehicle

If you need to have your vehicle towed, contact a professional service, Maruti Suzuki authorised workshop can provide you with detailed towing instructions.

NOTICE

Observe the following instructions when towing your vehicle.

- To help avoid damage to your vehicle during towing, proper equipment and towing procedures must be used.
- Using the frame hook, tow your vehicle on paved roads for short distances at low speed.

2-Wheel Drive (2WD) Automatic Transmission

Automatic transmission vehicles may be towed using either of the following methods.

- 1) From the front, with the front wheels lifted and the rear wheels on the ground. Before towing, make sure that the parking brake is released.
- 2) From the rear, with the rear wheels lifted and a dolly under the front wheels.

NOTICE

Towing your vehicle with the front wheels on the ground can result in damage to the automatic transmission.

2-Wheel Drive (2WD) Manual Transmission

Manual transmission vehicles may be towed using either of the following methods.

- 1) From the front, with the front wheels lifted and the rear wheels on the ground. Before towing, make sure that the parking brake is released.
- 2) From the rear, with the rear wheels lifted and the front wheels on the ground, provided the steering and drivetrain are in operational condition. Before towing, make sure that transmission is in neutral, the steering wheel is unlocked (vehicle without keyless push start system the ignition key should be in "ACC" position) (vehicle with keyless push start system the ignition mode is "ACC"), and the steering wheel is secured with a clamping device designed for towing service.

NOTICE

The steering column is not strong enough to withstand shocks transmitted from the front wheels during towing. Always unlock the steering wheel before towing.

Engine trouble: Starter does not operate

- Try turning the ignition switch to "START" position or try pressing the engine switch to change the ignition mode to "START" with the headlights turned on to determine the lead-acid battery condition. If the headlights go excessively dim or go off, it usually means that either the lead-acid battery is discharged or the lead-acid battery terminal contact is poor. Recharge the lead-acid battery or correct lead-acid battery terminal contact as necessary.
- 2) If the headlights remain bright, check the fuses. If the reason for failure of the starter is not obvious, there may be a major electrical problem. Have the vehicle inspected by a Maruti Suzuki authorised workshop.

Engine trouble: Does not start

Make sure that your vehicle has enough fuel and lead-acid battery.

If the engine does not start under very cold condition, press the accelerator pedal all the way to the floor and hold it while cranking the engine.

Refer to "Starting engine (vehicle without keyless push start system) (if equipped)" or "Starting engine (vehicle with keyless push start system) (if equipped)" in operating your vehicle section.

If the engine still does not start have your vehicle inspected at a Maruti Suzuki authorised workshop.

• Do not operate the starter motor for more than 12 seconds.

(Vehicle with Keyless Push Start System)

NOTE:

If the engine refuses to start, the starter motor automatically stops after a certain period of time. After the starter motor has automatically stopped or if there is anything abnormal in the engine starting system, the starter motor runs only while the engine switch is held pressed.

7-10

Engine trouble: Overheating

The engine could overheat temporarily under severe driving conditions. If the high engine coolant temperature warning light comes on as overheating during driving:


- 1) Turn off the air conditioner, if equipped.
- 2) Take the vehicle to a safe place and park.
- Run the engine at a normal idle speed for a few minutes until the high engine coolant temperature warning light goes off.

WARNING

If you see or hear escaping steam, stop the vehicle in a safe place and immediately turn off the engine to cool it. Do not open the hood when steam is present. When the steam can no longer be seen or heard, open the hood to see if the coolant is still boiling. If it is, you must wait until it stops boiling before you proceed. If the high engine coolant temperature warning light does not go off:


- Turn off the engine and check that the water pump belt and pulleys are not damaged or slipping. If any abnormality is found, correct it.
- 2) Check the coolant level in the reservoir. If it is found to be lower than "LOW" line, check radiator, water pump and radiator hoses for leakage. If leakage that may cause overheating is found, do not run the engine until these problems have been corrected.
- If leakage is not found, carefully add coolant to the reservoir and then the radiator, if necessary. (Refer to "Engine Coolant" in "INSPECTION AND MAIN-TENANCE" section.)

- It is hazardous to remove the radiator cap when the water temperature is high, because scalding fluid and steam may be blown out under pressure. The cap should only be taken off when the coolant temperature has lowered.
- To help prevent personal injury, keep hands, tools and clothing away from the engine cooling fan and air-conditioner fan (if equipped). These electric fans can automatically turn on without warning.




7-11

Warning Triangle




In case of vehicle break-down or during emergency stopping, where, your vehicle could become a potential traffic hazard, keep the warning triangle, provided with your vehicle, on the road free from any obstacles behind your vehicle so as to warn the approaching traffic, at an approximate distance of 50-100 m. The reflecting side of the triangle should face the on coming traffic. Please activate the hazard warning lamps before alighting the vehicle to keep the warning triangle.



MHO-07-014


- Remove the warning triangle carefully from the cover as shown by arrow 1.
- Open both the reflector arms as shown by arrow and lock the arms with each other with the clip provided in the right arm. Open the bottom stand in counter clock-wise direction as shown by arrow 3. Position the warning triangle behind the vehicle on a plain surface.
- Reverse the removal procedure for • keeping inside the cover.
- Place the warning triangle below 3rd row seat.





APPEARANCE CARE

Corrosion Prevention8-	-1
Vehicle Cleaning8-	2



8

Corrosion Prevention

It is important to take good care of your vehicle to protect it from corrosion. Listed below are instructions for how to maintain your vehicle to prevent corrosion. Please read and follow these instructions carefully.

Important Information about Corrosion

Common causes of corrosion

- Accumulation of road salt, dirt, moisture, or chemicals in hard-to-reach areas of the vehicle underbody or frame.
- Chipping, scratches and any damage to treated or painted metal surfaces resulting from minor accidents or abrasion by stones and gravel.
- 3) Any or all of the below mentioned points:
- continuous exposure to sunlight.
- hard water & Sea water coming in contact with vehicle.
- foot rubbing (skirting).

8-1

Environmental conditions which accelerate corrosion

- 1) Road salt, dust control chemicals, sea breeze or industrial pollution will all accelerate the corrosion of metal.
- High humidity will increase the rate of corrosion particularly when the temperature range is just above the freezing point.
- Moisture in certain areas of a vehicle for an extended period of time may pro-

mote corrosion even though other body sections may be completely dry.

 High temperatures will cause an accelerated rate of corrosion to parts of the vehicle which are not well-ventilated to permit quick drying.

This information illustrates the necessity of keeping your vehicle (particularly the underbody) as clean and dry as possible. It is equally important to repair any damage to the paint or protective coatings as soon as possible.

How to Help Prevent Corrosion

Wash your vehicle frequently

The best way to preserve the finish on your vehicle and to help avoid corrosion is to keep it clean with frequent washing. Wash your vehicle at least once during the winter and once immediately after the winter. Keep your vehicle, particularly the

underside, as clean and dry as possible. If you frequently drive on salted roads,

your vehicle should be washed at least once a month during the winter. If you live near the ocean, your vehicle should be washed at least once a month throughout the year.

For washing instructions, refer to "Vehicle Cleaning" section.

Remove foreign material deposits

Foreign material such as salts, chemicals, road oil or tar, tree sap, bird droppings and industrial fall-out may damage the finish of your vehicle if it is left on painted surfaces. Remove these types of deposits as quickly as possible. If these deposits are difficult to wash off, an additional cleaner may be required. Be sure that any cleaner you use is not harmful to painted surfaces and is specifically intended for your purposes. Follow the manufacturer's directions when using these special cleaners.

Repair finish damage

Carefully examine your vehicle for damage to the painted surfaces. Should you find any chips or scratches in the paint, touch them up immediately to prevent corrosion from starting. If the chips or scratches have gone through to the bare metal, have a qualified body shop make the repair.

Keep passenger and luggage compartments clean

Moisture, dirt or mud can accumulate under the floor mats and may cause corrosion. Occasionally, check under these mats to ensure that this area is clean and dry. More frequent checks are necessary if the vehicle is used for off-road driving or in wet weather.

Certain cargos such as chemicals, fertilizers, cleaners, salts, etc. are extremely corrosive by nature. These products should be transported in sealed containers. If they are spilled or leaked, clean and dry the area immediately.


Park your vehicle in a dry, well-ventilated area

Park your vehicle to save it from continuous exposure to direct sunlight.

Do not park your vehicle in a damp, poorly ventilated area. If you often wash your vehicle in the garage and place it there in wet condition, your garage may be damp. The high humidity in the garage may cause or accelerate corrosion. A wet vehicle may corrode even in a heated garage if the ventilation is poor.

Do not apply additional undercoating or rust preventive coating on or around exhaust system components such as the catalytic converter, exhaust pipes, etc. A fire could be started if the undercoating substance becomes overheated.

Vehicle Cleaning



WARNING

When cleaning the interior or exterior of the vehicle, do not use flammable solvents such as lacquer thinners, petrol and benzene. Also, do not use cleaning materials such as bleaches and strong household detergents. The materials could cause personal injury or damage to the vehicle.

Cleaning Interior

Leather upholstery

Remove loose dirt with a vacuum cleaner. Using a mild soap or saddle soap solution, wipe dirt off with a clean damp soft cloth. To remove soap, wipe the areas again with a soft cloth dampened with water. Wipe the areas dry with a soft dry cloth. Repeat this until the dirt or stain is removed, or use a commercial leather cleaner for tougher dirt or stains. If you use a leather cleaner, carefully follow the manufacturer's instructions and precautions. Do not use solvent type cleaners or abrasive cleaners.

NOTE:

- In order to keep leather upholstery looking good, it should be cleaned at least twice a year.
- If leather upholstery becomes wet, immediately wipe it dry with tissue paper or a soft cloth. Water may cause leather to harden and shrink if it is not wiped off.
- When parking on sunny days, select a shady place or use a sunshade. If leather upholstery is exposed to direct sunlight for a long time, it may discolor and shrink.
- As is common with natural materials, leather is inherently irregular in grain and cowhide has spots in its natural state. These do not affect the performance of the leather in any way.

Vinyl upholstery

Prepare a solution of soap or mild detergent mixed with warm water. Apply the solution to the vinyl with a sponge or soft cloth and let it soak for a few minutes to loosen dirt.

Rub the surface with a clean, damp cloth to remove dirt and the soap solution. If some dirt still remains on the surface, repeat this procedure.

Fabric upholstery (Except front passenger seat)

Remove loose dirt with a vacuum cleaner. Using a mild soap solution, rub stained areas with a clean damp cloth. To remove soap, rub the areas again with a cloth dampened with water. Repeat this until the stain is removed, or use a commercial fabric cleaner for tougher stains. If you use a fabric cleaner, carefully follow the manufacturer's instructions and precautions.

- Do not spill liquid or semi-solid on the front passenger's seat. If you spill it on the front passenger's seat, immediately wipe it dry with a soft cloth. Contact of liquid with sensor may impact the function of seat belt reminder sensor.
- Do not place any sharp or heavy object on passenger seat which can penetrate through seat upholstery and can cause damage to sensor.

Fabric upholstery (For front passenger

seat) Do not use liquid

Do not use liquid for cleaning as it may penetrate the fabric and damage the seat sensor.

Seat belts

Clean seat belts with a mild soap and water. Do not use bleach or dye on the belts. They may weaken the fabric in the belts.

- Do not spill liquid or semi-solid on the front passenger's seat. If you spill it on the front passenger's seat, immediately wipe it dry with a soft cloth. Contact of liquid with sensor may impact the function of seat belt reminder sensor.
- Do not place any sharp or heavy object on passenger seat which can penetrate through seat upholstery and can cause damage to sensor.

Vinyl floor mats

Ordinary dirt can be removed from vinyl with water or mild soap. Use a brush to help loosen dirt. After the dirt is loosened, rinse the mat thoroughly with water and dry it in the shade.

Carpets

Remove dirt and soil as much as possible with a vacuum cleaner. Using a mild soap solution, rub stained areas with a clean damp cloth. To remove soap, rub the areas again with a cloth dampened with water. Repeat this until the stain is removed, or use a commercial carpet cleaner for tougher stains. If you use a carpet cleaner, carefully follow the manufacturer's instructions and precautions.

Instrument panel and console

Remove loose dirt with a vacuum cleaner. Gently wipe dirt off with a tightly squeezed damp clean cloth. Repeat this until the dirt is removed.

NOTICE

Do not use chemical products that contain silicon to wipe electrical components such as the air conditioning system, audio, navigation system, or other switches. These will cause damage to the components.

NOTICE

- Liquid such as liquid aromatics, soft drinks or juice may cause discoloration, wrinkles, and cracking to resin-based parts and textiles. Immediately wipe it dry with tissue paper or a soft cloth.
- Do not leave leather products with color, fur or vinyl products, etc. in your vehicle for long periods. It may cause discoloration or deterioration of interior.

Cleaning Exterior

NOTICE

It is important that your vehicle be kept clean and free from dirt. Failure to keep your vehicle clean may result in fading of the paint or corrosion to various parts of the vehicle body.

Caring for Aluminum Wheels

NOTE:


- Do not use an acidic or alkaline detergent, or a cleaner containing petroleum solvent to wash aluminum wheels. These types of cleaner will cause permanent spots, discoloration and cracks on finished surfaces and damage to center caps.
- Do not use a bristle brush and soap containing an abrasive material. These will damage finished surfaces.

Washing

WARNING

- Never attempt to wash and wax your vehicle with the engine running.
- When cleaning the underside of the body and fender, where there may be sharp-edged parts, wear gloves and a long-sleeved shirt to protect your hands and arms from being cut.
- After washing your vehicle, carefully test the brakes before driving to make sure they have maintained their normal effectiveness.

Washing by hand



When washing the vehicle, park it in the place where direct sunlight does not fall on it as much as possible and follow the instructions below:

 Flush the underside of body and wheel housings with pressurized water to remove mud and debris. Use plenty of water.

NOTICE

When washing the vehicle:

- Avoid directing steam or hot water of more than 80°C (176°F) on plastic parts.
- To avoid damaging engine components, do not use pressurized water in the engine compartment.
- 2) Rinse the body to loosen the dirt. Remove dirt and mud from the body exterior with running water. You may use a soft sponge or brush. Do not use hard materials which can scratch the paint or plastic. Remember that the headlight covers or lenses are made of plastic in many cases.

NOTICE

To avoid damage to the paint or plastic surface, do not wipe the dirt off without ample water. Follow the above procedure. 3) Wash the entire exterior with a mild detergent or car wash soap using a sponge or soft cloth. The sponge or cloth should be frequently soaked in the soap solution.

NOTICE

When using a commercial car wash product, observe the cautions specified by the manufacturer. Never use strong household detergents or soaps.

- Once the dirt has been completely removed, rinse off the detergent with running water.
- 5) Wipe off the vehicle body with a wet chamois or cloth and allow it to dry in the shade.
- 6) Check carefully for damage to painted surfaces. If there is any damage, touch up the damage following the procedure below:
 - 1. Clean all damaged spots and allow them to dry.
 - 2. Stir the paint and touch up the damaged spots lightly using a small brush.
 - 3. Allow the paint to dry completely.

Washing by an automatic car wash

NOTICE

If you use an automatic car wash, make sure that your vehicle's body parts, such as spoilers, cannot be damaged. If you are in doubt, consult the car wash operator for advice.


Washing by a high-pressure cleaner

NOTICE

If you use a high-pressure cleaner, keep away the nozzle from your vehicle sufficiently.

- Bringing the nozzle to your vehicle too close or pointing the nozzle to the opening of front grill or bumper etc. can cause damage and malfunction of the vehicle body and parts.
- Pointing the nozzle to the weatherstrip of door glasses and doors can allow water to enter the cabin.

Waxing




After washing the vehicle, waxing and pol-ishing are recommended to further protect and beautify the paint.

- Only use waxes and polishes of good
- When using waxes and polishes, observe the precautions specified by the manufacturers.

8-6

8-7



SPECIFICATIONS

Vehicle Identification	9-1
FASTag (if equipped)	9-1
High Security Registration Plate (HSRP)	9-2
Fuel	9-3
SPECIFICATIONS	9-5

81MM01001


72RH0-74E

9

SPECIFICATIONS

Vehicle Identification


Chassis Serial Number



73R0136

The chassis and/or engine serial numbers are used to register the vehicle. They are also used to assist a Maruti Suzuki authorised workshop when ordering or referring to special service information. Whenever you have occasion to consult a Maruti Suzuki authorised workshop, remember to identify your vehicle with this number. Should you find the number difficult to read, you will also find it on the identification plate.

Engine Serial Number




The engine serial number is stamped on the cylinder block as shown in the illustration.

FASTag (if equipped)

As per Ministry of Road Transport and Highways, the FASTag (1) is mandatory for each vehicle for the purpose of electronic toll collection or any other purpose as may be defined by the Government of India.


In case of any damage to FASTag or replacement of front windscreen, please contact your nearest Maruti Suzuki authorised workshop.



9-1

EXAMPLE

As seen from inside of the vehicle



NOTE:

The picture shown is for indicative purpose only. Internal structure of actual device mounted on vehicle may be different. As seen from outside of the vehicle

EXAMPLE	
, <u>xxxx xxxx xxxx xxxx xxxx xxxx</u> (4)	

NOTE:

64MM01002

The picture shown is for indicative purpose only. Internal structure of actual device mounted on vehicle may be different.

64MM01003

NOTE:


- Any attempt to remove the tag from the windscreen will result in permanent damage to the tag.
- Use of chemical cleaners to clean the windscreen area where the tag is mounted can damage the tag.
- Use of any sharp objects on the tag can damage the tag.

High Security Registration Plate (HSRP)

As per Ministry of Road Transport and Highways, every new vehicle must have HSRP.


HSRP contains;

- Front and rear HSRP, which will be fitted with 2 snap-locks each on number plate area.
- Third license plate on front windshield.
- **Third License Plate**



(1) Third license plate

Third license plate - As seen from outside of the vehicle



(a) HSRP issuing authority name
(b) Vehicle registration number
(c) Unique laser number - Front plate
(d) Unique laser number - Rear plate
(e) Date of 1st registration

(in DD-MM-YYYY format)

(f) Green strip (BS6 vehicle)

NOTE:

The picture shown is for indicative purpose only. Internal structure of actual label mounted on vehicle may be different.

NOTE:

- Any attempt to remove the third license plate from the windscreen will result in permanent damage to the label.
- Use of chemical cleaners to clean the windscreen area where the label is mounted can damage the same.

- Use of any sharp objects on the label can damage the label.
- In the event of any replacement of the third license plate may please contact the approved authority.

Third license plate - As seen from inside of the vehicle

EXAMPLE

Notice It is unlawful for any person to duplicate, alter, change, deface, destroy, multilate, remove, tear down this Third Registration Plate Sticker, except if done by authority of law. Do not wipe with harsh abrasive materials, detergents, etc. as it may deface or damage this Sticker.

64MM01009

NOTE:

The picture shown is for indicative purpose only.

NOTE:

Color of third license plate (back) is as per HSRP regulation as defined by Ministry of Road Transport and highways.

Fuel

To avoid damaging catalytic converter, you must use unleaded petrol with an octane number (RON) of 90 or higher.

Petrol/Ethanol blends

Blends of unleaded petrol and ethanol (grain alcohol), also known as gasohol, are commercially available in certain areas. Blends of this type may be used in your vehicle if they are no more than 10% ethanol. Make sure this petrol-ethanol blend has octane ratings no lower than those recommended for the petrol.

NOTE:

If you are not satisfied with the driveability or fuel economy of your vehicle when you use a petrol/alcohol blend, you should switch back to unleaded petrol containing no alcohol.

Petrol containing MTBE

Unleaded petrol containing MTBE (methyl tertiary butyl ether) may be used in your vehicle if the MTBE content is not greater than 15%. This oxygenated fuel does not contain alcohol.

9-3

A CAUTION

Use of spurious, low quality, adulterated fuel can cause damage to the engine & engine auxilliaries, affect functioning of engine and degrade engine performance including but not limited to engine seizure.

NOTICE

The fuel tank has an air space to allow for fuel expansion in hot weather. If you continue to add fuel after the filler nozzle has automatically shut off or an initial blowback occurs, the air chamber will become full. Exposure to heat when fully fuelled in this manner will result in leakage due to fuel expansion. To prevent such fuel leakage, stop filling after the filler nozzle has automatically shut off, or when initial vent blowback occurs, if using an alternative non-automatic system.

NOTICE

Be careful not to spill fuel containing alcohol while refueling. If fuel is spilled on the vehicle body, wipe it up immediately. Fuels containing alcohol can cause paint damage, which is not covered under the New Vehicle Limited Warranty.

9-4

SPECIFICATIONS

NOTE:

Specifications are subject to change without notice. M/T: Manual Transmission A/T: Automatic Transmission

ITEM: Dimensions	UNIT: mm		
Overall length		4395	
Overall width		1735	
Overall height		1690	
Wheelbase		2740	
Track	Front	1510	
	Rear	1520	

ITEM: Mass (weight)	UNIT: kg	
	5M/T	1135-1160
Curb mass (weight)	A/T	1165-1170
Gross vehicle mass (weight) rating	5M/T	1730
	A/T	1740
Permissible maximum Axle Weight	Front	815
	Rear	960

9-5

ITEM: Engine		
K15B (DOHC)		
4		
74.0 mm		
85.0 mm		
1462 cm ³		
10.5 : 1		

ITEM: Electrical		
Standard spark plug NGK KR6A-10		NGK KR6A-10
Lead-acid battery		12V ISS N55 ^{*1}
Lithium-ion battery With Smart Hybrid Maintenance free ^{*2}		Maintenance free ^{*2}
Fuses		See "INSPECTION AND MAINTENANCE" section.

*1 When battery replacement is necessary, use only N55 (Exide Conservo) battery. Else it may deteriorate performance of Smart Hybrid system.
*2 If the lithium-ion battery is completely discharged, the battery cannot be recharged. When replacing or disposing the lithium-ion battery, consult the authorised dealer.

9-6

ITEM: Lights		WATTAGE	BULB No.
l le e dl'arbé	High beam	12V 60W	HB3
Headlight	Low beam	12V 55W	H11
Turn signal light	Front	12V 21W	WY21W
	Rear	12V 21W	PY21W
Side turn signal light (on fender)		12V 5W	WY5W
Side turn signal light (on outside rearview mirror)		LED	
Position light		12V 5W	W5W
Tail/brake light		LED	
License plate light		12V 5W	W5W
Reversing light		12V 16W	W16W
Interior light		12V 10W	_
Front fog light (if equipped)		12V 19W	H16
High mount stop light		LE	D

ITEM: Wheels and Tires		
Tire size (front, rear and spare*2)185/65R15 88H*1		
Rim size	15X5 1/2J	
Tire pressures	For the specified tire pressure, see the Tire Information Label loca on the driver's door lock pillar.	

*1 If you cannot prepare tires with the specified load index rate and speed symbol, prepare tires with higher load index rate and speed you cc symbol. *2 -

• The spare wheel provided with alloy wheel variant is of steel wheel rim, hence follow 4 tire rotation only. (Refer: Section Inspection and Maintenance)

• The provision of different spare wheel is as per government notification/regulation (MORTH notification vide GSR 625 (E)).

ITEM: Capacities (approx.)			
Fuel tank			45 L [#]
Coolant N		See "INSPECTION AND MAINTENANCE"	4.7 L
(including reservoir tank)	A/T	section.	4.6 L
Engine oil		Classification: API SN Viscosity: SAE 0W-16	3.1 L (replacement with oil filter)
Transmission oil	M/T	"MARUTI GENUINE GEAR OIL 75W"	2.6 L
	A/T	"SUZUKI AT OIL AW-1"	5.0 L
Brake fluid / Clutch fluid		MARUTI GENUINE BRAKE FLUID (MGBF) or DOT 3.	Refill to the proper oil level according to the instructions in "INSPECTION AND MAINTENANCE" section.

The fuel tank capacity is slightly more than the recommended quantity of fuel that you can fill. The additional voluminous space is provided for safety and scientific reasons.

9-8